



Magnum

SPRAY INJECTION PATCHER

Parts Manual - 91285
Revision N

Fill in the appropriate fields that apply to this machine.

Machine S/N: _____

1st Hose S/N: _____

2nd Hose S/N: _____

1st Pump S/N: _____

2nd Pump S/N: _____

Engine S/N: _____

Compressor S/N: _____

Gear Box S/N (Patcher): _____

Blower S/N (Magnum): _____

Machine Views



Machine Views



Table of Contents

Contents

1.0 About This Manual.....	1-1
1.1 How to use this Manual	1-1
1.2 General Machine Overview.....	1-1
1.3 Heating System Overview.....	1-2
1.4 Emulsion System Overview	1-2
1.5 Aggregate System Overview	1-2
1.6 Flush System Overview	1-2
2.0 Safety Precautions	2-1
2.1 General Safety.....	2-1
2.2 Personal Safety	2-1
2.3 Equipment or Operational Safety.....	2-1
2.4 Safety Symbols and Notices	2-3
3.0 Limited Warranty	3-1
3.1 Warranty Claim Instructions.....	3-2
4.0 Machine Specifications	4-1
5.0 Operating Instructions.....	5-1
5.1 Introduction.....	5-1
5.2 Preparing the Machine for Start Up.....	5-1
5.3 Start Up	5-5
5.4 Pressurize the Emulsion Tank	5-5
5.5 Charge the Auger with Stone.....	5-6
5.6 Set the Auger Feed for Operation	5-7
5.7 Purge the Solvent from the Emulsion Lines.	5-8
5.8 Patching Operation	5-8
5.9 Shut Down Procedure.....	5-11
5.10 Asphalt Emulsion Line Flush Procedure	5-11
5.11 Auger Flush Procedure.....	5-12
5.12 Reversing Augers Procedure.....	5-13
5.13 Boom Height Adjustment Procedure.....	5-14
5.14 Storing the Machine.....	5-15
5.15 Overnight Heater	5-15
6.0 Maintenance Instructions.....	6-1
6.1 Engine	6-1

Table of Contents

6.2 Hydraulic System	6-1
6.3 Blower.....	6-1
6.4 Air Compressor.....	6-1
6.5 Air Cleaners for Blower and Engine	6-1
6.6 Auger Bearings	6-1
6.7 Boom Bearings	6-1
6.8 Bearing Stub Support Shaft on Engine.....	6-1
6.9 Wheel Bearing	6-2
6.10 Brakes	6-2
6.11 Lug Nuts	6-2
6.12 Tongue Jack	6-2
6.13 Maintenance Chart.....	6-3
6.14 Service Instructions.....	6-4
6.15 Recommended Fluids and Lubricants.....	6-4
6.16 General Maintenance Parts	6-5
6.17 Recommended Spare Parts.....	6-5
6.18 Material Specifications	6-6
6.19 Stone/Aggregate Specifications	6-6
6.20 Emulsion Specifications	6-6
6.21 Wiring Code for Tail Lights and Brakes	6-6
6.23 Tensioning V-Belt Drive Procedure	6-7
6.24 Maintenance Guide of the V-Belt Drive	6-8
6.25 Drain Emulsion Tank.....	6-9
6.26 Adjusting the Air Pressure Regulator	6-9
6.27 Cleaning Nozzle Spray Ring	6-10
7.0 How to Use a Multimeter.....	7-1
7.1 Checking DC Voltage with a Multimeter	7-1
7.2 Checking AC Voltage with Multimeter	7-1
7.3 Checking Resistance (Ohms)	7-1
7.3.1 How to Check Wire Continuity	7-1
7.3.2 How to Check RTD Sensor	7-1
7.4 Checking Amperage	7-2
8.0 Troubleshooting.....	8-1
8.1 Emulsion is Not Flowing from the Nozzle	8-1

Table of Contents

8.2 Stone Not Flowing Through Hose	8-2
8.3 Engine Will Not Start.....	8-4
8.4 Emulsion Not Heating from Engine	8-5
8.5 Emulsion Not Heating From Overnight Heater	8-6
8.6 Hydraulic System Troubleshooting	8-7
8.7 Electrical Schematic for Hydraulic System	8-9
8.8 Hydraulic Valve Plug Layout.....	8-10
8.9 Hydraulic Schematic	8-11
9.0 About the Illustrated Parts List	9-1
9.1 Ordering Crafcoc Parts.....	9-1
9.2 Magnum Parts List.....	9-2
9.3 Nozzle Emulsion Line Connection Parts List.....	9-8
9.4 Operator Boom Parts List	9-10
9.5 Hydraulic and Fuel Tank Parts List	9-12
9.6 Dual Hydraulic Control Valve Parts List	9-13
9.7 Air Blower Parts List	9-14
9.8 Blower Air Cleaner Parts List	9-15
9.9 Hydraulic Auger Motor Parts List	9-16
9.10 Aggregate Feed System Air Lock Parts List.....	9-17
9.11 Emulsion Tank Drain Valve Parts List.....	9-18
9.12 Hitch Area Parts List	9-19
9.13 Solvent Flush Tank Parts List	9-20
9.14 Battery Parts List	9-21
9.15 Emulsion Tank Top Valve Assembly Parts List	9-22
9.16 Boom Control Console Parts List.....	9-23
9.17 Engine and Engine Components Parts List.....	9-24
9.18 Engine Intake and Exhaust Parts List	9-25
9.19 Engine Air Compressor Parts List.....	9-26
9.20 Engine Control Panel Parts List	9-27
9.21 Belt Drive Parts List	9-28
9.22 Emulsion Tank Gauge Parts List.....	9-30
9.23 Crack Sealing Attachment Option Parts List	9-31
9.24 Electric Throttle Option Parts List.....	9-32
9.25 8 Foot Quick Flush Hose Option Parts List	9-33

Table of Contents

9.26 External Water/Fuel Separator Option Parts List.....	9-34
9.27 Hitch Extension Option Parts List.....	9-35
9.28 Air Discharge System Parts List.....	9-36
9.29 Aggregate Screw Feed Assembly Parts List	9-38
9.30 Hydraulic Tailgate Assembly Parts List	9-40
9.31 Hydraulic Schematic and Parts List.....	9-42
9.32 Emulsion Supply Line Parts List.....	9-44
9.33 Solvent Flush Line Parts List.....	9-45
9.34 Air Supply Line Schematic	9-46
9.35 Wiring Schematic.....	9-47
9.36 Control Panel Wiring Schematic.....	9-48
10.0 Hydraulic Tailgate Mounting Instructions.....	10-1
10.1 Mounting Information	10-1
10.2 Exploded View of Tailgate and Custom Mounts	10-1
10.3 Assembled View of Tailgate and Custom Mounts	10-2
10.4 Mounted Hydraulic Tailgate	10-3

List of Figures

Figure 5.1 Diesel Fuel Fill Cap and Level Gauge.....	5-3
Figure 5.2 Hydraulic Fluid Fill Cap and Level Gauge.....	5-3
Figure 5.3 Emulsion Thermostat.....	5-4
Figure 5.4 Emulsion Level.....	5-4
Figure 5.5 Tailgate Hydraulic Connections.....	5-4
Figure 5.6 Nozzle Removed from Flush Box.....	5-5
Figure 5.7 Control Panel.....	5-6
Figure 5.8 Flow Control Valve.....	5-7
Figure 5.9 Emulsion Tank Valve.....	5-8
Figure 5.10 Tack Coat.....	5-9
Figure 5.11 Building up the Repair.....	5-10
Figure 5.12 Finishing the Repair.....	5-10
Figure 5.13 Nozzle Flush Box.....	5-11
Figure 5.14 Hopper Gate Handle.....	5-12
Figure 5.15 Reversing Augers.....	5-13
Figure 5.16 Boom Height Adjustment.....	5-14
Figure 6.1 Lug Bolt Tightening Sequence.....	6-2
Figure 6.2 Air Pressure Regulator.....	6-9
Figure 6.3 Nozzle Spray Ring.....	6-10
Figure 7.1 Standard Multimeter.....	7-2
Figure 7.2 Clamp-On Amp Meter/Multimeter.....	7-3
Figure 8.1 Electrical Schematic for Hydraulic System (PN 92353).....	8-9
Figure 8.2 Hydraulic Valve Plug Layout.....	8-10
Figure 8.3 Hydraulic Schematic (P/N 92352).....	8-11
Figure 9.1 Right Iso View.....	9-2
Figure 9.2 Left Iso View.....	9-4
Figure 9.3 Nozzle Exploded View.....	9-6
Figure 9.4 Rear View.....	9-6
Figure 9.5 Nozzle Emulsion Line Connection.....	9-8
Figure 9.6 Operator Boom Parts.....	9-10
Figure 9.7 Hydraulic and Fuel Tanks.....	9-12
Figure 9.8 Dual Hydraulic Control Valve.....	9-13
Figure 9.9 Air Blower.....	9-14
Figure 9.10 Blower Air Cleaner.....	9-15
Figure 9.11 Hydraulic Auger Motor.....	9-16
Figure 9.12 Aggregate Feed System Air Lock.....	9-17
Figure 9.13 Emulsion Tank Drain Valve.....	9-18
Figure 9.14 Hitch Area.....	9-19
Figure 9.15 Solvent Flush Tank.....	9-20

List of Figures

Figure 9.16 Battery	9-21
Figure 9.17 Emulsion Tank Top Valve Assembly	9-22
Figure 9.18 Boom Control Console	9-23
Figure 9.19 Engine and Engine Components	9-24
Figure 9.20 Engine Intake and Exhaust	9-25
Figure 9.21 Engine Air Compressor	9-26
Figure 9.22 Engine Control Panel	9-27
Figure 9.23 Belt Drive	9-28
Figure 9.24 Emulsion Tank Gauge	9-30
Figure 9.25 Crack Sealing Attachment	9-31
Figure 9.26 Electric Throttle Option	9-32
Figure 9.27 8 Foot Quick Flush Hose Option	9-33
Figure 9.28 External Water/Fuel Separator Option	9-34
Figure 9.29 Hitch Extension Option	9-35
Figure 9.30 Air Discharge System	9-36
Figure 9.31 Aggregate Screw Feed Assembly	9-38
Figure 9.32 Hydraulic Tailgate Assembly	9-40
Figure 9.33 Hydraulic Schematic (P/N 92352)	9-42
Figure 9.34 Emulsion Supply Line Parts List (P/N 91264)	9-44
Figure 9.35 Solvent Flush Line Parts List	9-45
Figure 9.36 Air Supply Line Schematic (P/N 91266)	9-46
Figure 9.37 Wiring Schematic (P/N 92353)	9-47
Figure 9.38 Control Panel Wiring Schematic (P/N 92251)	9-48
Figure 10.1 Exploded View of Tailgate and Custom Mounts	10-1
Figure 10.2 Assembled View of Tailgate and Custom Mounts	10-2
Figure 10.3 Mounted Tailgate	10-3

List of Tables

Table 2-1 Safety Symbols and Notices	2-3
Table 2-2 Safety Symbols and Notices (continued)	2-4
Table 4-1 Machine Specifications	4-1
Table 5-1 Preparing the Machine for Start Up.....	5-1
Table 5-2 Preparing the Machine for Start Up (continued).....	5-2
Table 5-3 Pressurize the Emulsion Tank	5-5
Table 5-4 Charge the Auger with Stone.....	5-6
Table 5-5 Set the Auger Feed for Operation.....	5-7
Table 5-6 Purge the Solvent from the Emulsion Lines	5-8
Table 5-7 Patching Operation	5-8
Table 5-8 Patching Operation (continued)	5-9
Table 5-9 Patching Operation (continued)	5-9
Table 5-10 Patching Operation (continued)	5-10
Table 5-11 Asphalt Emulsion Line Flush Procedure	5-11
Table 5-12 Auger Flush Procedure.....	5-12
Table 5-13 Reversing Augers Procedure.....	5-13
Table 5-14 Boom Height Adjustment Procedure.....	5-14
Table 5-15 Overnight Heaters	5-15
Table 6-1 Maintenance Chart	6-3
Table 6-2 Service Instructions	6-4
Table 6-3 Recommended Fluids and Lubricants.....	6-4
Table 6-4 General Maintenance Parts	6-5
Table 6-5 Recommended Spare Parts.....	6-5
Table 6-6 Emulsion Specifications.....	6-6
Table 6-7 V-Belt Tension Specifications	6-7
Table 6-8 Maintenance Guide of the V-Belt Drive	6-8
Table 6-9 Drain Emulsion Tank	6-9
Table 6-10 Adjusting Air Pressure Regulator	6-9
Table 6-11 Cleaning Nozzle Spray Ring	6-10
Table 8-1 Emulsion Flow Troubleshooting.....	8-1
Table 8-2 Stone Flow Troubleshooting	8-2
Table 8-3 Stone Flow Troubleshooting (continued).....	8-3
Table 8-4 Engine Will Not Start Troubleshooting	8-4
Table 8-5 Emulsion Not Heating from Engine Troubleshooting.....	8-5
Table 8-6 Emulsion Not Heating From Overnight Heater Troubleshooting.....	8-6
Table 8-7 Hydraulic System Troubleshooting	8-7
Table 8-8 Hydraulic System Troubleshooting (continued).....	8-8
Table 9-1 Right Iso View Parts List.....	9-3

List of Tables

Table 9-2 Left Iso View Parts List	9-5
Table 9-3 Rear View Parts List	9-7
Table 9-4 Nozzle Emulsion Line Connection Parts List.....	9-9
Table 9-5 Operator Boom Parts List	9-11
Table 9-6 Hydraulic and Fuel Tank Parts List	9-12
Table 9-7 Dual Hydraulic Control Valve Parts List.....	9-13
Table 9-8 Air Blower Parts List.....	9-14
Table 9-9 Blower Air Cleaner Parts List	9-15
Table 9-10 Hydraulic Auger Motor Parts List.....	9-16
Table 9-11 Aggregate Feed System Air Lock Parts List.....	9-17
Table 9-12 Emulsion Tank Drain Valve Parts List	9-18
Table 9-13 Hitch Area Parts List	9-19
Table 9-14 Solvent Flush Tank Parts List	9-20
Table 9-15 Battery Parts List	9-21
Table 9-16 Emulsion Tank Top Valve Assembly Parts List	9-22
Table 9-17 Boom Control Console Parts List	9-23
Table 9-18 Engine and Engine Components Parts List.....	9-24
Table 9-19 Engine Intake and Exhaust Parts List	9-25
Table 9-20 Engine Air Compressor Parts List	9-26
Table 9-21 Engine Control Panel Parts List	9-27
Table 9-22 Belt Drive Parts List	9-29
Table 9-23 Emulsion Tank Gauge Parts List.....	9-30
Table 9-24 Crack Sealing Attachment Option Parts List.....	9-31
Table 9-25 Electric Throttle Option Parts List.....	9-32
Table 9-26 8 Foot Quick Flush Hose Option Parts List	9-33
Table 9-27 External Water/Fuel Separator Option Parts List.....	9-34
Table 9-28 Hitch Extension Option Parts List.....	9-35
Table 9-29 Air Discharge System Parts List.....	9-37
Table 9-30 Aggregate Screw Feed Assembly Parts List	9-39
Table 9-31 Hydraulic Tailgate Assembly Parts List	9-41
Table 9-32 Hydraulic Parts List	9-43
Table 9-33 Emulsion Supply Line Parts List.....	9-44
Table 9-34 Solvent Flush Line Parts List.....	9-45
Table 10-1 Mounted Tailgate Parts List	10-3

Chapter 1 Introduction

1.0 About This Manual

This manual is supplied with each new Crafcro Magnum Spray Injection Patcher. The manual assists your machine operators in the proper use of the Magnum and provides information about the machine's mechanical functions.

Your Crafcro Magnum Spray Injection Patcher is specially made to give excellent service and save maintenance expense. However, as with all specially engineered equipment, you will get the best results at minimum cost if you:


- Operate your machine as instructed in this manual.
- Maintain your machine regularly as stated in this manual.

1.1 How to use this Manual

This manual is formatted to start each new chapter on the right page. There may be a blank page on the left page if the previous chapter ends on the right page.

If you are viewing this in a digital format (PDF) the following features are available:

1. The Table of Contents, List of Tables, and List of Figures are all hyperlinks, when left mouse clicked on section, table, or figure you will be sent to that page.
2. The blue highlighted text throughout the manual is a hyperlink, when left mouse clicked you will be sent to that page, table, or figure.
3. The panel to the left in the PDF is a bookmarks panel, if you left mouse click on any section/heading in the bookmarks panel you will be sent to that page.
4. There is an attachments icon (paper clip) to the left of the bookmarks, this is where you will find full size prints of the control box, electrical, and hydraulic schematics if available.

	WARNING
	<p>California Proposition 65 Warning</p> <p>Engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm. Always use care to avoid breathing engine exhaust. Failure to comply could result in death or serious injury.</p>

1.2 General Machine Overview

The Crafcro Magnum is a Spray Injection Patcher. It is designed to mix aggregate and emulsion together, and spray it into potholes and repair other pavement imperfections. The spray injection compacts the mixture into the pothole to create a strong bond that will last for many years. Plus traffic can drive over the patched area almost immediately.

Chapter 1 Introduction

1.3 Heating System Overview

There are two heating systems on the Magnum. There is an electrically activated heater (referred to as the overnight heater) and an engine based heater system. The overnight heater is designed to be plugged into an outlet from a building in order to slowly heat the emulsion and keep it at or close to operating temperatures. The engine based heater uses the engine coolant system to flow warm coolant through lines that go into the emulsion tank, as well as being wrapped around the emulsion lines going to the various locations on the machine. The engine based heating system is automatic and will heat the emulsion system to a similar temperature as engine. There are shut off lines to start or stop circulation if needed.

1.4 Emulsion System Overview

The emulsion system is a compressed air powered pump system. The air compressor on the engine builds air pressure to the emulsion tank. Once the tank has sufficient air pressure, the emulsion will flow from the system when the valves are set to the correct positions for operation.

1.5 Aggregate System Overview

The aggregate system combines two methods to spray it from the nozzle. The first system is powered by a hydraulic pump and motor. It powers an auger located inside the tailgate on the back of the dump truck. This auger is designed to provide a constant flow of aggregate into the Magnum hopper. It requires very little operator input other than operating the dump bed to the most effective angle. There is also a hydraulically powered center auger that takes the aggregate from the hopper and delivers a constant flow to the air powered delivery system. It is proven to be the most effective method to deliver a constant and precise flow of aggregate, and can also deliver more volume than an air only system. Once the aggregate drops into the airlock, the blower powers the rock through the rest of the hose system and out the nozzle. The air is also used to clean out and dry the potholes or areas that need coverage.

1.6 Flush System Overview

The Magnum is equipped with a solvent flushing system to help keep the emulsion lines and nozzle from getting clogged up from dried emulsion. There is an on board pressurized tank that stores and delivers the solvent through the lines and nozzle to flush the system into the flush box. This process needs to happen after every use of the emulsion or else the emulsion will dry out and clog the lines. If flushed properly after every use, no clogging issues should arise.

Chapter 2 Safety Precautions

2.0 Safety Precautions

For more in-depth safety information, please see Safety Manual (PN 26221) which comes with the machine. Or contact your nearest authorized Crafcro Distributor at crafcro.com/Distributors.

2.1 General Safety

- Crafcro, Inc. assumes no liability for an accident or injury incurred through improper use of the machine.
- Read this manual thoroughly before operating the machine.
- Obey all CAUTION and WARNING signs posted on the machine.
- Make sure an operator fully knows how to operate the machine before using the machine.

2.2 Personal Safety

- The high operating temperatures of this machine and the material it contains requires that protective clothing, gloves, hard-soled shoes, and safety glasses or a face shield be worn at all times by operators of the machine.
- Bodily contact with hot material or engine coolant can cause severe burns.
- Keep hands, feet, and clothing away from all moving parts.

2.3 Equipment or Operational Safety

- Do not operate the machine in buildings or work areas that do not have sufficient airflow.
- Shut down the engine before refilling the fuel tank.
- Always keep a correctly maintained fire extinguisher near the machine and know how to use it.
- Temperature control is for the overnight heater only. Operation temperature cannot be adjusted.
- Replace any hoses which show signs of wear, fraying or splitting.
- Precaution is the best insurance against accidents.
- Make sure all fittings and joints are tight and do not leak each time the machine is used.
- Do not leave the machine unattended while it is running.
- Tighten all bolts and screws every 100 hours of machine operation.
- Check the machine thoroughly for any signs of improper wear.
- Crafcro, Inc. recommends that the purchasers or users of the machine frequently and consistently undertake inspections and protective measures with respect to the use and application of the machine.
- Crafcro, Inc. assumes no liability for an accident or injury incurred through the improper use of the machine.
- Do not disassemble any valve while under pressure.
- Do not fill the emulsion tank more than 2/3's full. The emulsion will expand after the emulsion is heated up. Starting at the bottom of the lid opening, fill the emulsion about 12" down from the bottom of the opening. If you overfill the tank, you can damage the machine, and will void the warranty.
- Never operate the machine without all guards in place.

Chapter 2 Safety Precautions






- Do not open the hatch lid on the material tank, solvent flush tank fill port, or emulsion tank rear valve assembly, AS ALL OF THESE TANKS ARE UNDER PRESSURE! To relieve pressure, use the emulsion tank top valve assembly. Open the ½" bronze ball valve. To relieve pressure on the diesel flush tank, open the 2" brass ball valve. The pressure gauge should read "0" before opening any tank.
- Do not plug in emulsion tank overnight heater unless emulsion is above the heating element enclosure inside the tank. This requires a minimum of 60 gallons in the tank.
- Keep emulsion tank airtight when not in use.
- Do not allow emulsion to freeze.
- Do not put hands, feet, etc. near truck auger tailgate.
- Do not fill flush tank more than 2/3 full.
- Do not operate near open flame.
- Do not use any type of flame to unclog the emulsion hose or spray ring if they should become clogged.
- Do not operate diesel engine above 2200 RPM MAX.
- Do not touch the silencer as it can become very hot while the machine is operating.
- Hose should not be kinked or run over by any equipment. Hose should not be stored outdoors due to potential damage from the elements, which may shorten hose life.

Chapter 2 Safety Precautions

2.4 Safety Symbols and Notices







Important safety symbols and notices are marked on the machine and in this manual. Failure to comply could result in equipment damage, operational malfunction, serious injury, or death. Please read and comply with all symbols and notices. The table below includes the most commonly used symbols and notices.

Table 2-1 Safety Symbols and Notices

Symbol	Item	Remarks
WARNING	Warning	Refers to possible bodily injury or death.
CAUTION	Caution	Refers to possible equipment damage or operational malfunction.
	Severe Burn Hazard	Hot material can cause severe burns.
	Protective Shoes	Wear hard-soled work shoes.
	Protective Gloves	Wear heat resistant gloves.
	Protective Face or Eye Wear	Wear face shield or safety glasses.
	Body Crush Hazard	Do not stand between trailer and hitch when hooking melter to truck.

Chapter 2 Safety Precautions

Table 2-2 Safety Symbols and Notices (continued)

Symbol	Item	Remark
	Crush Hazard	Keep feet and legs clear.
	Pinch Hazard	Keep hands and feet clear.
	Moving Machinery	Never reach into moving machinery.
	Exhaust Hazard	Avoid breathing engine exhaust.
	Noise Hazard	Ear protection is advisable.
	Read Manual	Read and understand operator and safety manuals before operating machine.

Chapter 3 Warranty Information

3.0 Limited Warranty

Crafco, Inc., through Crafco or one of its affiliated distributors, will replace for the original purchaser free of charge any parts found upon examination by the factory at Chandler, Arizona, to be defective in material or workmanship. This warranty is for a period of one year from the in-service date, but excludes engine or components, tires, and battery as these items are subject to warranties issued by their manufacturers.

Crafco, Inc. shall not be liable for parts that have been damaged by accident, alteration, abuse, improper lubrication/maintenance, normal wear, or other cause beyond our control.

The warranty provided herein extends only to the repair and/or replacement of those components on the equipment covered above and does not cover labor costs. The warranty does not extend to incidental or consequential damages incurred as a result of any defect covered by this warranty.

All transportation and labor costs incurred by the purchaser in submitting or repairing covered components must be borne by the purchaser. Crafco, Inc. specifically disavows any other representation, warranty, or liability related to the condition or use of the product

CAUTION

Use of replacement parts other than genuine Crafco parts may impair the safety or reliability of your equipment and nullifies any warranty.

Chapter 3 Warranty Information

3.1 Warranty Claim Instructions

Crafco, Inc. warrants parts and machinery purchased through Crafco or one of its affiliated distributors for one year from purchased or in-service date**. If parts fail to function within the first year of purchase, a return authorization number (RA) must be obtained. If the part was purchased through Crafco, Inc., please contact Crafco returns department at [Returns@Crafco.com](mailto>Returns@Crafco.com) for an RA number or if purchased through a Crafco distributor please contact your distributor. Note: if the part has a serial number associated with it, for example; a machine or electric hose or wand, this must be furnished when requesting the RA number. The customer will be emailed or faxed an RA form with all instructions to return the item to Crafco, Inc. See example. If the part is found to be within the one year warranty period and has not been abused or modified, a credit will be issued to the customer's account or credit card. The customer may request the part be replaced instead of receiving a credit, if desired.

**Wear items are not covered under Crafco, Inc. limited warranty. A wear item is defined as but not limited to: material pumps, sealing tips, tires, etc.

Note: All engine warranties are covered through the engine manufacturer. If you need information for a distributor in your area please contact us and we will direct you to the closest engine distributor.

All parts returned are tested and evaluated. If the part has been modified in any way without prior consent from a Crafco, Inc. representative; the warranty is void.

Please follow the instructions stated below when calling in a Warranty Claim. Failure to follow these procedures may be cause to void the warranty.

Call your local Crafco Distributor. If you do not know who your local distributor is, call a Crafco Customer Service Representative, (Toll Free 1-800-528-8242) for name, location and telephone number.

On contacting the distributor, be prepared to identify the serial number, model number, engine number, engine manufacturer, and the date of purchase if available.

Should the cause of the malfunction be a defective part, the Distributor will advise you of the procedure to follow for a replacement.

The warranty is valid only for parts, which have been supplied or recommended by Crafco, Inc.

If you have any additional questions regarding warrant repairs and parts, please do not hesitate to call toll free 1-800-528-8242.

For Warranty:
Crafco, Inc.
25527 South Arizona Avenue, Chandler, AZ
85248
Phone: (480) 655-8333 or (800) 528-8242
Fax: (480) 655-1712

For all other inquires:
Crafco, Inc.
6165 West Detroit Street
Chandler, AZ 85226
Phone: (602) 276-0406 or (800) 528-8242
Fax: (480) 961-0513
CustomerService@crafco.com

Chapter 4 Machine Specifications

4.0 Machine Specifications

Table 4-1 Machine Specifications

Specification	PN 91000
Emulsion Tank Capacity	250 Gallons
Emulsion Temperature Range	160°F to 175°F
Tank Opening Size	8" Diameter
Air Blower	Positive Displacement 2475-2887 RPM
Hydraulic Pump Flow	11 Gallons per min @ 1200 RPM
Hydraulic Tank Capacity	22 Gallons
Hydraulic Pressure (running w/ load)	600-1000 PSI
Hydraulic Pressure Max Relief	1850 PSI
Center Auger Speed	39 +/- 10 RPM
Truck Auger Speed	31 +/- 6 RPM
Engine John Deere Diesel	Four cylinder Model 4045T 80 HP @ 2400 RPM
Diesel Fuel Tank Capacity	22 Gallons
Solvent Flush Tank Capacity	30 Gallons
Operating Temperature Range	Above 0°F
Dry Weight	Approximately 6400 lbs.
Axle Capacity	Dual 6000 lbs.
Tires	ST225/75R15, Load Range D

Chapter 5 Operating Instructions

5.0 Operating Instructions

5.1 Introduction

The Crafcro Magnum Spray Injection Patcher was developed to apply an asphalt emulsion and aggregate mixture to effectively fill and repair pot holes or other road imperfections.

Note: DO NOT attempt to operate the machine without using these and all other instructions.


5.2 Preparing the Machine for Start Up

Table 5-1 Preparing the Machine for Start Up

Step	Action
1	Fill the engine fuel tank with diesel fuel. See Figure 5.1 Diesel Fuel Fill Cap and Level Gauge Note: Refer to the manufacturer's instruction manual for more specifications on fuel requirements.
2	Check the oil level in the engine crankcase. Refer to the manufacturer's instruction manual for the engine.
3	Check the hydraulic fluid level while at a temperature of 70°F. Add fluid if necessary. See Figure 5.2 Hydraulic Fluid .
4	Emulsion – The emulsion tank should be filled with an asphalt emulsion suitable for the climate and condition in which the unit will be operating. Commonly this is an RS-2 or a CRS-2. Note: Not all emulsions are compatible. When changing emulsion brand or type, you should completely empty and flush out the tank before the new emulsion is added.
WARNING	
	Make sure to release pressure from the emulsion tank before opening the emulsion tank lid! Failure to do so could cause personal injury or damage to the machine.
5	Proper operation temperature for the emulsion is 160°F (+/- 10°F). If the emulsion is below this temperature the unit must be plugged into a 110 volt outlet. (Optional 220 volt wiring is available) The thermostat should be set to 160°F. The electric heating elements are designed to gently heat the emulsion at a rate of 10°F per hour (at 110V). If the emulsion temperature is low it will take several hours to get the emulsion to operation temperature. Plugging in the unit overnight is recommended. See Figure 5.3 Emulsion Thermostat Note: Never allow emulsion to freeze or heat emulsion above 190°F.
6	Emulsion Level- The Magnum comes with a dipstick that can be used to check the level. The dipstick is only meant to measure from the top of the emulsion to the lip of the lid. Do not submerge the dipstick into the emulsion. Just barely touch it to the top of the emulsion, take note of the notch, then wipe the dip stick clean so it won't stick in the holder. Compare notch to gauge on side of tank for approx. gallons. See Figure 5.4 Emulsion Level

Chapter 5 Operating Instructions

Table 5-2 Preparing the Machine for Start Up (continued)

7	<p>Stone – Fill the dump truck bed with the required amount of stone. A 3/8” crushed washed aggregate is the most common and versatile stone to use in patching operations. Smaller stone (1/4”) can be used and may improve results when skin patching. Larger stone (1/2”) can be used to improve results when patching larger holes or repairing shoulders.</p> <p>Note: Each day, before operating the unit, raise the dump body on the truck and rinse the stone with water. Allow the water to drain for several minutes. This will greatly reduce the dust developed during the patching operation and will improve the adhesion of the emulsion to the stone.</p>
8	<p>Solvent- Fill the solvent tank with diesel fuel or another solvent that has been recommended by the emulsion supplier.</p>
9	<p>Connect Tailgate Hydraulics - With the engine off, disconnect the hydraulic lines from the machine and connect them to the tailgate. Make sure the fittings are clean. Be sure to connect the black quick connect fitting to the corresponding black male fitting, otherwise the tailgate auger will run backwards.</p>
CAUTION	
	<p>Always have the tailgate hydraulic lines connected either in the stored position or to the tailgate, this will prevent undue strain on the hydraulic system. See Figure 5.5 Tailgate Hydraulic Connections</p>
WARNING	
	<p>The safe operation of this machine is the operator’s responsibility.</p> <p>Use extreme care when operating this machine; safety is the result of being careful and paying attention to details. Remember the emulsion material is at least 160°F, and the hydraulic fluid can get up to 200°F.</p> <p>Always put on protective clothing, gloves, hard-soled shoes, and safety glasses or a face shield, and ear protection. Be sure that all joints and fittings are tight and leak proof. Immediately replace any hose, which shows any signs of wear, fraying, or splitting. Tighten all bolts, nuts, and screws every 100 hours.</p>

Chapter 5 Operating Instructions



Figure 5.1 Diesel Fuel Fill Cap and Level Gauge



Figure 5.2 Hydraulic Fluid Fill Cap and Level Gauge

Chapter 5 Operating Instructions



Figure 5.3 Emulsion Thermostat




Figure 5.4 Emulsion Level



Figure 5.5 Tailgate Hydraulic Connections

Chapter 5 Operating Instructions

5.3 Start Up

5.4 Pressurize the Emulsion Tank

Table 5-3 Pressurize the Emulsion Tank

Step	Action
1	Remove the boom from the holder and remove the nozzle from the flush box.
WARNING	
	Failure to remove the nozzle from the flush box will blow any solvent and emulsion from the flush box out onto the machine, ground and operator. See Figure 5.6 Nozzle Removed from Flush Box .
2	Make sure all pressure relief valves on the tanks are closed.
3	With the nozzle pointed at the ground, start the engine by holding in the red Murphy Switch and turning the key. Once engine is running, release Murphy Switch and allow to run for several minutes. See Figure 5.7 Control Panel . The air compressor runs when the engine is running and will automatically start building pressure in the emulsion tank. Allow the pressure to build until the pressure reaches a minimum of 90 PSI.



Figure 5.6 Nozzle Removed from Flush Box

Chapter 5 Operating Instructions




Figure 5.7 Control Panel

5.5 Charge the Auger with Stone

Table 5-4 Charge the Auger with Stone

Step	Action
1	Set the center auger flow control at 2 turns out from closed and the truck auger control at 1 turn out from closed. See Figure 5.8 Flow Control Valve .
2	With the engine running at an idle, turn "ON" the "STONE" switch at the operator control panel.
3	Stone will quickly start to shoot out of the nozzle. Run the unit for 45 to 90 seconds until stone is flowing smoothly with no surging then shut "OFF" the "STONE" switch.
4	Shut off the engine, place the boom back in the transport support, and place the nozzle in the "FLUSH BOX".

Chapter 5 Operating Instructions




Figure 5.8 Flow Control Valve

5.6 Set the Auger Feed for Operation

Table 5-5 Set the Auger Feed for Operation

Step	Action
1	SKIN PATCHING – Set center auger at 2 turns out from closed. Truck auger at 1 turn out from closed.
2	POT HOLE PATCHING - Set center auger at 2 turns out from closed. Truck auger at 1 turn out from closed.
3	SHOULDER REPAIRS - Set center auger at 3 turns out from closed. Truck auger at 1.5 turns out from closed.
	<p>Note: These settings may be adjusted to meet the operators comfort level. As you make adjustments, the augers should be synchronized to keep the flow of material into the hopper above the top of the auger and auger tube. About half full in the hopper is correct. Overfilling the hopper can jam the auger. There is no perfect setting. It's all based on how much rock the operator needs to do the patch. Changes in rock size, shape, engine RPM, and valve flow will all contribute to varying the flow of rock.</p>

Chapter 5 Operating Instructions

5.7 Purge the Solvent from the Emulsion Lines.

Table 5-6 Purge the Solvent from the Emulsion Lines

Step	Action
1	Locate the EMULSION TANK VALVE at the rear of the emulsion tank. See Figure 5.9 Emulsion Tank Valve .
2	With the nozzle positioned in the flush box and the engine off, turn the EMULSION TANK VALVE to the position marked EMULSION ON.
3	Slowly open the ASPHALT VALVE at the OPERATOR CONTROL PANEL approximately 1/4 open. Solvent will begin to flow from the nozzle for about 10 to 15 seconds, then emulsion will start to flow. When you see the black emulsion start to flow, quickly close the ASPHALT VALVE, as now the solvent will be purged out.



Figure 5.9 Emulsion Tank Valve

5.8 Patching Operation

Table 5-7 Patching Operation

Step	Action
1	Remove the boom from the transport supports and position the nozzle over the area to be repaired. Note: Always open the boom fully from both holders. The hose needs to be as straight as possible for the best performance. It also needs to have a gradual slope as well, so the position of the hanger chains on the boom arms may need to be adjusted as well.
2	Start the engine.
3	Adjust the throttle up to 2000 RPM.
4	Lower the nozzle to about 12" from the ground and blow all dust, dirt and standing water away from the repair area.

Chapter 5 Operating Instructions

Table 5-8 Patching Operation (continued)

Step	Action
5	Reduce the engine RPMs to: <ul style="list-style-type: none"> • Skin Patching - 900 to 1000 RPM • Holes - 1100 to 1200 RPM • Shoulder Repairs 1300 to 1500 RPM Note: With variables in stone, equipment and operator you may find that your unit works better at slightly higher RPM. These settings are our recommended settings for 3/8" stone. Each operator can adjust to their comfort level. We suggest with 1/2" stone increase by 100 RPM and with 1/4" stone decrease slightly.
6	Raise the nozzle to 24" to 30" from the pavement (<i>Knee High</i>) and slowly open the ASPHALT VALVE approximately 1/4 open.
7	Tack coat the repair area with emulsion. See Figure 5.10 Tack Coat . Note: Coating the entire area including 6" past the edge of the repair is best. Highly distressed areas and damp areas require heavier tack application for good long lasting repairs.



Figure 5.10 Tack Coat

Table 5-9 Patching Operation (continued)

Step	Action
8	With the emulsion running, turn on the STONE SWITCH. Stone will immediately start shooting from the nozzle. Note: If stone surges you may need to increase the engine RPM or the stone feed to the auger & tailgate. (Increase the tailgate flow to keep the auger tube inside the hopper covered to prevent air flowing back into the hopper.)
9	Continuously move the nozzle over the repair using the nozzle position handle, building your repair from the bottom up. Note: If you hold the nozzle still, material will build up and you will not achieve a smooth repair.
10	When your stone and emulsion flow are adjusted properly, as the stone builds on the pavement, you should see that less than 10% of the stone looks uncoated. If an excess of emulsion appears, reduce the emulsion flow. If the stone appears undercoated increase the emulsion flow. Note: Emulsion is the glue. To get a long lasting repair, make sure you have enough emulsion.

Chapter 5 Operating Instructions

Table 5-10 Patching Operation (continued)

Step	Action
11	When the repair is at the desired level, close the ASPHALT VALVE. Dry stone will continue to flow from the nozzle. Lightly cover the entire repair with dry stone to complete the repair.
12	Shut off STONE SWITCH. Note: Stone continues to flow for about 10 seconds after the switch is off.
13	Move the nozzle away from the repair area.
14	Lower the engine RPM. Tip: With a push broom, clean up any overspray of material by sweeping it back onto the repair area.
15	Move to the next repair area.
CAUTION	
Never travel without properly stowing boom in the transport supports and locking into position. NEVER place the nozzle in the flush box with the engine running.	



Figure 5.11 Building up the Repair



Figure 5.12 Finishing the Repair

Chapter 5 Operating Instructions

5.9 Shut Down Procedure

5.10 Asphalt Emulsion Line Flush Procedure

The emulsion line should be flushed preferably with a non-flammable citrus based asphalt solvent or diesel fuel, when the time between repairs exceeds 20 minutes, and at the end of every day. If the emulsion line ever becomes clogged do not attempt to unclog by applying any type of open flame to the emulsion line. No open flame should be used to clean any part of the Magnum equipment.

If some asphalt emulsion is spilled on the machine it can be wiped off immediately with diesel fuel or asphalt solvent.

If asphalt emulsion has accumulated on the machine or hoses you should spray them with your asphalt cleaner, let soak approximately 3 minutes and wash off with water or steam. This should be done weekly.

Table 5-11 Asphalt Emulsion Line Flush Procedure

Step	Action
1	Shut down the engine.
2	Stow boom in transport supports and place the nozzle in the FLUSH BOX. See Figure 5.13 Nozzle Flush Box .
3	Turn the FLUSH VALVE to Flush Only.
4	Open the ASPHALT VALVE and allow emulsion to flow into the FLUSH BOX until solvent replaces the emulsion coming out of the nozzle.
5	Shut off ASPHALT VALVE.
6	Turn the FLUSH VALVE to Off.
7	When the Flush Box is 2/3rds full, it should be drained to prevent spilling.




Figure 5.13 Nozzle Flush Box

Chapter 5 Operating Instructions

5.11 Auger Flush Procedure

The aggregate hopper should be cleaned of fines by dropping the trap door on the bottom of the hopper daily. The entire aggregate feed assembly should be rinsed with water for 10 minutes daily with the engine operating at 1,500 RPM and the center screw turning at approximately 35 RPM and the truck auger off. This will thoroughly clean the unit of any fines and assure smooth operation to maintain the Magnum's high output.

Table 5-12 Auger Flush Procedure

Step	Action
1	Set the tailgate auger flow control to closed and the center auger control to 2 turns out.
2	Remove the nozzle from the flush box.
3	Start the engine and set the RPM at 1,500.
4	Turn on the rock switch.
5	Rock will flow from the nozzle. Allow rock to flow until most of the rock is purged from the auger and the hopper, 2 to 3 minutes.
6	Shut off the rock switch.
7	Shut down the engine.
8	Stow the boom and the nozzle and lock in position for transport.
9	Stone can also be purged by opening the gate below the hopper, reversing the auger and feeding the stone back towards the trailer tongue. This method allows you to capture the stone in pails rather than depositing on the roadside. See Figure 5.14 Hopper Gate Handle .
CAUTION	
If you use water to flush out the auger, we highly recommend making sure all of the fines and stones are removed. If the auger isn't completely clean after using water, the left over fines will mix with the water and turn into concrete as it dries. This can lock the auger in place and cause severe damage to the machine.	




Figure 5.14 Hopper Gate Handle

Chapter 5 Operating Instructions

5.12 Reversing Augers Procedure

If the augers ever get jammed (no rock flow and hydraulic pressure is around 1800 PSI+) then you will need to reverse the affected auger to continue operation.

Table 5-13 Reversing Augers Procedure

Step	Action
1	While running, turn off ASPHALT VALVE. See Figure 5.15 Reversing Augers .
2	Turn the STONE SWITCH to "REV" position.
3	While the STONE SWITCH is in "REV" position, hold the corresponding auger switch to the "ON" position. It will only reverse the auger while holding the switch.



Figure 5.15 Reversing Augers

Chapter 5 Operating Instructions

5.13 Boom Height Adjustment Procedure

For proper operation of the operator boom, the nozzle needs to be able to float in a constant position above the ground for best results. There are adjustable spring cylinders that control the tension on the boom. There is adjustment available because over time the springs may start to stretch, as well as different operating conditions might require a different tension. Correct adjustment allows the operator to be able to raise and lower the boom, and it will also hold its height without input from the operator.

Table 5-14 Boom Height Adjustment Procedure

Step	Action
1	Turn the adjustment nuts to the right to increase tension, and to the left to decrease tension. See Figure 5.16 Boom Height Adjustment .
2	Usually, all that is needed is an adjustment to the top cylinder. If not enough tension is available, you can decrease the tension on the upper cylinder, and increase tension on the 2 lower cylinders.
3	In the event that a more extreme adjustment is needed, the upper cylinder can also be adjusted by changing the mounting bolt position on the cylinder. There are 5 positions available.



Figure 5.16 Boom Height Adjustment

Chapter 5 Operating Instructions

5.14 Storing the Machine

Store the machine for longer periods with the emulsion tank empty and the lid sealed. Make sure the emulsion lines have been flushed properly to prevent clogging of the lines and nozzle.

5.15 Overnight Heater

The overnight heater may be used to maintain and heat up the emulsion without the engine running.

Table 5-15 Overnight Heaters

Step	Action
1	Attach the heater power cord to a suitable extension cord and outlet rated for 15 amps.
2	Turn the thermostat dial to the required temperature.
3	Disconnect the heater before moving the machine.
	<p style="text-align: center;">CAUTION</p> <p>Do not use the heater without at least 60 gallons of emulsion in the tank. Doing so will harm the heater and could cause the emulsion to overheat.</p>

Chapter 6 Maintenance Instructions

6.0 Maintenance Instructions

This chapter contains all normal maintenance instructions to properly maintain your machine.

6.1 Engine

Check oil daily. Service engine per the John Deere owner's manual. See engine owner's manual for additional operating and maintenance instructions. This manual is located in the manual storage box.

6.2 Hydraulic System

Check hydraulic fluid daily. Remove and clean hydraulic oil filter in first 30 hours and then every 100 hours. Replace return line filter the first 30 hours then every 100 hours. Change the hydraulic fluid every 500 hours.

6.3 Blower

Refer to the separate manual (Tuthill Blower Manual). The manual is located in the manual storage box.

6.4 Air Compressor

Refer to the separate manual (John Deere Manual). The manual is located in the manual storage box.

6.5 Air Cleaners for Blower and Engine

Replace the filter only when the restriction level has reached the maximum recommended by the engine or equipment manufacturer.

Empty the dust cap. Dust cap should be dumped when 1/3 full. When reinstalling dust cap, be sure it seals 360° around the air cleaner body. Check the vacuator valve to see that it is not inverted, damaged or plugged. If it is damaged, replace it immediately.

6.6 Auger Bearings

Lubricate the bearings at each end of the truck auger tailgate and the bearings on the center auger under the aggregate hopper approximately every 75 hours.

6.7 Boom Bearings

Lubricate bearings every 100 hours for boom. Boom has two bearings, an upper and a lower. Grease lightly.

6.8 Bearing Stub Support Shaft on Engine

Grease the bearing stub support shaft assembly on the back of the bell housing. It is under the belt guard cover.

Chapter 6 Maintenance Instructions

6.9 Wheel Bearing

Pack the wheel bearing every 24,000 miles or every two years, whichever comes first. Use a good grade of bearing grease.

6.10 Brakes

Check the brakes daily.

6.11 Lug Nuts

Torque all nuts/bolts before first road use and after each wheel removal. Check and torque after the first 10 miles, 25 miles, and again at 50 miles. Check periodically thereafter.

Torque in stages as follows:

- First stage 20-25 foot-pound (ft-lb)
- Second stage 50-60 foot pound (ft-lb)
- Third stage 90-120 foot pound (ft-lb)

Tighten bolts and nuts in the sequence shown in [Figure 6.1 Lug Bolt Tightening Sequence](#).




Figure 6.1 Lug Bolt Tightening Sequence

6.12 Tongue Jack

Lubricate the tongue jack, using a good grade of bearing grease.

Chapter 6 Maintenance Instructions

6.13 Maintenance Chart

Table 6-1 Maintenance Chart

Location	Procedure	Hours			
		8	50	100	500
Engine check oil level	Refer to the manufacturer's instructions for the engine	X			
Other engine maintenance	Refer to the manufacture's operating and maintenance instructions for the engine.				
Blower	Oil Check	X			
	Oil Change				X
	Grease Fittings		X		
Hydraulic Oil	Check	X			
	Change				X
Hydraulic Oil Filter	Change			X	
Center Auger Bearings	Grease using a good grade bearing grease.		X		
V-Belt Drive	Check tension. See Table 6-7 V-Belt Tension Specifications .		X		
Stub Support Bearing on Engine	Grease using a good grade bearing grease.		X		
Truck Auger Bearings	Grease using a good grade bearing grease.		X		
Boom Bearings	Grease using a good grade bearing grease.			X	
Wheel Bearings	Clean and re-pack using a good grade of bearing grease.	Every 24,000 miles or two years			
Tongue Jack	Grease using a good grade of bearing grease.	Once a year			
Flush Tank	Drain tank. Use solvent to break up hardened emulsion if needed.	When 2/3rds full or as needed.			

See [Table 6-4 General Maintenance Parts](#) for more info on part numbers.

Chapter 6 Maintenance Instructions

6.14 Service Instructions

Table 6-2 Service Instructions

Step	Action
1	Do a general inspection of the machine at least once a week.
2	Replace all worn or damaged parts. Note: Keep regular replacement items in stock for emergency repairs to prevent costly downtime. See Table 6-5 Recommended Spare Parts .
3	Make necessary adjustments and tighten all loose nuts or screws.
4	Watch for leaks. Tighten fittings or repair as necessary.
5	Clean the external surfaces of the machine at regular intervals. Note: Refer to the material manufacturer's instructions for recommendations.
6	Follow the recommended maintenance per Table 6-1 Maintenance Chart .

For service, find a list of authorized Distributors and service centers at CrafcO.com/Distributors.

6.15 Recommended Fluids and Lubricants

Table 6-3 Recommended Fluids and Lubricants

Application	Recommended	Full Point
Engine Oil	Refer to engine manual	Refer to Manual
Hydraulic Oil	Shell AW Hydraulic 46	Sight Glass
Blower Oil	Refer to blower manual.	8.5 Oz.
Blower Grease	Refer to blower manual	Refer to manual
Bearing Grease	Good grade of heavy duty grease	N/A

Chapter 6 Maintenance Instructions

6.16 General Maintenance Parts

Table 6-4 General Maintenance Parts

Recommended Quantity	Description	Part No.	Page No.
1	Engine Air Filter, Primary Outer	91014	9-25
1	Engine Air Filter, Safety Inner	91013	9-25
1	Air Compressor Air Filter	50109	9-26
1	Blower Air Filter **If built before July 2014, use 91035**	92262	9-15
1	Engine Oil Filter	91044	9-24
1	Hydraulic Filter	43871	9-12
1	Hydraulic Suction Filter (inside tank)	90565	9-12
1	Fuel Filter Mounted on Engine	91016	9-24
1	Optional External Fuel Filter	91872	9-34
3	Blower Drive Belts (3VX300)	91409	9-29
8.5oz	Blower Oil	60335	9-14
1	Engine Serpentine Belt	91043	9-24
1	Auger Assembly	92692	9-39
1	Nylon Wear Spacer for Auger	91265	9-39
1	3" Boxed 45° Elbow	91220	9-5
1	8" Enclosure O-Ring (Emulsion Tank Lid)	90621	9-30
1	Nozzle w/ Spray Ring Attached	91100	9-7
1	3" Nozzle O-Ring	91009	9-7

6.17 Recommended Spare Parts

Table 6-5 Recommended Spare Parts

Recommended Quantity	Description	Part No.
1	8" Enclosure O-Ring (Emulsion Tank Lid)	90621
1	3" Nozzle O-Ring	91009
1	Nozzle w/ Spray Ring Attached	91100
3	Blower Drive Belts (3VX300)	91409
1	Engine Serpentine Belt	91043
1	Nylon Wear Spacer for Auger	91265

Chapter 6 Maintenance Instructions

6.18 Material Specifications

Below are general specifications for the materials used in the Magnum. The materials are very common. This is not a complete list, as a variety of materials can be used and manufacturer trade names vary by locality. Please call if we can assist in any way.

6.19 Stone/Aggregate Specifications

General description: 3/8" or 1/4" preferably washed angular crushed stone. Round river rock is also acceptable, but crushed is preferred.

General Sieve Analysis

100%	1/2 inch
90 - 100%	3/8 inch
20 - 100%	3/16 inch (#4 screen)
5 - 30%	1/8 inch (#8 screen)
0 - 10%	1/16 inch (#16 screen)

6.20 Emulsion Specifications

General description: Rapid setting asphalt emulsion, commonly referred to as RS-2, CRS-2 and sometimes CMS-2. Other trade names are used in some areas. Rapid setting high floats are also acceptable, and are preferable in cold weather (less than 32°F.) operation.

Table 6-6 Emulsion Specifications

Property	Minimum	Maximum
Viscosity, Saybolt Furol @ 122°F. (50°C), s	75	400
Settlement, 5-Day, %		5
Storage Stability, Test, 24-H, %		1
Demulsibility, 35ml, 60	40	
Sieve test, %		0.10
Residue by distillation, %	63	
Penetration, 77°F. (25°C.)	100	
Ductility, 77°F. (25°C.), 5	40	
Solubility in trichloroethylene, %	97.5	

6.21 Wiring Code for Tail Lights and Brakes

- GD (Ground) - Black
- LT (Left Turn) - Red
- RT (Right Turn) - Green
- S (Brakes) - White
- TM (Running Lights) - Brown

Chapter 6 Maintenance Instructions

6.23 Tensioning V-Belt Drive Procedure

General Rules of Tensioning:

- Ideal tension is the lowest tension at which the belt will not slip under peak load conditions.
- Check tension frequently during the first 24 - 48 hours of operation.
- Over tensioning shortens belt and bearing life.
- Keep belts free from foreign material which may cause slip.
- Make V-drive inspection on a periodic basis. Tension when slipping.
- Never apply belt dressing as this will damage the belt and cause early failure.

Specific Rules for Tensioning:

To check for proper belt tightness you must measure the force required to achieve the desired deflection at the center of the belt span, midway between the two pulleys. Below are the minimum and maximum forces permissible to achieve the desired deflection. This should be checked after the first 24 hours, 48 hours and weekly thereafter.

Table 6-7 V-Belt Tension Specifications

Belt	Drive	Desired Deflection	Force to Achieve Deflection - Min	Force to Achieve Deflection - Max
91409	Blower	.156"	7.1 #	10.5 #

Chapter 6 Maintenance Instructions

6.24 Maintenance Guide of the V-Belt Drive

Table 6-8 Maintenance Guide of the V-Belt Drive

Type of Maintenance	Hours	Action
Check for sheave groove wear.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check for belt riding in the groove. In multiple groove drives, belt ride should be uniform, not more than 1/16" above or below top of sheave groove. Check groove wear area for wear. Side wall of groove should be straight, not dished out. Bottom of groove should show no signs of belt contact.
Check for sheave runout.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check sheave by eye for runout. If runout is excessive, it can easily be seen by visual inspection. If runout is noticeable, check sheave for source of problem and correct.
Inspect for heat build-up and proper ventilation.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check belts for heat. Ambient temperatures should not exceed 140°F. Contact temperatures should not exceed 180 °F. Make sure drives are properly ventilated.
Clean belts and sheave grooves.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Inspect belts for contaminates, such as oil or grease. Wipe belts clean with detergent and water. Inspect sheave grooves for buildup of such material and remove, if necessary.
Check belt tension.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check belt tension using Browning belt tension checker. Tension to recommendations shown in current catalogs.
Check sheave alignment.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check alignment with straight edge, string or machinist level. Correct alignment to as near perfect as possible.
Mismatched belt check.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check belt sag on slack side of drive. All belts should have a slight bow. If this bow is not uniform with all belts, replace entire set with a matched set.
Check for worn belts.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check wear surfaces of belt for excessive wear. If belts have a slick, glazed look, belts are slipping. Check drive capacity and belt tension. Never replace only one belt in a used set, as used belts will elongate. Replace entire set if replacement is necessary.
Check sheave setscrews and/or bushing capscrews.	Initial inspection - 8 hours. Second inspection - 24 hours. Third inspection - 100 hours. Periodically thereafter.	Check all setscrews and/or capscrews for looseness. Retighten to recommended torque, if necessary.

Chapter 6 Maintenance Instructions

6.25 Drain Emulsion Tank

In order to drain the Emulsion tank, follow the steps below. If the emulsion has dried out, and won't flow anymore, you will need to add a significant amount of solvent to the tank, and allow it to soak in. Towing the machine around with solvent in the tank can help to break up the emulsion. Once the emulsion is liquid, follow the steps below.

Table 6-9 Drain Emulsion Tank

Step	Action
1	Open tank air pressure valve to release air pressure from the system.
2	Attach a 2" sized drain hose to the drain pipe, or position the drain pipe over a suitable container or tank at your local emulsion recycler.
3	Open valve on the drain pipe, and allow material to flow out.
	Note: The machine may need to be tilted towards the back to help drain as much emulsion as possible.

6.26 Adjusting the Air Pressure Regulator

If your air pressure is going too high or too low, you will need to adjust the air pressure regulator that is mounted on the air compressor, which is mounted on the engine.

Table 6-10 Adjusting Air Pressure Regulator

Step	Action
1	Remove the black plastic dust cap.
2	Loosen the lock nut.
3	To raise the pressure, turn the adjustment screw counter clockwise.
4	To lower the pressure, turn the adjustment screw clockwise.
	Note: Be careful to not over adjust. Each ¼ turn of the adjusting screw raises or lowers the pressure setting approximately 4 PSI.
5	When proper adjustment is obtained, tighten the lock nut, and replace the cover.




Figure 6.2 Air Pressure Regulator

Chapter 6 Maintenance Instructions

6.27 Cleaning Nozzle Spray Ring

If your stone is not being coated properly, you may need to clean the nozzle spray ring.

Table 6-11 Cleaning Nozzle Spray Ring

Step	Action
1	Remove the nozzle from the housing.
2	Place the nozzle into the nozzle storage box. Either soak the nozzle in solvent or clean the nozzle with solvent. Make sure all of the holes are clean.
3	Make sure there isn't built up emulsion inside the housing, or it will need to be cleaned as well.
4	Make sure the o-ring is in place, and return the nozzle into the housing.



Figure 6.3 Nozzle Spray Ring

Chapter 7 How to Use a Multimeter

7.0 How to Use a Multimeter

Crafco machines use 12-volt direct current (DC) to power the burner, hydraulic valves, and trigger on electric wand. The DC power is from a 12-volt battery.

If equipped, the electric hose and wand uses 24-volt 3-phase alternating current (AC). The AC power is from the generator which hangs under the radiator. This system has no reference to ground so there is no possibility of electrical shock unless you are between 2 of the phases. **NOTE: ONLY CHECK AMPERAGE ON A HOSE WITH A CLAMP-ON AMP METER.**

12-volt DC power has little danger of electrical shock. Care must still be taken when dealing with DC power systems because it is capable of producing large amounts of current.

7.1 Checking DC Voltage with a Multimeter

Connect the probes to the meter.

Set the range to a position that includes 12-volts or higher.

Touch the red probe to the positive side of accessory and black probe to ground. If the item you are checking has a ground wire attached then use that ground or you can use a non-painted surface on the frame.

7.2 Checking AC Voltage with Multimeter

Connect the probes to the meter.

Set the range to a position that includes 24-volts or higher.

There are three steps to test the generator voltage. All 3 values should be in the range of 24-30 volts AC.

- Touch red probe to the white wire of the generator and the black probe to the green wire of the generator.
- Next move black probe to black wire.
- Then move red probe to green wire.

7.3 Checking Resistance (Ohms)

Connect the probes to the meter. See [Figure 7.1 Standard Multimeter](#).

Note: When checking Ohms, the circuit cannot be completed. This means one end of the wire will need to be disconnected.

7.3.1 How to Check Wire Continuity

Set the meter to "Audible Continuity". Now touch the probe to each end of the wire in question. The meter will read "0" on the screen and make an audible beep if the wire has continuity from end to end.

7.3.2 How to Check RTD Sensor

Set dial to Ohms Ω . If your meter has different ranges, set to 2k or 2000 ohm range. Touch one probe to each screw or wire of the sensor. The meter will read X.XX if in the 2k range or XXX.X if in the 2000 range.

Chapter 7 How to Use a Multimeter

7.4 Checking Amperage

The Multimeter can be used to check amperages under 10 amps in AC or DC current. When checking the amperage of the electric hose **always use a clamp-on amp meter**. The amperage in the hose can reach as high as 35 amps. Clamp the meter around one wire at a time. Remember most clamp-on meters do not work on DC current.




Figure 7.1 Standard Multimeter

Chapter 7 How to Use a Multimeter




Figure 7.2 Clamp-On Amp Meter/Multimeter

Chapter 8 Troubleshooting

8.0 Troubleshooting

8.1 Emulsion is Not Flowing from the Nozzle

Table 8-1 Emulsion Flow Troubleshooting

Step	Possible Cause	If . . .
1	Start- Is the asphalt valve open on the Operator Control?	<ul style="list-style-type: none"> • Yes, go to Step 2. • No, open the Asphalt Valve and emulsion should start to flow.
2	Is the emulsion line valve set to “Emulsion On” on the back of the emulsion tank?	<ul style="list-style-type: none"> • Yes, go to Step 3. • No, turn the valve to “Emulsion On” position.
3	Is the emulsion at the proper application temperature? Look at the temperature gauge on top of the emulsion tank	<ul style="list-style-type: none"> • Yes, go to Step 4. • No, let the engine run to add heat to the emulsion. Depending on how low it is, you might need to plug in the overnight heater to bring it up to the correct temperature faster.
4	Does the emulsion tank have enough pressure built up? It should be showing at least 90 PSI.	<ul style="list-style-type: none"> • Yes, go to Step 5. • No, let the engine run to build up pressure. If pressure isn’t building up, check to make sure all the pressure relief valves are closed. If all valves are closed, you may need to adjust the air pressure regulator mounted on the engine. See Table 6-10 Adjusting Air Pressure Regulator.
5	Is the emulsion tank empty? Relieve the tank of air pressure, open the lid and check the level.	<ul style="list-style-type: none"> • Yes, fill the tank with the required amount of emulsion. • No, go to Step 6.
6	Is the emulsion in the tank dried up?	<ul style="list-style-type: none"> • Yes, see Table 6-9 Drain Emulsion Tank. • No, go to Step 7
7	Is the nozzle spray ring clogged?	<ul style="list-style-type: none"> • Yes, see Table 6-11 Cleaning Nozzle Spray Ring. • No, go to Step 8.
8	Is the emulsion line clogged?	<ul style="list-style-type: none"> • Yes, start engine to heat up and pressurize the system. Turn the Emulsion Valve to Flush, and wait for system to start flowing. Do not use any heat from an external source. • No, call CrafcO, Inc. and speak to customer service technician.

Chapter 8 Troubleshooting

8.2 Stone Not Flowing Through Hose

Table 8-2 Stone Flow Troubleshooting

Step	Possible Cause	If . . .
1	Is the engine RPM high enough?	<ul style="list-style-type: none"> • Yes, go to Step 2 • No, adjust engine RPM up until stone starts to flow at the rate you want.
2	Are the auger speed controls correctly adjusted?	<ul style="list-style-type: none"> • Yes, go to Step 3 • No, see Table 5-5 Set the Auger Feed for Operation.
3	Did you try reversing both the center auger and the truck auger to clear any jams?	<ul style="list-style-type: none"> • Yes, go to Step 4. • No, see Table 5-13 Reversing Augers Procedure.
4	Is the aggregate hose mostly straight?	<ul style="list-style-type: none"> • Yes, go to Step 5. • No, adjust the position of the boom so the hose has minimal bends. The straighter the hose, the better it will work. Also, you may need to adjust the location of the hanger chains so the slope of the hose is constant.
5	Is the aggregate hose plugged?	<ul style="list-style-type: none"> • Yes, angle the front section of hose and nozzle down and shake the hose. If hose is still plugged, remove the hose from the air flow pipe, angle it down and shake the hose to remove any aggregate that is stuck. Then re-attach to air flow pipe. • No, go to Step 6.
6	Is the nozzle plugged?	<ul style="list-style-type: none"> • Yes, remove the nozzle and clean it out. Make sure the housing and hose above it is clear from obstruction as well. • No, go to Step 7.
7	Is the hopper grate closed and activating the safety switch? Check continuity of switch to make sure it is working properly.	<ul style="list-style-type: none"> • Yes, go to Step 8 • No, make sure the hopper grate is fully closed. Clean off any debris that might be keeping it open and not activating the safety switch.

Chapter 8 Troubleshooting

Table 8-3 Stone Flow Troubleshooting (continued)

8	Is the stone flowing out of the tailgate auger?	<ul style="list-style-type: none"> • Yes, go to Step 9. • No, connect hydraulic hoses to the tailgate. • No, make sure the stone is reaching the tailgate. You may need to increase the angle of the dump bed. If the tail gate auger isn't turning, you may need to reverse the auger to clear a jam. If the auger is not jammed, see Table 8-7 Hydraulic System Troubleshooting.
9	Is the stone free falling from the tailgate chute?	<ul style="list-style-type: none"> • Yes, go to Step 10. • No, raise the dump bed to lower the chute, or remove obstruction as required. Return the bed to the appropriate height so stone cannot sit on the chute. It needs to fall off the chute for correct operation.
10	Is the airlock plugged?	<ul style="list-style-type: none"> • Yes, open the airlock and remove the built up aggregate. Also make sure the tube from the airlock is clear to the hose. • No, go to Step 11.
11	Is the hydraulic pressure gauge reading close to 1800 PSI or greater?	<ul style="list-style-type: none"> • Yes, check the augers in the tailgate. If too much stone is piled on top of the augers, the excess weight may cause the auger to stop turning. If dirty wet stone sits in the augers overnight, it may harden and prevent the augers from turning. Turn off the engine, remove stone from around the augers, and remove any packed stone under the augers. • No, go to Step 12.
12	Are the augers turning?	<ul style="list-style-type: none"> • Yes, call Crafco, Inc. and speak to customer service technician. • No, if the augers are clear, and you are still not getting them to move, See Table 8-7 Hydraulic System Troubleshooting.

Chapter 8 Troubleshooting

8.3 Engine Will Not Start

Table 8-4 Engine Will Not Start Troubleshooting

Step	Possible Cause	If . . .
1	Did you hold the red murphy button while turning the key?	<ul style="list-style-type: none"> • Yes, go to Step 2. • No, See Table 5-3 Pressurize the Emulsion Tank Step 3.
2	Is there diesel fuel in the tank?	<ul style="list-style-type: none"> • Yes, go to Step 3. • No, then fill the fuel up and go to Step 3.
3	Did the engine run out of fuel?	<ul style="list-style-type: none"> • Yes, then prime the fuel line using the fuel system primer. See the John Deere manual for more info. • No, go to Step 4.
4	Does the battery have 12 volts?	<ul style="list-style-type: none"> • Yes, go to Step 5. • No, replace or charge the battery.
5	Have the battery cables been checked?	<ul style="list-style-type: none"> • Yes, call your local John Deere service center, or your Crafco Representative for more information. You can locate your closest John Deere service center by following this link: http://dealerlocator.deere.com/servlet/ • No, check all the cables for loose connections and/or corrosion on the terminals for the battery and starter.

Chapter 8 Troubleshooting

8.4 Emulsion Not Heating from Engine

Table 8-5 Emulsion Not Heating from Engine Troubleshooting

Step	Possible Cause	If . . .
1	Is the engine up to normal operating temperature?	<ul style="list-style-type: none"> • Yes, go to Step 2. • No, let the engine run to get to normal operating temperature.
2	Are the heating line valves on the engine both open?	<ul style="list-style-type: none"> • Yes, go to Step 3. • No, open both the valves and allow the engine coolant to flow and heat up the emulsion system.
3	Is there enough emulsion in the tank to reach the heating core?	<ul style="list-style-type: none"> • Yes, go to Step 4. • No, fill the emulsion tank with the correct amount of emulsion.
4	Are there any kinked or damaged heating lines?	<ul style="list-style-type: none"> • Yes, repair or replace any damaged heating lines. • No, call Crafco, Inc. and speak to customer service.

Chapter 8 Troubleshooting

8.5 Emulsion Not Heating From Overnight Heater

Table 8-6 Emulsion Not Heating From Overnight Heater Troubleshooting

Step	Possible Cause	If . . .
1	Is the emulsion heater plugged in?	<ul style="list-style-type: none"> • Yes, go to Step 2. • No, plug in the heater to a 15 amp outlet.
2	Is the thermostat set to the correct temperature?	<ul style="list-style-type: none"> • Yes, go to Step 3 • No, turn the thermostat to the correct temperature. See Table 5-1 Preparing the Machine for Start Up Step 5.
3	Is the green light illuminated on the heater control?	<ul style="list-style-type: none"> • Yes, go to Step 4 • No, turn up the thermostat until the light illuminates. If the light is not illuminated, then there is no power going to the heater rod.
4	Is the emulsion level above the heating tubes inside the tank?	<ul style="list-style-type: none"> • Yes, go to Step 5. • No, fill tank to a level above the heating tubes.
5	Does the circuit of the building the heater is plugged into have power?	<ul style="list-style-type: none"> • Yes, go to Step 6 • No, reset the circuit breaker connected to that circuit.
6	If everything else checks out, there is a problem with either the thermostat or the heating rods.	<ul style="list-style-type: none"> • Call Crafco, Inc. and speak to customer service for more information.

Chapter 8 Troubleshooting

8.6 Hydraulic System Troubleshooting

Table 8-7 Hydraulic System Troubleshooting

Step	Possible Cause	If . . .
1	Is the stone switch activating the augers?	<ul style="list-style-type: none"> • Yes, then there isn't a problem with the hydraulics. See Table 8-2 Stone Flow Troubleshooting. • No, then go to Step 2
2	Are the flow control valves set correctly?	<ul style="list-style-type: none"> • Yes, go to Step 3. • No, go to Table 5-5 Set the Auger Feed for Operation.
3	Is the hydraulic oil level correct? Check the level using the sight glass on the side of the tank.	<ul style="list-style-type: none"> • Yes, go to Step 4 • No, fill the hydraulic tank with the correct grade of hydraulic fluid up to the sight glass.
4	Is the hydraulic pressure gauge reading around 1800 PSI while the stone switch is on?	<ul style="list-style-type: none"> • Yes, then you have a jammed auger. Try reversing each auger to remove the jam. See Table 5-13 Reversing Augers Procedure. • No, go to Step 5
5	Is the stone switch activating the valves? To check, hold your hand on the solenoid and energize the switch. You should be able to feel the impulse in the valve. You should also be able to see the LED lights on the valve plugs. They should light up when activated. They are dim, so they will be hard to see in direct sunlight.	<ul style="list-style-type: none"> • Yes, then there is a problem with the hydraulic valve. Call CrafcO, Inc. and speak to customer service technician. • No, then go to Step 6
6	Are the wires connected to the switches? Make sure all connections are tight by pulling or wiggling the terminals and wires	<ul style="list-style-type: none"> • Yes, go to Step 7. • No, repair or connect any of the wires, terminals or switch connections. See Figure 8.1 Electrical Schematic for Hydraulic System (PN 92353).
7	Is the switch closing and opening the circuit? Test for continuity on the switch in all positions of the switch.	<ul style="list-style-type: none"> • Yes, go to Step 8. • No, replace the switch.

Chapter 8 Troubleshooting

Table 8-8 Hydraulic System Troubleshooting (continued)

Step	Possible Cause	If . . .
8	If all electrical connections are correct, the hydraulic valves are working, you have enough hydraulic pressure, and the augers still aren't working?	<ul style="list-style-type: none"> • Yes, call Crafc, Inc. and speak to customer service technician.

Chapter 8 Troubleshooting

8.7 Electrical Schematic for Hydraulic System

1. USE ENGINE CONTROL PANEL SUB ASSY-80 HP PART NUMBER 92251.
2. USE #1 TERMINAL ON DIN PLUG FOR POWER "IN".
USE #2 TERMINAL ON DIN PLUG FOR GROUND.
3. SINGLE POLE, SINGLE THROW (MOMENTARY SIDE)
DOUBLE POLE, DOUBLE THROW

(REF. BLACK BOOT COVER 32527)




Figure 8.1 Electrical Schematic for Hydraulic System (PN 92353)

Chapter 8 Troubleshooting

8.8 Hydraulic Valve Plug Layout




Figure 8.2 Hydraulic Valve Plug Layout

Chapter 8 Troubleshooting

8.9 Hydraulic Schematic




Figure 8.3 Hydraulic Schematic (P/N 92352)

Chapter 9 Illustrated Parts List

9.0 About the Illustrated Parts List

The Illustrated Parts List (IPL) is designed to help technical service or maintenance personnel correctly identify orderable replacement parts.

The figure and table titles reference the part number (PN) to which they apply. The PN's for each of the Magnum models are as follows:

Magnum PN 91000

Illustrations and pictures are designed to show general shape and size of a part and the relationship that part has to other parts. Actual size and shape of parts or components may differ or vary from the actual part or component.

9.1 Ordering Crafco Parts

Crafco distributors and Crafco Pavement Preservation Supply Centers are strategically located throughout the United States. Parts can be ordered from your local Crafco distributor or directly from Crafco, Inc. if a distributor is not available in your area.

When ordering parts, give the following information:

- Part Number
- Machine Model
- Serial Number

Write, call, or Fax Crafco, Inc. at the following:

Crafco, Inc. Headquarters
6165 West Detroit Street.
Chandler, AZ 85226
Phone: (602) 276-0406
Toll Free: (800) 528-8242
Fax: (480) 961-0513

Visit our website at www.crafco.com

Chapter 9 Illustrated Parts List

9.2 Magnum Parts List




Figure 9.1 Right Iso View

Chapter 9 Illustrated Parts List

Table 9-1 Right Iso View Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.1	1	20019	1	3" PINTLE HITCH (MAGNUM)
	2	91132	2	HOPPER LID HOLD DOWN STRAP
	3	91186	1	AGGREGATE HOPPER INLET LID ASSY
	4	91030	1	ENGINE COVER (JD 4045T)
	5	90547	4	3" ROUND AMBER REFLECTOR
	6	32314	4	YELLOW CLEARANCE MARKER, LARGE
	7	90200	1	BATTERY LOCK BOX ASSY
	8	44342	4	TIRE W/ BLACK RIM ST225/75 R15
	9	23130	24	LUG NUT
	10	92607	2	6000LB TORSION AXLE W/ ELEC BRAKES
	11	92350	1	HYDRAULIC CONTROL VALVE ASSY
	12	91235	1	RUBBER CONNECTION HOSE BLOWER
	13	92261	1	AIR CLEANER HOUSING (2014 AND UP MODELS)
	14	90860	1	30 GAL FLUSH TANK ASSY
	15	92671	1	FUEL TANK ASSY
	16	91158-13	1	3" AGGREGATE HOSE, BLUE, 13FT
	17	90181	3	HANGER HOSE CHAIN BOOM
	18	90325	1	COVERED BOOM/HEAT HOSE ASSY
	19	90149	3	4" AGGREGATE HOSE HANGER
	20	41243	1	24" TEMP GAUGE. BOTTOM MOUNT
	21	42629	1	SAFETY VALVE
	22	29961	1	200PSI PRESSURE GAUGE (FILLED)
	23	29214	1	BRONZE BALL VALVE, 1/2"
	24	91095	1	READY TO MOUNT THERMOSTAT ASSY
	25	91830	1	EMULSION HEIGHT GAUGE DIPSTICK
	26	90790	1	EMULSION TANK HEAT SHIELD ASSY
	27	91799	1	EMULSION TANK HEATER
	28	23082	1	5000LB TONGUE JACK, 15"

Chapter 9 Illustrated Parts List




Figure 9.2 Left Iso View

Chapter 9 Illustrated Parts List

Table 9-2 Left Iso View Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.2	1	91299	1	SQUARE RED REFLECTOR
	2	91200	1	FLUSH OUT BOX
	3	90640	1	250GAL EMULSION TANK, INS. COMPLETE
	4	90547	4	3" ROUND AMBER REFLECTOR
	5	32314	4	YELLOW CLEARANCE MARKER, LARGE
	6	92634	1	EMULSION D.S. SAFETY STEP
	7	91645	1	BACK UP ALARM, HEAVY DUTY
	8	91133	1	HOPPER SAFETY SWITCH
	9	90235	1	DIPSTICK HEIGHT GAUGE HOLDER
	10	92605	1	MAGNUM FRAME
	11	92657	1	HYDRAULIC TANK ASSY COMPLETE
	12	90395	1	ARRWBRD CNTRL PRTCN. BOX (OPTIONAL)
	13	92682	1	TAILLIGHT BACK BOARD
	14	90624	1	ARRWBRD AND CNTRL ASSY (OPTIONAL)
	15	91396	1	HANDLE ASSY
	16	90606	1	PULL CLAMP, 700#
	17	91220	1	3" BOXED 45° ELBOW
	18	91103	1	3" ALUMINUM NOZZLE HOUSING
	19	92315	1	REAR EMULSION FLUSH TROUGH

Chapter 9 Illustrated Parts List




Figure 9.3 Nozzle Exploded View




Figure 9.4 Rear View

Chapter 9 Illustrated Parts List

Table 9-3 Rear View Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.4	1	32318	4	SECURITY RING
	2	32317	4	FLANGE MOUNT STT RED 4" RD LED LIGHT
	3	32315	2	RED SIDE MARKER LIGHT
	4	32316	2	ARMORED BRACKET
	5	91846	1	CONTROL BOX ENCLOSURE ASSY
	6	32319	1	CENTER RED LIGHT
	7	92318	1	BRACKET, SINGLE CENTER TAILLIGHT
	8	91530	1	DEEP NOZZLE STORAGE BOX
	9	91073	1	3" PIPE WELDED ASSY
	10	91162	1	NOZZLE POSITION HANDLE
	11	90549	2	3" REFLEX REFLECTOR, RED
	12	91100	1	3" NOZZLE W/ SPRAY RING
	13	91009	1	3" O-RING
	14	91103	1	3" ALUMINUM NOZZLE HOUSING
	15	91356	1	INSERT, NOZZLE
	16	91344	1	NIPPLE HOSE COMBO, KING
	17	25952	6	3.5" U BOLT CLAMP
	18	91155	1	3" HOSE X 24" LONG GUM RUBBER LINED
	19	92693	1	EMULSION TANK INSULATION BOX
	20	25951	1	3" U BOLT CLAMP
	21	26099	1	LICENSE PLATE HOLDER
	22	44797	1	LED LICENSE PLATE LAMP
	23	32371	1	RED 6" CENTER LIGHT KIT
	24	43897	1	3/16" CHAIN, 1 LINK
	25	91648	1	BOOM STAY SAFETY CHAIN
	26	91312	1	AGGREGATE BOOM CLAMP ASSEMBLY

Chapter 9 Illustrated Parts List

9.3 Nozzle Emulsion Line Connection Parts List




Figure 9.5 Nozzle Emulsion Line Connection

Chapter 9 Illustrated Parts List

Table 9-4 Nozzle Emulsion Line Connection Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.5	1	91207	1	EMULSION LINE COVER 110" (PART OF 90325)
	1	90325	1	COVERED BOOM/HEATED HOSE ASSY
	2	90307	1	EMULSION COVER "U" SHAPE WATER LINES
	3	29619	28 FT	RED ½" EMULSION LINE HOSE
	4	29618	28 FT	BLUE ½" WATER LINE HOSE
	5	29618	33 FT	BLUE ½" WATER LINE HOSE
	6	26764	1	#8 HSE-6MPT PUSH-ON HOSE BARB
	7	27787	1	3/8 90DEG FEM SWIVEL/MALE PIPE
	8	90301	1	EMULSION WATER RETURN BOTTOM U

Chapter 9 Illustrated Parts List

9.4 Operator Boom Parts List




Figure 9.6 Operator Boom Parts

Chapter 9 Illustrated Parts List

Table 9-5 Operator Boom Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.6	1	91396	1	HANDLE ASSY
	2	91648	1	BOM STOW SAFETY CHAIN ASSY
	3	91545	1	BOOM SECTION 2 ND COMPLETE
	4	91299	2	SQUARE RED REFLECTOR
	5	90549	2	3" REFLEX REFLECTOR, RED
	6	90149	3	4" AGGREGATE HOSE HANGER
	7	90577	6	LARGE TAPER BEARING RACE OUTER
	8	91722	3	HEX CASTLE NUT
	9	90576	6	LARGE TAPER BEARING INNER
	10	90661	3	3" ID BEARING ASSY COVER
	11	91320	1	BEARING RACE WELD BUSHING PIVOT ARM
	12	91360	1	SPRING CYLINDER LH ASSY
	13	91365	1	UPPER SPRING CYLINDER ASSY
	NA	91357	1	SPRING CYLINDER RH ASSY
	14	91246	1	BOOM STOWING SNAP HOOK
	15	91535	1	1 ST BOOM SECTION
	16	90181	3	HANGER HOSE CHAIN BOOM
	17	91310	1	BOOM MOUNTING SECTION, FRAME MAG
	18	91230	1	CONTROL CONSOLE COMPLETE ASSY
	19	91700	1	EMULSION REGULATION VALVE ASSY
	20	91162	1	NOZZLE POSITION HANDLE
	21	29270	1	2" BRONZE GATE VALVE
	22	91073	1	3" PIPE WELD ASSY
	23	91220	1	3" BOXED 45° ELBOW
	24	90628	1	EMULSION TANK REAR VALVE ASSY
	25	29214	1	BRONZE BALL VALVE, 1/2"
	26	90569	1	VALVE POSITION INDICATOR PLATE
	27	91808	1	3 WAY BRASS VALVE
28	91046	1	THROTTLE CABLE	
28A	91021K	1	OPTIONAL ELECTRIC THROTTLE CONTROL	

Chapter 9 Illustrated Parts List

9.5 Hydraulic and Fuel Tank Parts List




Figure 9.7 Hydraulic and Fuel Tanks
Table 9-6 Hydraulic and Fuel Tank Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.7	1	90813	1	HYD. TANK TOP ACCESS PANEL
	2	90812	1	TOP ACCESS PANEL GASKET
	3	92657	1	HYDRAULIC TANK ASSY COMPLETE
	4	90564	1	2" ROUND HYD LEVEL SIGHT GAUGE
	5	51300	1	3/4" TUBE X 1"NPT ELBOW ADPTR
	6	43872	1	HYD OIL FILTER ASSY
	6A	43871	1	HYDRAULIC FILTER ELEMENT
	7	29921	1	45 DEGREE ADAPTER
	8	28039	1	1" X 4" PIPE NIPPLE
	9	29213	1	1/2" BRASS GATE VALVE
	10	90565	1	HYDRAULIC SUCTION FILTER
	11	29971	2	1/4 NPT M 90X1/4 M HOSE BARB
	12	43579	2	PRESSURE FILLER BREATHER CAP
	13	92671	1	FUEL TANK ASSY COMPLETE
14	92664	1	FUEL LEVEL GAUGE 15"	

Chapter 9 Illustrated Parts List

9.6 Dual Hydraulic Control Valve Parts List




Figure 9.8 Dual Hydraulic Control Valve

Table 9-7 Dual Hydraulic Control Valve Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.8	1	92350	1	HYDRAULIC CONTROL VALVE ASSY
	2	45376	5	DIN PLUG
	3	92631	1	HYD. CONTROL VALVE MOUNTING PLATE

Chapter 9 Illustrated Parts List

9.7 Air Blower Parts List




Figure 9.9 Air Blower

Table 9-8 Air Blower Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.9	1	91235	1	RUBBER CONNECTION HOSE TO BLOWER
	2	91843	2	6" WORM DRIVE HOSE CLAMP
	3	91306	1	MAGNUM BELT GUARD ENG/BLOWER
	4	60151	1	ROTARY AIR BLOWER
	5	90827	4	BLOWER MOUNTING TAB
	6	91330	1	BLOWER SLIDE PLATE
	7	90858	2	3/8"-16 X 4" ALL THREAD BOLT
	8	28010	1	3" CLOSE NIPPLE
	9	28364	1	4" X 3" REDUCER BUSHING
	10	90520	1	6" X 5" BLOWER AIR CLEANER ADAPTER

Chapter 9 Illustrated Parts List

9.8 Blower Air Cleaner Parts List




Figure 9.10 Blower Air Cleaner

Table 9-9 Blower Air Cleaner Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.10	1	91795	1	AIR FILTER RESTRICTION INDICATOR
	2	91843	2	6" WORM DRIVE HOSE CLAMP
	3	91235	1	RUBBER CONNECTION HOSE TO BLOWER
	4	91727	1	VACTUATOR VALVE – AIR CLEANER
	5	91708	2	AIR CLEANER MOUNTING RING CLAMP
	6	92261	1	AIR CLEANER HOUSING COMPLETE
	7	92262	1	AIR CLEANER AIR FILTER ELEMENT ***UNITS BUILT BEFORE JULY 2014, USE ELEMENT 91035***
	8	91031	1	INLET HOOD – LRG BLOWER AIR CLEANER
	9	25289	1	MODEL 550 RECORD BOX

Chapter 9 Illustrated Parts List

9.9 Hydraulic Auger Motor Parts List




Figure 9.11 Hydraulic Auger Motor

Table 9-10 Hydraulic Auger Motor Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.11	1	91127	1	FACE PLATE, MOTOR MOUNT
	2	91122	1	HYDRAULIC MOTOR
	3	28763	1	½"-13 X 1 ¾" BOLT
	4	91106	1	HYD MOTOR KEEPING BRACKET

Chapter 9 Illustrated Parts List

9.10 Aggregate Feed System Air Lock Parts List





Figure 9.12 Aggregate Feed System Air Lock

Table 9-11 Aggregate Feed System Air Lock Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.12	1	91158-13	1	3" AGGREGATE HOSE, BLUE, 13FT.
	2	91855	1	HOSE CLAMP 3" TIGER
	3	90554	2	PIN PLUG – 3" FEMALE LUG COUPLER
	4	91559	2	PIN PLUG GASKET
	5	91165	1	6" AIR LOCK, COMPLETE ASSY
	6	91057	1	AIR LOCK GASKET
	7	90606	3	PULL CLAMP 700 #
	8	28200	1	3" 45 DEGREE THREADED ELBOW
	9	28010	1	3" CLOSE NIPPLE
	10	25952	1	3 ½" U BOLT CLAMP
	11	91338	1	3" WILDCAT HOSE X 28" LONG

Chapter 9 Illustrated Parts List

9.11 Emulsion Tank Drain Valve Parts List



VIEW FROM GROUND
LOOKING UP

Figure 9.13 Emulsion Tank Drain Valve

Table 9-12 Emulsion Tank Drain Valve Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.13	1	28060	1	2" NIPPLE, 5" LONG
	2	28198	1	2" - 45° ELBOW IRON PIPE
	3	28008	1	2" CLOSE NIPPLE
	4	29270	1	2" BRONZE GATE VALVE
	5	28136	1	2" NIPPLE, 9" LONG

Chapter 9 Illustrated Parts List

9.12 Hitch Area Parts List




Figure 9.14 Hitch Area

Table 9-13 Hitch Area Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.14	1	23082	1	5000LB TONGUE JACK, 15"
	2	20019	1	3" PINTLE HITCH, MAGNUM
	3	91850	1	2 1/2" PINTLE HITCH, MAGNUM (OPTIONAL)
	4	24074	1	6 WIRE TRAILER CONNECTOR
	5	23117	1	BREAKAWAY SWITCH UNIT
	6	20130	2	48"X 3/8" CHAIN (STD)
	7	91781	2	3/8" SAFETY CHAIN HOOK
	8	43528	2	DOUBLE CLEVIS LINK

Chapter 9 Illustrated Parts List

9.13 Solvent Flush Tank Parts List




Figure 9.15 Solvent Flush Tank

Table 9-14 Solvent Flush Tank Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.15	1	28238	2	1/2" STREET ELBOW
	2	26765	2	#8 HOSE - 8 MPT PUSHON
	3	90702	1	SUCTION TUBE ASSY, FLUSH TANK
	4	90703	1	2" PIPE PLUG W/ PRESSURE RELIEF HOLE
	5	29281	1	2" BALL VALVE
	6	28008	1	CLOSE NIPPLE, 2"
	7	90860	1	30 GAL FLUSH TANK COMPLETE ASSY
	8	91815	1	1/4" DRAIN PETCOCK
	9	28253	2	1/2" PIPE TEE
	10	28003	3	1/2" CLOSE NIPPLE
	11	90861	1	1/2" #60 CHECK VALVE

Chapter 9 Illustrated Parts List

9.14 Battery Parts List



Figure 9.16 Battery

Table 9-15 Battery Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.16	1	24001	1	1000 C.C.A. BATTERY
	2	90200	1	BATTERY LOCK BOX ASSEMBLY
	3	90215	1	BATTERY HOLD DOWN FRAME
	4	90904	1	POS BATTERY CABLE 69" LONG ASSY
	5	32602	1	NEG 20" CRESCENT BATTERY CABLE

Chapter 9 Illustrated Parts List

9.15 Emulsion Tank Top Valve Assembly Parts List




Figure 9.17 Emulsion Tank Top Valve Assembly

Table 9-16 Emulsion Tank Top Valve Assembly Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.17	1	28262	1	1/4" BLK PIPE CROSS
	2	28281	1	1/4" PIPE PLUG
	3	42629	1	SAFETY VALVE
	4	28344	2	1/2" X 1/4" BUSHING
	5	41243	1	24" TEMP GAUGE BOTTOM. MOUNT
	6	28175	1	1/2" PIPE COUPLING
	7	26765	2	#8 HOSE - 8 NPT PUSH ON FITTING
	8	28223	2	1/2" 45° STREET ELBOW
	9	90861	1	1/2" CHECK VALVE
	10	28003	4	1/2" CLOSE NIPPLE
	11	28253	3	1/2" PIPE TEE
	12	28070	1	1/2" X 6" NIPPLE
	13	29214	1	1/2" BRONZE BALL VALVE
	14	91135	1	1/4" PIPE PIG TAIL
	15	90896	1	AIR BRAKE FITTING, 90°
	16	28340	1	1/4" X 1/8" HEX HEAD PIPE BUSHING
	17	29961	1	200 PSI PRESSURE GAGE, FILLED

Chapter 9 Illustrated Parts List

9.16 Boom Control Console Parts List



Figure 9.18 Boom Control Console

Table 9-17 Boom Control Console Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.18	1	32521	3	TOGGLE SWITCH – SPDT MOMENTARY
	2	32522	1	TOGGLE SWITCH – DPDT/ON-OFF-ON
	3	91046	1	MANUAL THROTTLE CONTROL (STANDARD)
	4	32524	1	ELECTRIC THROTTLE SWITCH (OPTIONAL)
	5	91700	1	EMULSION REGULATION VALVE ASSY
	6	91230	1	CONTROL PANEL PLATE
	7	90299	1	DECAL, OPERATORS CONTROL PANEL
	8	32527	4	TOGGLE SWITCH BOOT

Chapter 9 Illustrated Parts List

9.17 Engine and Engine Components Parts List




Figure 9.19 Engine and Engine Components

Table 9-18 Engine and Engine Components Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.19	1	41403	1	½" STAINLESS STEEL LINE
	2	91043	1	ENGINE SERPENTINE BELT
	3	90530	1	WATER PUMP OUTLET VALVE ASSY
	4	90895	1	AIR COMPRESSOR CHECK VALVE ASSY
	5	91022	1	13 CFM AIR COMPRESSOR
	6	91044	1	OIL FILTER, ENGINE
	7	90529	1	RETURN WATER HEATING VALVE ASSY
	8	90800	1	HYDRAULIC PUMP
	9	90794	1	HYDRAULIC PUMP FITTING ASSY
	10	91016	1	ENGINE MOUNTED FUEL FILTER
	11	92270	1	ENGINE ASSY W/ COMPRESSOR & COVER

Chapter 9 Illustrated Parts List

9.18 Engine Intake and Exhaust Parts List




Figure 9.20 Engine Intake and Exhaust

Table 9-19 Engine Intake and Exhaust Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.20	1	91795	1	AIR FILTER RESTRICTION INDICATOR
	2	91014	1	ENGINE AIR FILTER ELEMENT, PRIMARY
	2	91013	1	ENGINE AIR FILTER ELEMENT, SAFETY
	3	91048	1	EXHAUST SYSTEM
	4	91727	1	VACTUATOR VALVE – AIR FILTER HOUSING
	5	91043	1	ENGINE SERPENTINE BELT
	-	26491	1	JOHN DEERE SERVICE MANUAL W/ CD

Chapter 9 Illustrated Parts List

9.19 Engine Air Compressor Parts List




Figure 9.21 Engine Air Compressor

Table 9-20 Engine Air Compressor Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.21	1	50109	1	AIR COMPRESSOR FILTER
	2	28238	1	1/2" STREET ELBOW
	3	29844	1	ADAPTER - JIC MP 8MJ-8MP
	4	41403	1	1/2" STAINLESS STEEL LINE
	5	90890	1	INTAKE AIR COMPRESSOR FILTER BRACKET
	6	90891	1	INTAKE AIR COMPRESSOR HOSE
	7	90899K	1	GOVERNOR - COMPRESSOR UNLOADING
	8	91022	1	13 CFM AIR COMPRESSOR
	9	90800	1	HYDRAULIC PUMP

Chapter 9 Illustrated Parts List

9.20 Engine Control Panel Parts List



Figure 9.22 Engine Control Panel

Table 9-21 Engine Control Panel Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.22	1	91869	1	OIL PRESSURE SWITCH GAUGE
	2	91822	1	AMP METER GAUGE
	3	91764	1	TEMPERATURE SWITCH GAUGE
	4	90537	1	IGNITION KEY SWITCH
	5	91854	1	TACHOMETER W/ HOUR METER
	6	91758	1	RED MURPHY SWITCH
	7	91177	1	FUSE HOLDER
	8	91837	1	COOLANT PRESSURE SWITCH GAUGE
	9	91780	1	HOUR METER
	10	90453	1	2" 0-3000 HYDRAULIC PRESSURE GAUGE
	11	91846	1	ENCLOSURE ASSEMBLY
	12	51694	1	CIRCUIT BREAKER 5 AMPS
	13	51695	1	CIRCUIT BREAKER 30 AMPS

Chapter 9 Illustrated Parts List

9.21 Belt Drive Parts List




Figure 9.23 Belt Drive

Chapter 9 Illustrated Parts List

Table 9-22 Belt Drive Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.23	1	91335	1	BEARING SUPPORT STUB SHAFT ASSY
	2	60151	1	ROTARY AIR BLOWER (NOT SHOWN)
	3	91330	1	BLOWER SLIDE PLATE, MAGNUM
	4	91326	1	ENGINE SHAFT KEY 3/8" X 3/8" X 2-1/2"
	5	91308	1	SDS 1-1/2" BUSHING W/ 3/8" KEYWAY
	6	91409	3	ENGINE TO BLOWER BELT (3VX300)
	7	92304	1	3/3 V 6.0" QD-SDS SHEAVE
	8	60335	8.5oz	OIL, ROTARY AIR BLOWER (NOT SHOWN)
	9	27953	8	3/8"-16 X 1" GR8 HEX HEAD BOLT
	10	28641	20	3/8" FLAT HARDENED WASHER
	11	28658	20	3/8" LOCK WASHER GRADE 8
	12	27955	12	3/8"-16 X 1-1/4" GR8 HEX HEAD BOLT
	13	28528	8	1/2"-13 ESNA LOCK NUT
	14	28659	8	1/2" LOCK WASHER GRADE 8
	15	29026	8	1/2"-13 X 1-1/2" GRADE 8 BOLT
	16	90858	2	3/8"-16 X 4" FULL THRD BOLT (NOT SHOWN)
	17	28526	2	3/8"-16 ESNA LOCK NUT (NOT SHOWN)
	18	27986	2	3/8" FLAT WASHER GRADE 8 (NOT SHOWN)
	19	27964	2	3/8"-16 GRADE 8 NUT (NOT SHOWN)
	20	90827	8	BLOWER MOUNTING TAB
	21	91065	1	BLOWER KEY, 1/4"
	22	92306	1	7/8" SH BUSHING
	23	92302	1	3/3V 3.65" QD-SH SHEAVE
	24			1

Chapter 9 Illustrated Parts List

9.22 Emulsion Tank Gauge Parts List




Figure 9.24 Emulsion Tank Gauge

Table 9-23 Emulsion Tank Gauge Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.24	1	91830	1	EMULSION TANK GAUGE DIPSTICK
	2	90621	1	8" O-RING (FOR EMULSION TANK LID)

Chapter 9 Illustrated Parts List

9.23 Crack Sealing Attachment Option Parts List



Figure 9.25 Crack Sealing Attachment

Table 9-24 Crack Sealing Attachment Option Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.25	1	91530	1	DEEP NOZZLE STORAGE BOX
	2	90780	1	CRACK FILLING ATTMTNT ASSY (OPTIONAL)
	3	90782	1	TACK WAND ASSY
	4	90772	1	TACK WAND GRIP HANDLE ASSY
	5	91825	1	QUICK COUPLER ¼" NPT X 1/4" FML AIR
	6	90777	1	TACK WAND SUPPLY HOSE STOW REEL
	7	90771	1	TACK WAND SUPPLY HOSE, 25FT

Chapter 9 Illustrated Parts List

9.24 Electric Throttle Option Parts List




Figure 9.26 Electric Throttle Option

Table 9-25 Electric Throttle Option Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.26	1	91021K	1	ELECTRIC REMOTE CONTROL ACTUATOR
	2	90212	1	REMOTE CONTROL ACTR SWCH CVR BOX
	3	32527	1	TOGGLE SWITCH BOOT
	4	32524	1	ELECTRIC THROTTLE SWITCH

Chapter 9 Illustrated Parts List

9.25 8 Foot Quick Flush Hose Option Parts List



Figure 9.27 8 Foot Quick Flush Hose Option

Table 9-26 8 Foot Quick Flush Hose Option Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.27	1	90225	1	8 FOOT QUICK FLUSH HOSE OPTION

Chapter 9 Illustrated Parts List

9.26 External Water/Fuel Separator Option Parts List



Figure 9.28 External Water/Fuel Separator Option

Table 9-27 External Water/Fuel Separator Option Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.28	1	90420	1	WATER/FUEL SEPARATOR OPTIONAL
	2	91872	1	FILTER REPLACEMENT ELEMENT

Chapter 9 Illustrated Parts List

9.27 Hitch Extension Option Parts List




Figure 9.29 Hitch Extension Option

Table 9-28 Hitch Extension Option Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig.9.29	1	90887	1	24" HITCH EXTENSION ASSY, 15" OFFSET

Chapter 9 Illustrated Parts List

9.28 Air Discharge System Parts List




Figure 9.30 Air Discharge System

Chapter 9 Illustrated Parts List

Table 9-29 Air Discharge System Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.30	1	91344	1	3" NIPPLE/HOSE COMBO KING
	2	91339	1	3" WILDCAT HOSE X 8-1/2" LONG
	3	90554	4	PIN PLUG / 3" FEMALE COUPLER
	4	28010	5	3" CLOSE NIPPLE
	5	91668	1	3" x 2" x 3" BLACK MI TEE-DRILLED
	6	28008	1	2" CLOSE NIPPLE
	7	91661	1	BLOWER PRESSURE RELIEF VALVE 10 PSI
	8	92691	1	CHAMBER ABSORPTION SILENCER
	9	91708	2	MOUNTING RING CLAMP
	10	28259	1	3" x 2" x 3" BLACK MI TEE
	11	28200	2	3" 45 DEG. THREADED ELBOW
	12	91338	1	3" WILDCAT HOSE X 28" LG
	13	28288	1	PIPE PLUG 2"
	14	91165	1	6" AIR LOCK COMPLETE
	15	25952	4	3-1/2" U-BOLT MUFFLER CLAMP
	16	60151	1	ROTARY AIR BLOWER
	17	28364	1	4" X 3" REDUCING BUSHING
	18	91332	1	4" SCH 40 FEMALE PVC ADAPTER- DRILLED
	19	90754	1	ELBOW OIL HOLE COVER

Chapter 9 Illustrated Parts List

9.29 Aggregate Screw Feed Assembly Parts List




Figure 9.31 Aggregate Screw Feed Assembly

Chapter 9 Illustrated Parts List

Table 9-30 Aggregate Screw Feed Assembly Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.31	1	92638	1	6" MAGNUM AGGREGATE SCREW FEED PIPE
	2	92692	1	AUGER ASSEMBLY
	3	91057	1	AIR LOCK GASKET
	4	91106	1	HYDRAULIC MOTOR KEEPING BRACKET
	5	91127	1	FACE PLATE
	6	91130	1	AGGREGATE HOPPER
	7	91165	1	6" AIR LOCK COMPLETE
	8	91131	1	1 1/4" HOPPER BEARING
	9	91122	1	HYDRAULIC MOTOR
	10	91265	1	ANTI-FRICTION NYLON WASHER
	11	28762	2	1/2" X 1-1/2" HEX HEAD BOLT
	12	27953	4	3/8" X 1" GR8 HEX HEAD BOLT
	13	28634	8	3/8" FLAT WASHER
	14	28526	12	3/8"-16 ESNA LOCK NUT
	15	28733	4	3/8"-16 X 1-1/2" HEX HEAD BOLT
	16	28732	4	3/8"-16 X 1-1/4" HEX HEAD BOLT
	17	28764	3	1/2"-13 X 2" HEX HEAD BOLT
	18	28528	2	1/2"-13 ESNA LOCK NUT
	19	28674	4	1/2" FLAT WASHER
	20	28504	1	1/2"-13 HEX NUT STEEL
	21	91192	1	AUGER IDLER SHAFT, 6"
	22	92633	1	DRIVE SHAFT ASSEMBLY

Chapter 9 Illustrated Parts List

Table 9-31 Hydraulic Tailgate Assembly Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.32	1	90752	1	ROCK CHUTE COVER
	2	90650	1	SHORT ROCK CHUTE
	3	91196	1	TRUCK AUGER TAILGATE ASSY
	4,5,7	90610	1	TAILGATE AUGER COMPLETE
	4,5,7	90380	1	TAILGATE AUGER COMPLETE - HARDFACED
	4	90613	1	CENTER AUGER SHAFT @ PADDLES
	5	90614	1	LONG SCREW AUGER
	5	90382	1	LONG SCREW AUGER - HARDFACED
	6	90578	2	TRUCK AUGER BEARING, 2 BOLT FLANGE
	7	90611	1	SHORT SCREW AUGER
	7	90381	1	SHORT SCREW AUGER - HARDFACED
	8	90399	1	TAILGATE COVER ASSY
	9	28672	2	3/8" FLAT WASHER
	10	28502	2	3/8"-16 NC HEX NUT
	11	28734	2	3/8"-16 X 1 3/4" HEX HEAD BOLT
	12	90288	2	DECAL,WARNING NO OPRTN W/O GUARDS
	13	29607	2	8M3K 8G-8MP 8G-8MP 12-9 HOSE
14	41102	1	HYDRAULIC MOTOR	
15	91428	1	TAILGATE HYD BRACKET ASSY	
16	90601	1	SPIDER INSERT	
17	90602	2	1/2" HYDRAULIC MOTOR COUPLER	

Chapter 9 Illustrated Parts List

Table 9-32 Hydraulic Parts List

FIG	ITEM	PART NO.	DESCRIPTION	QTY
Fig.9.33	1. HYDRAULIC VALVE "A2" TO TAILGATE MOTOR			
	1	8M3K 8G-8FJX90S 8G-8MP 192 188.5	192" HYD HOSE	1
	9	29897	1/2" TUBE CONNECTOR	1
	2. HYDRAULIC TANK TO HYDRAULIC PUMP SUCTION			
	2	16GH4 16G-16FJX 16G-16FJX 47-43	47" SUCTION HOSE	1
	3. HYDRAULIC PUMP TO HYDRAULIC VALVE "P"			
	3	12M3K 12G-12FJX 12G-12FJX 72-68.5	72" HYD HOSE	1
	8	29916	O-RING ADAPTER 12MB-12MJ 90°	1
	4. HYDRAULIC VALVE TO HYDRAULIC TANK			
	8	29916	O-RING ADAPTER 12MB-12MJ 90°	1
	4	12M3K 12G-12FJX 12G-12FJX90S 42-37.5	42" HYD HOSE	1
	5. HYDRAULIC VALVE "A1" TO CENTER MOTOR			
	9	29897	1/2" TUBE CONNECTOR	1
	5	8M3K 8G-8FJX 8G-8FJX90S 68-64.5	68" HYD HOSE	1
	6. CENTER MOTOR TO HYDRAULIC VALVE "B1"			
	9	29897	1/2" TUBE CONNECTOR	1
	6	8M3K 8G-8FJX 8G-8FJX90S 69-65.5	68" HYD HOSE	1
	7. HYDRAULIC VALVE "B2" TO TAILGATE MOTOR			
	9	29897	1/2" TUBE CONNECTOR	1
	7	8M3K 8G-8FJX90S 8G-8MP 192-188.5	192" HYD HOSE	1

Chapter 9 Illustrated Parts List

9.32 Emulsion Supply Line Parts List




Figure 9.34 Emulsion Supply Line Parts List (P/N 91264)

Table 9-33 Emulsion Supply Line Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.34	1	90640	1	250 GAL. EMULSION TANK COMPLETE
	2	90628	1	EMULSION TANK REAR VALVE
	3	29619	1	HOSE, 1/2" HOLD-TITE RED
	4	26764	1	#8 HOSE 6MPT PUSH ON HOSE BARB
	5	27787	1	3/8" 90DEG FEM SWIVEL/MALE PIPE FITTING
	6	91103	1	3" ALUMINUM NOZZLE HOUSING
	7	91100	1	3" NOZZLE W/SPRAY RING ATTACHED

Chapter 9 Illustrated Parts List

9.33 Solvent Flush Line Parts List




Figure 9.35 Solvent Flush Line Parts List

Table 9-34 Solvent Flush Line Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 9.35	1	90640	1	250 GAL. EMULSION TANK COMPLETE
	2	90628	1	EMULSION TANK REAR VALVE
	3	29619	1	HOSE, ½" HOLD-TITE RED
	4	90702	1	SUCTION TUBE, FLUSH TANK
	5	90860	1	30 GAL. SOLVENT FLUSH TANK ASSY
	6	90703	1	2" PIPE PLUG W/ RELIEF
	7	29281	1	2" BALL VALVE

Chapter 9 Illustrated Parts List

9.34 Air Supply Line Schematic




Figure 9.36 Air Supply Line Schematic (P/N 91266)

Chapter 9 Illustrated Parts List

9.35 Wiring Schematic

1. USE ENGINE CONTROL PANEL SUB ASSY-80 HP PART NUMBER 92251.
2. USE #1 TERMINAL ON DIN PLUG FOR POWER "IN".
USE #2 TERMINAL ON DIN PLUG FOR GROUND.
3. SINGLE POLE, SINGLE THROW (MOMENTARY SIDE)
DOUBLE POLE, DOUBLE THROW

(REF. BLACK BOOT COVER 32527)




Figure 9.37 Wiring Schematic (P/N 92353)

Chapter 9 Illustrated Parts List

9.36 Control Panel Wiring Schematic




Figure 9.38 Control Panel Wiring Schematic (P/N 9251)

Chapter 10 Hydraulic Tailgate Mounting

10.3 Assembled View of Tailgate and Custom Mounts




Figure 10.2 Assembled View of Tailgate and Custom Mounts

Chapter 10 Hydraulic Tailgate Mounting

10.4 Mounted Hydraulic Tailgate



Figure 10.3 Mounted Tailgate

Table 10-1 Mounted Tailgate Parts List

FIG.	ITEM	PART NUMBER	QTY	DESCRIPTION
Fig. 10.3	1	-	2	CUSTOM BRACKET SUPPLIED BY CUSTOMER
	2	-	2	CUSTOM BRACKET SUPPLIED BY CUSTOMER
	3	91196K	1	PURCHASED CRAFCO TAILGATE



©2016 Crafco, Inc.