



BAX 600

**PART MANUAL - 26369
REV. A**

Original: 05/04

BAX 600




TABLE OF CONTENTS

BAX 600.....	5
Safety Precautions.....	6
Limited Warranty.....	7
Warranty Claim Instructions.....	8
Specifications.....	9
Introduction.....	10

Operating Instructions

Machine Start Up/Starting the Engine.....	11
Heated Hose, Wand, and Controller.....	11
Starting the Mixer.....	12
Dispensing the Material.....	12
Loading the Machine.....	13
Shutdown and Clean-out Procedure/Storing Machine.....	13
Instructions for Ordering Parts.....	14
Electric Hose Care and Cautions.....	14
Hose Transport Instructions.....	15

Maintenance

Maintenance Instructions and Chart.....	16
Temperature Control Calibration.....	16
Service Instructions/Recommended Fluids and Lubricants.....	17

Trouble Shooting

Hose Trouble Shooting - Hose Does Not Heat.....	18-19
Hose Trouble Shooting - Material Does Not Dispense When Pump is Activated..	19-20
Hose Trouble Shooting - Material Dispenses Once Then Stops.....	20
Electrical Schematic.....	21
Burner Trouble Shooting.....	22
Burner Schematic.....	23

Parts

Bax 600 Assembly - Diagram and Parts.....	24-27
Tank Assembly - Diagram and Parts.....	28-29
Pump/Agitator Motor Assembly - Diagram and Parts.....	30-31
Power Pack Assembly - Diagram and Parts.....	32-33
Control Box Assembly - Diagram and Parts.....	34-35
Gas Manifold Assembly - Diagram and Parts.....	36-37
Hydraulic Valve Assembly - Diagram and Parts.....	38-39
Hydraulics Schematic and Parts.....	40-41
LPG Piping Diagram and Parts.....	42-43
Electrical Schematic and Parts.....	44-45

BAX 600

This manual is furnished with each new **CRAFCO BAX 600**. This manual will help your machine operators learn to run the melter applicator properly and understand its mechanical functions for trouble-free operation.

Your **CRAFCO BAX 600** is designed to give excellent service and save maintenance expense. However, as with all specially engineered equipment, you can get best results at minimum costs if:

1. You operate your machine as instructed in this manual.
2. Maintain your machine regularly as stated in this manual.



WARNING: The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Operate in well ventilated area only. Engine exhaust is deadly.



SAFETY PRECAUTIONS

- High operating temperatures of sealant and machine require protective clothing, hard soled shoes and heat resistant gloves be worn by operator.

- Always wear eye protection.



- Observe all **CAUTION AND WARNING** signs posted on machine.



- Avoid the entrance of water into any part of the machine.

- Avoid bodily contact with hot sealant material, serious burns may result.

- Read Operator Manual thoroughly before operating machine.


- Make sure operator is familiar with machine operation.

- Do not operate in closed building or confined areas.

- Shut-down burner and engine prior to refilling propane tank.

- When adding solid material to sealant tank, stop mixer, lift lid, place material onto lid and close lid before restarting mixer. Hot material could splash and cause serious burns if this procedure is not followed.

- Keep hands, feet, and clothing away from all moving parts.



- Always keep a fire extinguisher near the unit. Maintain extinguisher properly and be familiar with its use.

- Follow operating instructions for starting and shut-down of burner. Instructions are mounted on control box.

- Calibrate temperature control prior to initial operation and each 50 hours of operation. See page 16 step by step instruction.

- Replace any hoses which show signs of wear, fraying, or splitting. Be sure all fittings and joints are tight and leak-proof.

- Precaution is the best insurance against accidents.

- The BAX 600 Melter should not be left unattended with burner lit.



- Tighten all bolts and screws after every 100 hours of operation.

- CrafcO, Inc. assumes no liability for an accident or injury incurred through improper use of the machine.

LIMITED WARRANTY

Crafco, Inc., through its authorized distributor, will replace for the original purchaser free of charge any parts found upon examination by the factory at Mesa, Arizona, to be defective in material or workmanship. This warranty is for a period within 60 days of purchase date, but excludes engine or components, tires, and battery as these items are subject to warranties issued by their manufacturers.

After 60 days, Crafco, Inc., warrants structural parts, excluding heating system, hydraulic components, material pump and hoses, applicator valves, and electrical components for a period of (1) one year from date of delivery. Crafco, Inc., shall not be liable for parts that have been damaged by accident, alteration, abuse, improper lubrication/maintenance, normal wear, or other cause beyond our control.

The warranty provided herein extends only to the repair and/or replacement of those components on the equipment covered above and does not cover **labor** costs. The warranty does not extend to incidental or consequential damages incurred as a result of any defect covered by this warranty.

All transportation and labor costs incurred by the purchaser in submitting or repairing covered components must be bore by the purchaser.

Crafco, Inc. specifically disavows any other representation, warranty, or liability related to the condition or use of the product.



WARNING: Use of replacement parts other than genuine Crafco parts may impair the safety or reliability of your equipment and nullifies any warranty.

WARRANTY CLAIM INSTRUCTIONS

Please follow the instructions stated below when calling in a Warranty Claim. Failure to follow these procedures may be cause to void the warranty.

1. Call your local CrafcO Distributor. If you do not know who your local distributor is, call a CrafcO Customer Service Representative, (Toll Free 1-800-528-8242) for name, location, and telephone number.
2. On contacting the distributor, be prepared to identify the machine type, model number, and serial number, also, the date of purchase if available.
3. Should the cause of the malfunction be a defective part, the distributor will advise you of the procedure to follow for a replacement.
4. The warranty is valid only for parts, which have been supplied or recommended by CrafcO, Inc.

If you have any additional questions regarding warranty repairs and parts, please do not hesitate to call toll free 1-800-528-8242.

CRAFCO, INCORPORATED
235 SOUTH HIBBERT DRIVE
MESA, AZ. 85210
480-655-8333
Toll Free 1-800-528-8242

SPECIFICATIONS

Vat Capacity.....	60 Gallons
Melt Capacity.....	35 Gallons/Hour
Tank Construction.....	Direct Fired Type Construction
Tank Opening Size.....	12" X 15"
Maximum Heat Input.....	Vapor Burner 180,000 BTU's
Burner and Temperature Control.....	Automatic - Fail Safe
Engine - Kohler.....	Single Cylinder
Model CH-14 - Propane Fueled	14 BHP @ 3,600 rpm
Drive Mechanism.....	All Hydraulic Mixer and Material Pump
Mixer.....	High Speed Two Pitched Blade Agitator
Dry Weight.....	Approximately 1,400 lbs.
Propane Bottle (1).....	100 lbs.
Generator.....	2,000 Watt - 12 Volt
Hydraulic Tank Capacity.....	12 Gallons

MOUNTING THE BAX 600 MELTER

1. Only mount the unit to a metal truckbed or any other non-flammable surface.
2. Mount unit 3" above the truckbed. Mount with four(4) 1/2" bolts minimum.
3. Leave 15" clear all around the machine.

BAX 600 MELTER

INTRODUCTION

The CRAFCO BAX 600 MELTER was developed to melt CRAFCO Brand Sealant. However, it will work equally well with all road asphalt and federal specification crack or joint sealant.

DO NOT operate machine without following these instructions:

1. Fill propane tank.
2. Check engine crankcase oil level (refer to Engine Operator's Manual).
3. Check hydraulic fluid level, at ambient temperature. Add fluid if necessary to bring to correct level.
4. All toggle switches should be turned "**OFF**" and both temperature control dials at minimum settings.
5. Remember that safe operation of this equipment is the operator's responsibility.



CAUTION:

Extreme care must be used when operating this equipment. Safety is the result of being careful and paying attention to details. Remember the diesel flame is about 2,200° F. Certain exposed parts of this machine, when operating reach 500° F.; the sealant as high as 400° F. and the hydraulic fluid may reach 200° F. Always wear protective clothing, hard-soled shoes, and eye protection. Be sure that all joints and fittings are tight and leak proof. Immediately replace any hose, which shows any signs of wear, fraying, or splitting. Tighten all bolts, nuts, and screws every 250 hours.

MACHINE START UP

TO START BURNER

1. Do not travel with propane burner ignited per Federal Regulation 49CFR392.67.
2. Open LPG tank valve.
3. Open ball valve at cylinder.
4. Start engine per instruction below.
5. Turn “**ON**” burner toggle switch at control box. Follow directions on control box.



CAUTION:

If burner does not ignite the first time, turn temperature dial to off. Turn temperature dial to desired setting. Burner should ignite. If burner still does not ignite, determine cause of malfunction (see Burner Trouble Shooting Guide pg. 22).

STARTING THE ENGINE

Choke engine, turn the ignition key to start position. Engine should start. After engine starts, allow to warm up before using hydraulics or generator.

HEATED HOSE, WAND, AND CONTROLLER



CAUTION:



The hose must be up to temperature before dispensing can take place. **IMPORTANT!! DO NOT** twist or kink hose. Avoid sharp bends and continuous twisting. Maintain minimum 10” bend radius. **DO NOT** exceed 400 degrees!! **DO NOT** move or bend hose when cold. Damage may result.

The heated hose supplied with the machine is Teflon lined with a stainless steel overbraid. It has a heating element which runs down the hose to heat the material within the hose. The hose is insulated with silicone foam rubber and is covered with a durable rubber outer covering. The wand has an aluminum tube to protect both the wand and the operator. The pistol grip actuator is equipped with an electric switch which when depressed sends a signal to actuate the pump. At the end of the wand, a high temperature elasomeric output valve is attached. The valve is pressure actuated and opens automatically when fluid pressure is applied. The wand is equipped with a trigger lock to prevent accidental pump actuation when not pumping material. The trigger should be in the “**LOCKED**” position at all times except when intentionally pumping material.

Turn the hose toggle switch to the “**ON**” position. Adjust the temperature dial to approximately 400 degrees. The hose will come up to temperature in approximately 30 minutes. After the hose has reached its preset temperature, the light in the control box will turn off and the temperature may be reduced to approximately 360 degrees. It is advisable to run the hose at the lowest temperature setting possible. (Continued...)

IT IS STRONGLY RECOMMENDED THAT THE HOSE BE STORED IN THE HOSE HANGER WHEN NOT IN USE OR WHEN IN TRANSIT. THIS WILL HELP PREVENT TWISTING OR KINKING.

STARTING THE MIXER

When the sealant material reaches a liquid state, engage the mixer by moving the toggle switch to "ON" (switch located on hydraulic panel.) If the mixer does not move, allow material to heat longer. Jamming of mixer shaft causes hydraulic oil to overheat and machine damage could occur. Remember, mixer does not start with melter lid open. The mixer speed is preset for optimum performance for the factory.



DISPENSING THE MATERIAL



NOTE: PROTECTIVE CLOTHING, GLOVES, HARD-SOLED SHOES, AND FACE SHIELD OR SAFETY GLASSES SHOULD BE WORN WHEN OPERATING OR FILLING THIS EQUIPMENT. READ ENTIRE MANUAL BEFORE OPERATING.

The wand is equipped with a disposable duckbill valve on the end, which shuts off the flow of material when the pump is turned off and prevents excessive dripping of material. This valve also directs the material into a stream for easy application onto the pavement. Other sealing tips are available. See your local distributor for options.

Although the wand is designed to heat the material all the way down to the tip, on cold days it may be necessary to place the tip of the wand under the lid to facilitate material melting in the valve. Insert the wand tip for only a short time before proceeding.

When the material and the hose have reached proper application temperature, you are ready to dispense material. Install bottom reed switch and cylinder should return to top. With the wand tip inserted into the tank, depress trigger on the wand. Material should start to flow from the tip of the duckbill valve. Adjust the stroke of the cylinder by moving the bottom reed switch up or down for the desired rate of flow for the application and dispense material as required.



NEVER POINT THE WAND AT ANY PART OF THE BODY OR AT ANY OTHER PERSON. HOT MATERIALS CAN CAUSE SEVERE BURNS. WEAR PROTECTIVE EQUIPMENT WHEN FILLING OR OPERATING THE EQUIPMENT. READ MANUAL BEFORE OPERATING EQUIPMENT.



LOADING THE MACHINE

When loading solid material into the sealant tank, the mixer will stop when the lid is lifted.

To load, lift the lid, place the material on the lid and close lid. Following this procedure will prevent the hot material from splashing and causing serious burns to personnel.

The solid material must be added at intervals, which will allow the mixer to rotate without jamming. If blocks of material are fed in too quickly, jamming will result and slow down the melting process.

SHUTDOWN AND CLEAN-OUT PROCEDURE

When shutting down the machine for the day, Crafc0 recommends leaving the material level at or below agitator paddles. This will give a fairly rapid heat up rate in the morning, but will allow enough material to start dispensing right away when the material becomes molten.

1. Place a box or metal bucket under valve. Open ball valve at hose connection.
2. Remove bottom reed switch and extend cylinder by activating the pump. Close the ball valve. **CAUTION:** Hot material may splatter and cause injury to personnel.
3. Turn material temperature down to 200° and allow material temperature to drop 100° while agitator is running.
4. Turn power toggle switch to "OFF".
5. Store the hose in safe area on truck or trailer bed. **IMPORTANT!! DO NOT** kink or twist hose, as permanent damage will result.
6. Turn the mixer toggle switch to the "**OFF**" position.
7. Turn the engine "**OFF**" at the engine key switch.
8. Turn LPG "**OFF**" at ball valve and valve at LPG bottle.

STORING MACHINE

The BAX 600 should be stored in an area where moisture cannot enter machine heating system, such as controls, etc. Extended down time can cause moisture build up.

INSTRUCTIONS FOR ORDERING PARTS

Parts may be ordered from your local CRAFCO distributor or directly from CRAFCO, Inc. if a distributor is not available in your area. When ordering parts, give the following information:

1. Part Number.
2. Machine Model.
3. Serial Number.

Write, telephone, or fax:

CRAFCO, INCORPORATED
235 SOUTH HIBBERT DRIVE
MESA, AZ. 85210
Phone: 480-655-8333
Fax: 480-655-1712
Toll Free: 1-800-528-8242



ELECTRIC HOSE CARE AND CAUTIONS



Twisting and kinking of the electric hose (used on LF, BAX, SS60, and SS125 Melter) is the number one cause of hose failure.

When this happens, the electric heating wires are shorted out to the metal hose cover and the hose stops heating.

This type of failure is not covered under the CrafcO warranty.

To help prevent twisting and kinking and the resulting hose damage, the operator should:

- a. Not move or use hose unless it has been turned on a least 35 minutes and set at a minimum temperature of 300° F.
- b. Make sure hose swivel between hose and wand moves freely.
- c. Limit the hose bending to a radius of 10 inches.
- d. Avoid bending the hose over sharp edges such as the edge of the frame or tank.
- e. Avoid twisting.
- f. Do not exceed 400° F. on the hose controller or material temperature.
- g. Follow all instructions of the melter as well as those in the instruction manual.
- h. Avoid pulling hose beyond its limits.

HOSE TRANSPORT INSTRUCTIONS

1. Rotate hose boom toward hose hanger.
2. Wrap hose on hose hanger two complete wraps (Approximately 20 inch diameter).
3. Store wand in shoe box and locking support bracket.

CAUTION:



Hose damage will occur if:

- a. Hose is bent or moved when cold.
- b. Hose is twisted or bent at less than a 10 inch radius.
- c. Hose is moved prior to being turned on at least 35 minutes and set at 380° F.
- d. Operator crosses over or under hose causing hose to twist or wires between hose and wand connection to twist or wrap up.
- e. Swivel is cold and not free to move allowing hose to twist.
- f. Hose to wand wiring is pulled, stressed, or used to support the wand.

MAINTENANCE INSTRUCTIONS AND CHART

ENGINE

Check oil every 8 hours of operation. Change after the first 5 hours of operation and change every 50 hours thereafter.

See engine owners manual for additional operating and maintenance instructions.

HYDRAULIC SYSTEM

Check hydraulic fluid every 8 hours. Change hydraulic filter every 250 hours. Change hydraulic fluid every 500 hours of operation.

LOCATION	PROCEDURE	HOURS			
		8	50	250	500
Engine check oil level	See engine instruction manual.	*			
Other engine maintenance	See engine operating and maintenance instructions.				
Battery	Check water level weekly.		*		
Hydraulic oil filter	Change oil filter.			*	
Hydraulic oil	Check oil.	*			
Hydraulic oil	Change oil.				*
Hydraulic oil	For proper oil, see recommended fluids & lubricants.				
Belt tension	Tighten to 1/2" slack on tension side of belt			*	
Wire check	Check for cuts or breaks		*		
Hose inspection hydraulic and electric hose	Check for cuts and abrasions		*		

TEMPERATURE CONTROL CALIBRATION

Check control knob calibration weekly. Calibrate by aligning the line on the control knob with the calibration line on the scale plate (see Fig. 1).




Fig. 1


SERVICE INSTRUCTIONS

1. Conduct a general inspection of your machine at least once a week. Replace all worn or damaged parts, make any necessary adjustments and tighten all loose nuts or screws.
2. Keep regular replacement items in stock for emergency repairs, to avoid costly “down” time.
3. Watch for leaks. Tighten fitting or repair as necessary.
4. Clean machine externally periodically. Check with sealant manufacturer for recommendation.
5. Follow recommended maintenance procedures on maintenance chart.


RECOMMENDED FLUIDS AND LUBRICANTS

APPLICATION	RECOMMENDED	FULL POINT
Engine oil	Refer to Kohler owners manual.	4 Pts.
LPG	Propane	100 Lbs.
Hydraulic oil	Rondo Oil - HD - 68 Texaco	12 Gals.

HOSE TROUBLE SHOOTING



KETTLE END



WAND END

HOSE DOES NOT HEAT

Step 1: Is the “HEATED HOSE” switch “ON”?

YES: Go to step 2

NO: Turn switch “ON”.

Step 2: Is “HEATED HOSE” light illuminated?

YES: Go to step 3

NO: Check for tripped circuit breaker in front panel.

YES: Reset circuit breaker.

NO: Remove front panel and check for 12 volts at purple wire on hose switch.

YES: Go to step 2a.

NO: Check for 12 volts at circuit breaker in front panel.

Step 2a: Check for 12 volts at #3 terminal (purple wire) on Pak-Stat.

YES: Go to step 2b.

NO: Check wire connections or replace switch.

Step 2b: Check for 12 volts at #7 terminal (blue wire) when Pak-Stat is on.

YES: Go to step 3

NO: Replace Pak-Stat.

YES: Check wire connections (red wire) between circuit breaker and switch

NO: Check wire connections between “ACC” terminal on ignition switch and “A” terminal on plug #2.

Step 3: Check for 12 volts at “BATT” terminal on generator.

YES: Go to step 4

NO: Check wire connections between (blue wire) in control box to “BATT” terminal on generator.

HOSE TROUBLE SHOOTING

Step 4: Check for 24 volts AC at the “BLACK”, “WHITE” and “GREEN” wires on the generator.

YES: Go to step 5.

NO: Replace generator.

Step 5: Check for 1.08K (1080) OHMS resistance of the hose sensor (black and white wire) at the junction box. (**NOTE: One of the sensor wires must be disconnected to check resistance**).

MATERIAL DOES NOT DISPENSE WHEN PUMP IS ACTIVATED

Step 1: Is the pump cylinder extending?

YES: Go to step 2.

NO: Has the sealant had sufficient time to completely melt.

YES: Go to step 2.

NO: Allow material to heat longer.

Step 2: Has the hose had sufficient time to reach operating temperature?

YES: Go to step 3.

NO: Allow hose to heat longer.

Step 3: Is the light illuminated on the top reed switch?

YES: Go to step 4.

NO: Is pump light illuminated on control panel?

YES: Go to step 4.

NO: Replace bottom reed switch onto cylinder or move up/down until light on bottom reed switch illuminates and cylinder returns to top and light illuminates on top reed switch.

Step 4: Check for 12 VDC at red wire in junction box.

YES: Go to step 5.

NO: Check for 12 VDC at terminal #4 (red wire) of relay

YES: Go to step 5.

NO: Replace relay p/n 51675.

Step 5: Is the top left light on the hydraulic valve illuminated when trigger is activated?

YES: Replace coil p/n 43853.

NO: Disconnect wand and check continuity between “C” and “B” on wand when trigger is activated.

YES: Check for poor wire connections from hose to terminal #4 of relay.

NO: Replace switch or check for poor wire connection.

Step 6: Check for 12VDC at terminal #14 of relay.

YES: Replace reed switch p/n 55106.

NO: Check for poor wire connections between red-blk wire of terminal block and terminal #14 of relay.

HOSE TROUBLE SHOOTING

Step 7: Check for 12 VDC at terminal #8 of relay.

YES: Cylinder has not returned to the top.

NO: Go back to step 3.

MATERIAL DISPENSES ONCE THEN STOPS


Step 1: Did the top left light of hydraulic valve stay illuminated?

YES: Check for 12 VDC at relay terminal #12 of relay.


YES: Replace relay p/n 51675.

NO: Move bottom reed switch until light illuminates and cylinder returns to top and light illuminates on top reed switch.

NO: Then everything should be working.



ELECTRICAL SCHEMATIC



BURNER TROUBLE SHOOTING

BURNER WILL NOT IGNITE

- Step 1:** Check for 12 volts at toggle switch.
No: Then toggle switch is "OFF"
Fuse is "Blown"
Broken wire
Yes: Then go to Step 2



- Step 2:** Check for 12 volts at terminal #7 on material temperature thermostat.
No: Then material temperature thermostat is bad
Yes: Then go to Step 3

- Step 3:** Check for 12 volts at power terminal of spark control module.
No: Then there is a bad connection or a broken wire
Yes: Then there is a Faulty spark control module
Faulty ignitor or ignitor wire
Reposition ignitor
Check for clogged burner orifice
Inadequate gas flow/or pressure
Faulty "ASCO" gas valve

BURNER LIGHTS BUT SHUTS DOWN IN 3.5 SECONDS

- Faulty ignitor
- Broken or loose flame sensor wire
- Faulty spark control module


BURNER LIGHTS BUT WILL NOT RELIGHT

- Calibrate thermostat
- Blown fuse
- Faulty spark control module
- Faulty sensor


BURNER WILL NOT SHUT OFF @ TEMPERATURE SETTING

- Calibrate thermostat
- Dirt in "ASCO" valve
- Faulty sensors

BURNER SCHEMATIC




BAX 600 ASSEMBLY



BAX 600 ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
1	25289	1	RECORD BOX
2	25290	1	RECORD BOX BRACKET
3	26221	1	SAFETY MANUAL
4	26369	1	BAX 600 MANUAL
5	43688	3	1-1/2" GROMMENT
6	44027	1	JUNCTION BOX
7	50074	4	SPACER
8	24002	1	BATTERY BOX
9	24000	1	BATTERY
10	25118	1	LPG STORAGE BOTTLE
11	25073	1	LP SPUD ASSY.
12	26032	1	1/2"-13 BLACK KNOB
13	43450	2	STACK GUARD
14	39607	1	ON/OFF PLATE
15	50719	1	TOGGLE SWITCH
16	50720	1	WATER TIGHT SWITCH BOOT
17	43465	1	RTD SENSOR
18	51065	1	CORD GRIP
19	39608	1	SWITCH
20	39609	1	DUST CAP
21	28569	1	5/8-24 EX-FINE THRD. NUT
22	55350	1	CONTROL BOX ASSY. (SEE PG. 34)
23	43430	1	GAS MANIFOLD (SEE PG. 36)
24	44030	1	HYDRAULIC TANK
25	55117	1	T-HANDLE SCREW


BAX 600 ASSEMBLY



BAX 600 ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
26	22071	1	HYD. FILTER ELEMENT
27	55355	1	HYDRAULIC CONTROL VALVE (SEE PG. 38)
28	50570	1	HEATED HOSE ASSY.-10 FT.
29	51055	1	24" WAND - 12V
30	43768	1	HANDLE ASSY.
31	55335	1	POWER PACK ASSY. (SEE PG. 32)
32	41636	4	ISO MOUNT
33	26059	OPT.	FIRE EXTING BRACKET
34	26058	OPT.	FIRE EXTING W/COVER
35	43672	OPT.	STROBE LIGHT MTG. BRKT.
36	24095K	OPT.	STROBE LIGHT KIT
37	43416	OPT.	GRAVITY FEED KIT (NOT SHOWN)
38	43411	OPT.	WAND TIP ADAPTER KIT (NOT SHOWN)
39	55106	2	REED SWITCH, N.O.
40	44827	1	HYDRAULIC PUMP
41	44828	1	COUPLING HALF, 3/4 BORE
42	55357	1	HEAT GUARD

TANK ASSEMBLY




SECTION THRU TANK

TANK ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
1	43123	1	BURNER ASSEMBLY
2	43153	1	IGNITOR
3	55311	1	PUMP PLATE
4	55316	1	PUMP PISTON
5	55320	2	MIXER PADDLE ASSEMBLY
6	50012	1	FLANGED BEARING
7	55321	1	PUMP PLUNGER ROD
8	55333	2	CHAIN GUARD
9	55328	1	PUMP/AGITATOR MOTOR ASSY. (SEE PG. 30)
10	43322	1	SPROCKET, DRIVEN
11	43321	1	CHAIN, DRIVE
12	55315	1	AGITATOR SHAFT ASSEMBLY
13	28060	1	2 X 5 NIPPLE
14	28273	1	2" PIPE CAP
15	55034	1	1/2" SWIVEL
16	28239	1	3/4" ELBOW
17	28351	1	1" x 3/4" REDUCER BUSHING
18	55326	1	PADDLE RING


PUMP/AGITATOR MOTOR ASSEMBLY



PUMP/AGITATOR MOTOR ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
1	55327	1	CYLINDER MOUNT BRIDGE
2	22029	2	ADAPTOR
3	22027	1	HYDRAULIC MOTOR
4	29834	2	JIC ADAPTER STR 6MJ-6MP
5	55329	1	AIR CYLINDER-NON-LUBE
6	28720	1	5/16 -18 NC. X 2" LG. BOLT
7	28681	1	5/16 FENDER WASHER
8	28646	1	5/16 LOCK WASHER
9	43323	1	SPROCKET


POWER PACK ASSEMBLY



POWER PACK ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
1	55339	1	MOUNTING BASE - ENGINE
2	43480	1	ENGINE, 14 HP
3	44806	1	HYD. PUMP ADAPTOR
4	43612	1	GENERATOR, 24 VAC
5	43887	3	TERMINAL BOOT
6	55340	1	PULLEY, DRIVE
7	55337	1	BELT GUARD - INNER
8	55338	1	BELT GUARD - OUTER
9	55341	1	DRIVE SHAFT, FRONT
10	50066	1	BUSHING, TAPERLOCK - 1"B
11	29871	1	3/8 J X 1/4 NPT ELBOW
12	44829	1	1" BORE COUPLING
13	27017	1	SHAFT KEY
14	44830	1	SPIDER, COUPLING
15	43557	1	BELT, AX-39
16	28619	1	5/16-18 WING NUT
17	29834	1	3/8 NPT X 3/8 J ADAPTOR
18	SEE DESC.	1	AX6-6MP-6FJ9-8 HOSE
19	28267	1	3/8 PIPE CAP
20	55358	1	ALTERNATOR BRACKET REAR SUPPORT


CONTROL BOX ASSEMBLY



CONTROL BOX ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
1	51676	2	RELAY SOCKET
2	51675	2	RELAY, LATCHING
3	51662	2	SPRING, RELAY
4	50517	2	6 PIN RECEPTACLE
5	50344	3	GASKET
6	50215	1	5 PIN RECEPTACLE
7	51665	1	15 AMP CIRCUIT BREAKER
8	50280	1	1/2" CONDUIT NUT
9	51064	1	1/2" CORD CONNECTOR
10	50719	2	TOGGLE SWITCH
11	43397	2	TEMP. CONTROLLER
12	50238	1	JUMPER
13	50250	2	TERMINAL STRIP
14	50559	1	WIRING HARNESS
15	50251	2	LCD READOUT W/CABLE (P1 TO 1)
16	25278	1	SPARK CONTROL MODULE
17	51651	2	PILOT LIGHT
18	50593	2	KNOB, TEMPERATURE CONTROL (NOT SHOWN)
19	24024	1	CORD CONNECTOR
20	25404	1	DECAL, CONTROL BOX (NOT SHOWN)


GAS MANIFOLD ASSEMBLY



GAS MANIFOLD ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
1	29839	2	1/4 NPT X 3/8 JIC ADAPTOR
2	25208	1	1/4 STRAINER
3	51401	2	1/4 HEX PIPE NIPPLE
4	29980	1	1/4 STREET TEE
5	25236	1	SOLENOID VALVE
6	28236	1	1/4 STREET ELBOW
7	25087	1	FISHER REGULATOR
8	43441	1	3/8 JIC TEST PORT ELBOW
9	28825	4	8-32 X 3/8 THR. CUT SCREW
10	43761	1	MANIFOLD MOUNTING PLATE


HYDRAULIC VALVE ASSEMBLY



HYDRAULIC VALVE ASSEMBLY

NUMBER	PART NUMBER	QTY.	DESCRIPTION
1	55325	1	HYDRAULIC VALVE ASSEMBLY
2	43853	3	COIL-CONTROL VALVE
3	29998	3	STRAIGHT O-RING ADAPTER
4	29897	3	STRAIGHT O-RING ADAPTER
5	44810	1	CARTRIDGE - PUMP
6	44834	1	CARTRIDGE - MIXER
7	44812	2	RELIEF VALVE
8	44833	1	FLOW CONTROL


HYDRAULICS SCHEMATIC



HYDRAULICS SCHEMATIC

1. HYDRAULIC RESERVOIR TO HYDRAULIC PUMP (SUCTION)		
1	29819	3/4 JIC TUBE X 3/4 O-RING STR. ADAPTER
1	C12-12FJ-26	HYDRAULIC HOSE ASSEMBLY, 3/4 X 26"
1	29819	3/4 JIC TUBE X 3/4 O-RING STR. ADAPTER
2. HYDRAULIC PUMP "PRESS" PORT TO HYD. VALVE "P" PORT		
1	29812	5/8 JIC TUBE X 5/8 O-RING STR. ADAPTER
1	AX8-6FJ9-10FJ-45	HYD. HOSE ASSEMBLY, 1/2 X 45"
1	29998	3/8 JIC TUBE X 1/2 O-RING STR ADAPTER
3. HYDRAULIC VALVE (RETURN PORT) TO MIXER MOTOR (FRONT)		
1	29897	1/2 JIC TUBE X 1/2 O-RING ADAPTER
1	AX6-8FJ9-6FJ9-14	HYDRAULIC HOSE ASSEMBLY 3/8 X 14"
1	22029	3/8 TUBE X 5/8 O-RING ADAPTER
4. HYDRAULIC VALVE "T" PORT TO HYDRAULIC FILTER (RETURN)		
1	29876	3/8 TUBE X 1/2 NPT ELBOW
1	AX6-6FJ-6FJ9-26	HYDRAULIC HOSE ASSEMBLY 3/8 X 26"
1	29998	3/8 JIC TUBE X 1/2 O-RING ADAPTER
5. HYDRAULIC VALVE ("PUMP A" PORT) TO HYDRAULIC CYLINDER		
1	29897	1/2 JIC TUBE X 1/2 O-RING STR. ADAPTER
1	AX6-8FJ9-6FJ9L-22	HYDRAULIC HOSE ASSEMBLY 3/8 X 22"
1	29834	3/8 JIC TUBE X 3/8 PIPE STR. ADAPTER
6. HYDRAULIC CYLINDER TO HYDRAULIC VALVE ("PUMP B" PORT)		
1	29834	3/8 JIC TUBE X 3/8 PIPE STR. ADAPTER
1	AX6-6FJ9-6FJ9L-18	HYDRAULIC HOSE ASSEMBLY 3/8 X 18"
1	29998	3/8 JIC TUBE X 1/2 O-RING STR. ADAPTER
7. MIXER MOTOR (REAR PORT) TO HYDRAULIC VALVE (OUT PORT)		
1	22029	3/8 TUBE X 5/8 O-RING ADAPTER
1	AX6-6FJ9-6FJ9L-16	HYD. HOSE ASSEMBLY, 3/8 X 16"
1	29998	3/8 JIC TUBE X 1/2 O-RING ADAPTER


LPG PIPING DIAGRAM



LPG PIPING DIAGRAM

1. L.P.G. TANK TO MANIFOLD		
1	25073	SPUD AND REGULATOR ASSEMBLY CONTAINS:
1	25123	TANK SPUD
1	25066	REGULATOR
1	28001	1/4 CLOSE
1	29195	1/4 BALL VALVE
1	29857	3/8 TUBE X 1/4 NPT 45 ELBOW
1	LPG-37	HOSE ASSEMBLY, 3/8 X 37"
1	29839	3/8 TUBE X 1/4 NPT ADAPTER
2. MANIFOLD TO BURNER		
1	43441	3/8 TUBE X 3/8 NPT ELBOW WITH TEST PORT
1	LP6-S-26	FIREJACKET HOSE ASSEMBLY, 3/8 X 26"
1	29959	3/8 TUBE X 3/4 NPT FEMALE ELBOW
3. MANIFOLD TO POWERPACK		
1	29839	3/8 TUBE X 1/4 NPT ADAPTER
1	LP6-42	HOSE ASSEMBLY, 3/8 X 42"
1	29871	3/8 TUBE X 1/4 NPT ELBOW

ELECTRICAL SCHEMATIC



ELECTRICAL SCHEMATIC

NUMBER	PART NUMBER	QTY	DESCRIPTION
1	43903	1	TRIGGER/SENSOR CABLE
2	43979	1	HI-VOLTAGE CABLE
3	43978	1	HOSE CABLE
4	43977	1	BURNER CABLE
5	43975	1	REED SWITCH CABLE
6	43976	1	SENSOR CABLE
7	24015	1	BATTERY CABLE, POSITIVE
8	32602	1	BATTERY CABLE, NEG. 20"
9	37038	1	BATTERY CABLE, NEG. 20" (NOT SHOWN)

**Pioneering Leadership and
Innovation in Quality
Pavement Maintenance
Products.**

CRAFCOTM INC
AN ERGONER COMPANY

**235 South Hibbert • Mesa, Arizona 85210
480-655-8333 • Watts 1-800-528-8242
Fax 480-655-1712**

©Copyright 2003 by Crafc0, Inc.