



# ***E-Z*** ***SERIES II*** ***1000***

Parts Manual - 26458  
Revision H

Fill in appropriate fields that apply to this machine

Machine S/N: \_\_\_\_\_

1<sup>st</sup> Hose S/N: \_\_\_\_\_

2<sup>nd</sup> Hose S/N: \_\_\_\_\_

1<sup>st</sup> Pump S/N: \_\_\_\_\_

2<sup>nd</sup> Pump S/N: \_\_\_\_\_

Engine S/N: \_\_\_\_\_

Compressor S/N: \_\_\_\_\_

Gear Box S/N (Patcher): \_\_\_\_\_

Blower S/N (Magnum): \_\_\_\_\_

# EZ 1000 Series II Melter Part Manual

## Revisions

[illegible]



**EZ1000 Series II Melter - Electric Hose  
PN 46200EB**



**EZ1000 Series II Melter - Electric Hose  
PN 46200EC63**



**EZ1000 Series II Melter - Standard Hose  
PN 46200SB**



**EZ1000 Series II Melter - Standard Hose  
PN 46200SC63**

## Table of Contents

|                                                            |      |
|------------------------------------------------------------|------|
| 1.0 About This Manual .....                                | 1-1  |
| 1.1 How to use this manual: .....                          | 1-1  |
| 2.0 Safety Precautions.....                                | 2-1  |
| 2.1 General Safety .....                                   | 2-1  |
| 2.2 Personal Safety .....                                  | 2-1  |
| 2.3 Equipment or Operational Safety.....                   | 2-1  |
| 2.4 Safety Symbols and Notices.....                        | 2-2  |
| 3.0 Limited Warranty.....                                  | 3-1  |
| 3.1 Warranty Claim Instructions.....                       | 3-2  |
| 4.0 Machine Specifications .....                           | 4-1  |
| 5.0 Operating Instructions.....                            | 5-1  |
| 5.1 Preparing the Machine for Start Up .....               | 5-1  |
| 5.2 Machine Start Up for Electric Hose.....                | 5-3  |
| 5.3 Altitude Compensation System.....                      | 5-5  |
| 5.4 About the Heated Hose, Wand, Valve, and Tip Guard..... | 5-5  |
| 5.5 Electric Hose Care and Cautions.....                   | 5-6  |
| 5.6 Storing the Electric Hose for Transport.....           | 5-6  |
| 5.7 Machine Start Up for Standard Hose.....                | 5-7  |
| 5.8 Loading Material into the Sealant Tank .....           | 5-8  |
| 5.8.1 Material Tank Depth Chart.....                       | 5-9  |
| 5.9 Dispensing the Material .....                          | 5-10 |
| 5.10 Shutting Down and Cleaning Out the Machine .....      | 5-11 |
| 5.11 Storing the Machine .....                             | 5-13 |
| 5.12 Air Compressor: PN 46200EC63, 46200SC63 .....         | 5-13 |
| 6.0 Maintenance Instructions .....                         | 6-1  |
| 6.1 Engine.....                                            | 6-1  |
| 6.2 Hydraulic System .....                                 | 6-1  |
| 6.3 Heat Transfer Oil .....                                | 6-1  |
| 6.4 Wheel Bearing.....                                     | 6-1  |
| 6.5 Material Sensor Tube .....                             | 6-1  |
| 6.6 Cleaning Material Tank and Sensor Area .....           | 6-1  |
| 6.7 Lug Nuts.....                                          | 6-1  |
| 6.8 Brakes.....                                            | 6-2  |
| 6.9 Tongue Jack.....                                       | 6-2  |

## **Table of Contents**

|                                                                            |      |
|----------------------------------------------------------------------------|------|
| 6.10 Temperature Control Calibration.....                                  | 6-2  |
| 6.11 Maintenance Chart .....                                               | 6-3  |
| 6.12 Service Instructions .....                                            | 6-4  |
| 6.13 General Maintenance Parts .....                                       | 6-4  |
| 6.14 Recommended Spare Parts.....                                          | 6-5  |
| 6.15 Recommended Fluids and Lubricants.....                                | 6-5  |
| 6.16 Applicable Brands of Heat Transfer Oil .....                          | 6-7  |
| 6.17 Typical Heat Transfer Oil Specifications .....                        | 6-7  |
| 6.18 Material Pump Replacement.....                                        | 6-8  |
| 7.0 How to Use a Multimeter .....                                          | 7-1  |
| 7.1 Checking DC Voltage with a Multimeter.....                             | 7-1  |
| 7.2 Checking AC Voltage with Multimeter .....                              | 7-1  |
| 7.3 Checking Resistance (Ohms) .....                                       | 7-1  |
| 7.4 Checking Amperage .....                                                | 7-2  |
| 8.0 Burner Troubleshooting.....                                            | 8-1  |
| 8.1 Sealant Heating Slowly .....                                           | 8-11 |
| 8.2 Agitator Troubleshooting.....                                          | 8-12 |
| 8.2.1 Symptom: Mixer Does Not Rotate.....                                  | 8-12 |
| 8.2.2 Mixer Hydraulic Troubleshooting.....                                 | 8-18 |
| 8.3 Hose Troubleshooting.....                                              | 8-21 |
| 8.3.1 Symptom: Hose Does Not Heat .....                                    | 8-21 |
| 8.3.2 Symptom: Trigger is not Working .....                                | 8-26 |
| 8.3.3 RTD Sensor Ohms vs. Temperature.....                                 | 8-27 |
| 8.4 Pump Troubleshooting.....                                              | 8-29 |
| 8.4.1 Symptom: Material Does Not Dispense When the Pump is Activated ..... | 8-29 |
| 8.4.2 Pump Hydraulic Troubleshooting .....                                 | 8-34 |
| 9.0 About the Illustrated Parts List.....                                  | 9-1  |
| 9.1 Ordering Crafco Parts.....                                             | 9-1  |
| 9.2 EZ1000 Series II Melter .....                                          | 9-2  |
| 9.3 EZ1000 Series II melter Options .....                                  | 9-6  |
| 9.4 Tank Detail .....                                                      | 9-9  |
| 9.5 Plumbing .....                                                         | 9-10 |
| 9.6 Control Box Assembly – Electric Hose.....                              | 9-12 |
| 9.7 Control Box Assembly – Standard Hose.....                              | 9-16 |

## Table of Contents

|                                                        |      |
|--------------------------------------------------------|------|
| 9.8 Engine Assembly – Non Compressor .....             | 9-20 |
| 9.9 Engine Assembly, Compressor - Standard Hose .....  | 9-21 |
| 9.10 Engine Assembly, Compressor – Electric Hose ..... | 9-22 |
| 9.11 Hydraulic Control Valve Assembly .....            | 9-23 |
| 9.12 Hydraulic Compressor Valve Assembly .....         | 9-25 |
| 9.13 Diesel Burner Assembly .....                      | 9-26 |
| 9.14 Material Pump Assembly .....                      | 9-29 |
| 9.15 Air Compressor Assembly .....                     | 9-30 |
| 9.16 Wand Assembly .....                               | 9-32 |
| 9.17 Hydraulic Diagram .....                           | 9-34 |
| 9.18 Hydraulic Diagram - Compressor .....              | 9-38 |
| 9.19 Diesel Line Schematic .....                       | 9-44 |
| 9.21 Electrical Schematic – Electric Hose .....        | 9-46 |
| 9.22 Electrical Schematic – Standard Hose .....        | 9-48 |
| 9.23 Hot Air Lance .....                               | 9-50 |
| 10.0 Tools and Accessories .....                       | 10-1 |

## List of Figures

|                                                         |      |
|---------------------------------------------------------|------|
| Fig. 5.1 Hydraulic Fluid Level and Temp. Gauge.....     | 5-2  |
| Fig. 5.2 Heat Transfer Oil Dipstick.....                | 5-2  |
| Fig. 6.1 Lug bolt Tightening Sequence.....              | 6-2  |
| Fig. 6.2 Temperature Control Calibration .....          | 6-2  |
| Fig. 6.3 Material Pump Replacement .....                | 6-9  |
| Fig. 7.1 Standard Multimeter .....                      | 7-2  |
| Fig. 7.2 Clamp – On Amp Meter/Multimeter .....          | 7-3  |
| Fig. 8.1 Diesel Burner Schematic.....                   | 8-6  |
| Fig. 8.2 Diesel Burner Electrode Adjustment.....        | 8-10 |
| Fig. 8.3 Diesel Burner Air Settings .....               | 8-10 |
| Fig. 8.4 Checking Din Plug Voltage.....                 | 8-16 |
| Fig. 8.5 Mixer Circuit .....                            | 8-17 |
| Fig. 8.6 Hydraulic Valve Pressure Setting .....         | 8-19 |
| Fig. 8.7 Din Plug Layout.....                           | 8-20 |
| Fig. 8.8 Junction Box Voltage Testing .....             | 8-23 |
| Fig. 8.9 Hose Circuit Schematic .....                   | 8-24 |
| Fig. 8.10 Junction Box Wiring.....                      | 8-25 |
| Fig. 8.11 Pump Circuit Schematic .....                  | 8-33 |
| Fig. 9.1 EZ1000 Series II Melter.....                   | 9-2  |
| Fig. 9.2 EZ1000 Series II Melter.....                   | 9-4  |
| Fig. 9.3 EZ1000 Series II Melter Options.....           | 9-6  |
| Fig. 9.4 Tank Detail .....                              | 9-9  |
| Fig. 9.5 Plumbing .....                                 | 9-10 |
| Fig. 9.6 Control Box Assembly: 46200EB, 46200EC63 ..... | 9-13 |
| Fig. 9.7 Control Box Assembly: 46200EB, 46200EC63 ..... | 9-14 |
| Fig. 9.8 Control Box Assembly: 46200SB, 46200SC63 ..... | 9-16 |
| Fig. 9.9 Control Box Assembly: 46200SB, 46200SC63 ..... | 9-18 |
| Fig. 9.10 Engine Assembly - 46200EB, 46200SB .....      | 9-20 |
| Fig. 9.11 Engine Assembly - 46200SC63.....              | 9-21 |
| Fig. 9.12 Engine Assembly - 46200EC63.....              | 9-22 |
| Fig. 9.13 Hydraulic Control Valve .....                 | 9-23 |

### List of Figures

|                                                                      |      |
|----------------------------------------------------------------------|------|
| Fig. 9.14 Compressor Valve Assembly .....                            | 9-25 |
| Fig. 9.15 Diesel Burner .....                                        | 9-26 |
| Fig. 9.16 Material Pump Assembly .....                               | 9-29 |
| Fig. 9.17 Compressor Assembly .....                                  | 9-30 |
| Fig. 9.18 Wand Assembly .....                                        | 9-32 |
| Fig. 9.19 Hydraulic Diagram W/O Compressor 46200EB, 46200SB .....    | 9-34 |
| Fig. 9.20 Hydraulic Diagram W/O Compressor 46200EB, 46200SB .....    | 9-36 |
| Fig. 9.21 Hydraulic Diagram W/ Compressor 46200EC63, 46200SC63 ..... | 9-38 |
| Fig. 9.22 Hydraulic Diagram W/ Compressor 46200EC63, 46200SC63 ..... | 9-40 |
| Fig. 9.23 Hydraulic Diagram W/ Compressor 46200EC63, 46200SC63 ..... | 9-42 |
| Fig. 9.24 Diesel Fuel Line Schematic .....                           | 9-44 |
| Fig. 9.25 Electrical Schematic 46200EB, 46200EC63 .....              | 9-46 |
| Fig. 9.26 Electrical Schematic – 46200SB, 46200SC63 .....            | 9-48 |
| Fig. 9.27 Hot Air Lance (Option) .....                               | 9-50 |

### List of Tables

|                                                                |      |
|----------------------------------------------------------------|------|
| Table 2-1 Safety Symbols and Notices .....                     | 2-2  |
| Table 2-2 Safety Symbols and Notices (continued).....          | 2-3  |
| Table 4-1 Machine Specifications.....                          | 4-1  |
| Table 5-1 Preparing the Machine for Start Up .....             | 5-1  |
| Table 5-2 Starting the Burner for Electric Hose .....          | 5-3  |
| Table 5-3 Electric Hose Care .....                             | 5-6  |
| Table 5-4 Hose for Transport Instructions .....                | 5-6  |
| Table 5-5 Starting the Burner for Standard Hose .....          | 5-7  |
| Table 5-6 Loading Material into the Sealant Tank .....         | 5-8  |
| Table 5-7 Material Tank Depth Chart .....                      | 5-9  |
| Table 5-8 Dispensing the Material – Electric Hose .....        | 5-10 |
| Table 5-9 Dispensing the Material – Standard Hose .....        | 5-11 |
| Table 5-10 Shutting Down with an Electric Hose.....            | 5-12 |
| Table 5-11 Shutting Down with a Standard Hose .....            | 5-12 |
| Table 6-1 Maintenance Chart.....                               | 6-3  |
| Table 6-2 Service Instructions.....                            | 6-4  |
| Table 6-3 General Maintenance Parts.....                       | 6-4  |
| Table 6-4 Recommended Spare Parts .....                        | 6-5  |
| Table 6-5 Recommended Fluids and Lubricants .....              | 6-5  |
| Table 6-6 Applicable Brand of Heat Transfer Oil .....          | 6-7  |
| Table 6-7 Material Pump Replacement .....                      | 6-8  |
| Table 8-1 Basic Visual Burner Troubleshooting.....             | 8-1  |
| Table 8-2 Basic Visual Burner Troubleshooting (continued)..... | 8-2  |
| Table 8-3 Burner Electrical Troubleshooting .....              | 8-2  |
| Table 8-4 Burner Electrical Troubleshooting (continued).....   | 8-3  |
| Table 8-5 Electrical Troubleshooting (continued) .....         | 8-4  |
| Table 8-6 Electrical Troubleshooting (continued) .....         | 8-5  |
| Table 8-7 Smoke Coming Out of Exhaust Stack .....              | 8-7  |
| Table 8-8 Burner Lights but Shuts Down After 15 Seconds.....   | 8-7  |
| Table 8-9 Testing the DC controller.....                       | 8-8  |
| Table 8-10 Burner Fuel Solenoid Testing .....                  | 8-8  |

### List of Tables

|                                                              |      |
|--------------------------------------------------------------|------|
| Table 8-11 Burner Ignition Coil Test.....                    | 8-9  |
| Table 8-12 Bleeding the Burner .....                         | 8-9  |
| Table 8-13 Sealant is Heating Slowly.....                    | 8-11 |
| Table 8-14 Basic Visual Mixer Troubleshooting .....          | 8-12 |
| Table 8-15 Mixer Electrical Troubleshooting .....            | 8-13 |
| Table 8-16 Mixer Electrical Troubleshooting (continued)..... | 8-14 |
| Table 8-17 Mixer Electrical Troubleshooting (continued)..... | 8-15 |
| Table 8-18 Mixer Hydraulic Troubleshooting .....             | 8-18 |
| Table 8-19 Basic Visual Troubleshooting .....                | 8-21 |
| Table 8-20 Electrical Troubleshooting.....                   | 8-21 |
| Table 8-21 Electrical Troubleshooting (continued) .....      | 8-22 |
| Table 8-22 Electrical Troubleshooting (continued) .....      | 8-23 |
| Table 8-23 Trigger is not Working.....                       | 8-26 |
| Table 8-24 RTD Sensor Ohms vs. Temperature .....             | 8-27 |
| Table 8-25 RTD Sensor Ohms vs. Temperature (continued) ..... | 8-28 |
| Table 8-26 Basic Visual Pump Troubleshooting.....            | 8-29 |
| Table 8-27 Pump Electrical Troubleshooting.....              | 8-30 |
| Table 8-28 Pump Electrical Troubleshooting (continued) ..... | 8-31 |
| Table 8-29 Pump Electrical Troubleshooting (continued) ..... | 8-32 |
| Table 8-30 Pump Electrical Troubleshooting (continued) ..... | 8-33 |
| Table 8-31 Pump Hydraulic Troubleshooting .....              | 8-34 |

## Chapter 1 Introduction

### 1.0 About This Manual

This manual is supplied with each new Crafcro EZ Series II 1000 Diesel Melter. The manual assists your machine operators in the proper use of the melter applicator and provides information about the machine's mechanical functions.

Your Crafcro EZ Series II 1000 Diesel Melter is specially made to give excellent service and save maintenance expense. However, as with all specially engineered equipment, you get best results at minimum cost if you:

Operate your machine as instructed in this manual.


Maintain your machine regularly as stated in this manual.

### 1.1 How to use this manual:

This manual is formatted to start each new chapter on the right page. There may be a blank page on the left page if the previous chapter ends on the right page.

If you are viewing this in a digital format (PDF) the following features are available:

1. The Table of Contents, List of Tables, and List of Figures are all hyperlinks, when mouse is left clicked on section, table, or figure you will be sent to that page.
2. The blue highlighted text throughout the manual is a hyperlink, when mouse is left clicked you will be sent to that page, table, or figure.
3. The panel to the left in the PDF is a bookmarks panel, if you left mouse click on any section/heading in the bookmarks panel you will be sent to that page.
4. There is an attachments icon (paper clip) to the left of the bookmarks, this is where you will find full size prints of the control box, electrical, and hydraulic schematics



### **WARNING**

#### California Proposition 65 Warning

Engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm. Always use care to avoid breathing engine exhaust. Failure to comply could result in death or serious injury.



## Chapter 2 Safety

### 2.0 Safety Precautions

For more in-depth safety information, please see Safety Manual (PN 26221) which comes with the machine. Or contact your nearest authorized Crafco Distributor at [crafco.com/Distributors](http://crafco.com/Distributors).

### 2.1 General Safety

- Crafco, Inc. assumes no liability for an accident or injury incurred through improper use of the machine.
- Read this manual thoroughly before operating the machine.
- Obey all CAUTION and WARNING signs posted on the machine.
- Make sure an operator fully knows how to operate the machine before using the machine.

### 2.2 Personal Safety

- The high operating temperatures of this machine and the sealant it contains requires that protective clothing, gloves, hard-soled shoes, and safety glasses or a face shield be worn at all times by operators of the machine.
- Prevent water from going into any part of the machine. If there is indication of water in the heat transfer oil system, warm heating oil to 250-300°F for 2 to 3 hours.
- Bodily contact with hot sealant or heat transfer oil can cause severe burns.
- If the mixer is not stopped before adding solid material, hot material can get on an operator's body and cause severe burns.
- Keep hands, feet, and clothing away from all moving parts.

### 2.3 Equipment or Operational Safety

- Do not operate the machine in buildings or work areas that do not have sufficient airflow.
- Shut-down the burner and the engine before refilling the fuel tank.
- Make sure mixer stops before adding solid material to the sealant tank. Lift the lid, place the material on the lid and close the lid. The mixer should restart automatically.
- Always keep a correctly maintained fire extinguisher near the machine and know how to use it.
- DO NOT heat transfer oil to a temperature of more than 525°F.
- DO NOT put too much heat transfer oil in the reservoir. The expansion of oil while it heats up can cause overflow. With the machine on level ground, check the oil each day before starting the burner. Add oil to the top mark on the dipstick if required (at 70°F). Use only recommended heat transfer oil. Change the oil after 500 hours of machine operation, or one year, whichever comes first.
- Follow the operating instructions for starting and shutting down the burner. Instructions are mounted on the control box on the machine.
- Calibrate the temperature control operation after each 50 hours of machine operation. Refer to section [6.9 Temperature control Calibration](#).
- Replace any hoses which show signs of wear, fraying or splitting.
- Make sure all fittings and joints are tight and do not leak each time the machine is used.
- Do not leave the machine unattended while the burner is lit.
- Tighten all bolts and screws every 100 hours of machine operation.

## Chapter 2 Safety

### 2.4 Safety Symbols and Notices

Important safety symbols and notices are marked on the machine and in this manual. Failure to comply could result in equipment damage, operational malfunction, serious injury, or death. Please read and comply with all symbols and notices. The table below includes the most commonly used symbols and notices.

**Table 2-1 Safety Symbols and Notices**

| Symbol                                                                              | Item                        | Remarks                                                              |
|-------------------------------------------------------------------------------------|-----------------------------|----------------------------------------------------------------------|
| <b>WARNING</b>                                                                      | Warning                     | Refers to possible bodily injury or death.                           |
| <b>CAUTION</b>                                                                      | Caution                     | Refers to possible equipment damage or operational malfunction.      |
|    | Severe Burn Hazard          | Hot material can cause severe burns.                                 |
|   | Protective Shoes            | Wear hard-soled work shoes.                                          |
|  | Protective Gloves           | Wear heat resistant gloves.                                          |
|  | Protective Face or Eye Wear | Wear face shield or safety glasses.                                  |
|  | Body Crush Hazard           | Do not stand between trailer and hitch when hooking melter to truck. |

## Chapter 2 Safety

**Table 2-2 Safety Symbols and Notices (continued)**

| Symbol                                                                             | Item           | Remark                                                                    |
|------------------------------------------------------------------------------------|----------------|---------------------------------------------------------------------------|
|   | Crush Hazard   | Keep feet and legs clear.                                                 |
|   | Pinch Hazard   | Keep hands and feet clear.                                                |
|   | Exhaust Hazard | Avoid breathing engine exhaust.                                           |
|  | Read Manual    | Read and understand operator and safety manuals before operating machine. |



## Chapter 3 Warranty Information

### 3.0 Limited Warranty

Crafco, Inc., through Crafco or one of its affiliated distributors, will replace for the original purchaser free of charge any parts found upon examination by the factory at Chandler, Arizona, to be defective in material or workmanship. This warranty is for a period one year from in-service date, but excludes engine or components, tires, and battery as these items are subject to warranties issued by their manufacturers.

Crafco, Inc. shall not be liable for parts that have been damaged by accident, alteration, abuse, improper lubrication/maintenance, normal wear, or other cause beyond our control.

The warranty provided herein extends only to the repair and/or replacement of those components on the equipment covered above and does not cover labor costs. The warranty does not extend to incidental or consequential damages incurred as a result of any defect covered by this warranty.

All transportation and labor costs incurred by the purchaser in submitting or repairing covered components must be borne by the purchaser. Crafco, Inc. specifically disavows any other representation, warranty, or liability related to the condition or use of the product

### CAUTION

Use of replacement parts other than genuine Crafco parts may impair the safety or reliability of your equipment and nullifies any warranty.

## Chapter 3 Warranty Information

### 3.1 Warranty Claim Instructions

Crafcro, Inc. warrants parts and machinery purchased through Crafcro or one of its affiliated distributors for one year from purchased or in-service date. If parts fail to function within the first year of purchase, a return authorization number (RA) must be obtained. If the part was purchased through Crafcro, Inc., please contact Crafcro returns department at [Returns@Crafcro.com](mailto>Returns@Crafcro.com) for an RA number or if purchased through a Crafcro distributor please contact your distributor. Note: if the part has a serial number associated with it, for example; a machine or electric hose or wand, this must be furnished when requesting the RA number. The customer will be emailed or faxed an RA form with all instructions to return the item to Crafcro, Inc. See example. If the part is found to be within the one year warranty period and has not been abused or modified, a credit will be issued to the customer's account or credit card. The customer may request the part be replaced instead of a credit, if desired.

Wear items are not covered under Crafcro, Inc. limited warranty. A wear item is defined as but not limited to: material pumps, sealing tips, tires, etc.

Note: All engine warranties are covered through the engine manufacture. If you need information for a distributor in your area please contact us and we will direct you to the closest engine distributor.

All parts returned are tested and evaluated. If the part has been modified in anyway without prior consent from a Crafcro, Inc. representative, warranty is void.

Please follow the instructions stated below when calling in a Warranty Claim. Failure to follow these procedures may be cause to void the warranty.

Call your local Crafcro Distributor. If you do not know who your local distributor is, call a Crafcro Customer Service Representative, (Toll Free 1-800-528-8242) for name, location and telephone number.

On contacting the distributor, be prepared to identify the serial number, model number, engine number, engine manufacturer, and the date of purchase if available.

Should the cause of the malfunction be a defective part, the Distributor will advise you of the procedure to follow for a replacement.

The warranty is valid only for parts, which have been supplied or recommended by Crafcro, Inc.

If you have any additional questions regarding warrant repairs and parts, please do not hesitate to call toll free 1-800-528-8242.

#### For Warranty:

Crafcro, Inc.

25527 South Arizona Avenue, Chandler, AZ  
85248

Phone: (480) 655-8333 or (800) 528-8242

Fax: (480) 655-1712

#### For all other inquires:

Crafcro, Inc.

6165 W, Detroit St., Chandler, AZ 85226

Phone: (602) 276-0406 or (800) 528-8242

Fax: (480) 961-0513

[CustomerService@crafcro.com](mailto:CustomerService@crafcro.com)

## Chapter 4 Machine Specifications

### 4.0 Machine Specifications

**Table 4-1 Machine Specifications**

| Specification                  | PN 46200EB/SB                                                                                 | PN 46200EC63                                               | PN 46200SC63                                             |
|--------------------------------|-----------------------------------------------------------------------------------------------|------------------------------------------------------------|----------------------------------------------------------|
| Vat capacity                   | 265 gallons                                                                                   |                                                            |                                                          |
| Melt Capacity                  | 2100 lbs. per hour                                                                            |                                                            |                                                          |
| Heat transfer oil required     | 33.5 gallons at 70°F                                                                          |                                                            |                                                          |
| Tank construction              | Double boiler type                                                                            |                                                            |                                                          |
| Tank opening size              | Dual 14" x 18"                                                                                |                                                            |                                                          |
| Maximum heat input             | 290,000 BTUs                                                                                  |                                                            |                                                          |
| Burner and temperature control | Diesel-forced air thermostatic control                                                        |                                                            |                                                          |
| Engine Isuzu diesel            | Three cylinder<br>Model 3CH1 –<br>21.2 BHP @<br>3000 RPM                                      | Three cylinder<br>Model 3CD1TK<br>– 35.9 BHP @<br>2800 RPM | Three cylinder<br>Model 3CE1 –<br>32.5 BHP @<br>2800 RPM |
| Drive Mechanism                | All hydraulic with infinite speed forward and reverse on material pump. Fixed speed agitator. |                                                            |                                                          |
| Mixer                          | Full sweep mixer with 2 horizontal paddles, vertical risers                                   |                                                            |                                                          |
| Axle Capacity                  | Dual 5,200lbs..                                                                               |                                                            |                                                          |
| Tires                          | ST225/75R15 Load Range D                                                                      |                                                            |                                                          |
| Dry Weight Approximately       | 5,632lbs.                                                                                     | 5800lbs                                                    | 5800lbs                                                  |
| Diesel tank Capacity           | 30 Gallons                                                                                    |                                                            |                                                          |
| Hydraulic Tank Capacity        | 26 Gallons                                                                                    |                                                            |                                                          |
| Air Compressor                 | N/A                                                                                           | 63CFM @<br>125 PSI                                         | 63CFM @<br>125 PSI                                       |



## Chapter 5 Operating Instructions

### 5.0 Operating Instructions

The Crafco EZ 1000 Series II was developed to melt Crafco sealants. However, it works well with most road asphalt and federal specification crack or joint sealants.

**Note:** DO NOT attempt to operate the machine without using these and all other instructions.

### 5.1 Preparing the Machine for Start Up


**Table 5-1 Preparing the Machine for Start Up**

| Step                                                                                | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1                                                                                   | Fill the engine fuel tank with diesel fuel.<br>Note: Use No. 1 Diesel fuel in cold weather and No. 2 Diesel fuel in warm weather                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 2                                                                                   | Check the oil level in the engine crankcase. (Refer to the manufacturer's instruction for the engine.)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 3                                                                                   | Check the hydraulic fluid level while at a temperature of 70°F. Add fluid if necessary. See <a href="#">Fig. 5.1 Hydraulic Fluid Level and Temp. Gauge</a>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 4                                                                                   | With the machine on level surface, check the heat transfer oil level while at a temperature of 70°F. The oil should be at the full mark on the dipstick. DO NOT overfill or spillage may occur when the oil is heated and expands. See <a href="#">Fig. 5.2 Heat Transfer Oil Dipstick</a>                                                                                                                                                                                                                                                                                                                                                                              |
| 5                                                                                   | Make sure all toggle switches are turned "OFF" and all temperature control dials are set to their minimum settings.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 6                                                                                   | Check the oil level in the air compressor if this machine is so equipped.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>WARNING</b>                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|  | <p>The safe operation of this machine is the operator's responsibility. Use extreme care when operating this machine; safety is the result of being careful and paying attention to details. Remember the propane flame is approximately 2,200°F. Some exposed parts of the machine reach 500°F, the sealant 400°F, and the hydraulic fluid 180°F.</p> <p>Always put on protective clothing, gloves, hard-soled shoes, and safety glasses or a face shield. Be sure that all joints and fittings are tight and leak proof. Immediately replace any hose, which shows any signs of wear, fraying, or splitting. Tighten all bolts, nuts, and screws every 100 hours.</p> |

## Chapter 5 Operating Instructions



**Fig. 5.1 Hydraulic Fluid Level and Temp. Gauge**



**Fig. 5.2 Heat Transfer Oil Dipstick**

## Chapter 5 Operating Instructions

### 5.2 Machine Start Up for Electric Hose

**Table 5-2 Starting the Burner for Electric Hose**

| Step | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Fully open the exhaust stack cover.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 2    | Start the engine. (Refer to the manufacturer's instructions for the engine).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 3    | <p>Turn the "POWER" toggle switch in the control box to the "ON" position. The red light marked "BURNER" will illuminate indicating that the material and hot oil temperatures are below set point. When the red light goes off this indicates the material or oil temperatures are up to the set point.</p> <p><b>NOTE:</b> Just because this light is illuminated does not indicate the burner is actually working.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 4    | <p>Turn "HOSE SELECTOR" switch to "ELECTRIC".</p> <p><b>Note:</b> Electric hose will only work if hose selector switch is in the electric hose position.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 5    | Set the heat transfer oil temperature at 500°F.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 6    | Set the material temperature to the manufacturer's recommended temperature.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|      | <p style="text-align: center;"><b>CAUTION</b></p> <p>If the burner does not ignite the first time, turn the "POWER" toggle switch to the "OFF" position. Turn the toggle switch to "ON" again; the burner should ignite. If the burner still does not ignite, refer to <a href="#">8.0.1 Symptoms: Burner will Not Ignite</a> to determine the malfunction.</p> <p><b>Important:</b> The solid material in the tank melts first around the walls, bottom, and around the center tower of the tank. The material temperature sensor is located by the wall, therefore, it is possible that at the beginning of the melting process the indicated temperature reaches operating value, but the material between the center tower and the outside wall of the tank is still solid. This is normal, and when the heated hose is ready for operation, most of the material in the tank will be melted and heated to the proper application temperature.</p> |
| 7    | Allow the heat transfer oil to continue to heat.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 8    | <p>When the material reaches 275°F, the mixer light will illuminate which indicates the mixer can be engaged by turning the toggle switch at the control panel to "FORWARD" position. If the mixer does not move, allow the material to heat longer.</p> <p><b>Note:</b> Mixer speed is preset at the factory and cannot be adjusted. The mixer cannot be engaged until the material reaches 275°F.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|      | <p style="text-align: center;"><b>CAUTION</b></p> <p>Jamming the mixer can cause the hydraulic oil to overheat and damage the machine.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 9    | The hose automatically turns "ON" when the material temperature reaches 275°F. The red light marked "HEATED HOSE" will illuminate when the hose control is calling for heat.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 10   | <p>Adjust the temperature dial to the manufacturer's recommended temperature.</p> <p><b>Note:</b> The hose reaches operating temperature in approximately 30 minutes.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

## Chapter 5 Operating Instructions

**Table 5-2.1 Starting the Burner for Electric Hose (continued)**

| Step | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 11   | After the hose reaches the temperature set point, the light in the control box marked "HEATED HOSE" turns off.                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 12   | Remove hose and wand from transport position and place wand tip in shoebox.                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|      | <p><b>Important:</b> The hose must reach 325°F before dispensing can take place. If the hose does not dispense when the trigger is activated, allow the material to heat longer. If the hose still does not dispense, shut the machine down, locate and remove the plug in the line.</p> <p>The oven must be at 300°F for 20 minutes before attempting to pump. The oven temperature can be regulated by opening the slide gate to increase temperature or close slide gate to decrease temperature. Slide gate is located on passenger side.</p> |
| 13   | When sealant reaches application temperature, open "TANK, RECIRCULATION."                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 14   | Reverse pump for 3-5 minutes by turning the pump toggle switch to "PUMP REVERSE". When pump turns freely, return switch to "ON ELECTRIC" position.                                                                                                                                                                                                                                                                                                                                                                                                |
| 15   | Depress wand trigger to recirculate material back into the tank to get material flowing freely through the pump.                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 16   | When application of material is desired, open "APPLICATOR VALVE" AND close "RECIRCULATION VALVE". See Table 5-8 Dispensing the Material – Electric Hose                                                                                                                                                                                                                                                                                                                                                                                           |
|      | <p align="center"><b>CAUTION</b></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|      | <p>DO NOT twist or kink the hose.</p> <p>Avoid sharp bends and continuous twisting by maintaining a minimum 10-inch bend radius.</p> <p>DO NOT use a setting on the hose controller if more than 400°F.</p> <p>DO NOT move or bend the hose when cold: it can cause damage to the hose.</p> <p>DO NOT leave the hose cycling for longer than 30 minutes without dispensing material; coking can occur and permanently damage the hose.</p> <p>DO NOT remove the hose from the boom during operation or kinking will occur.</p>                    |
|      | <p><b>Important:</b> It is strongly recommended that the hose be stored in the boom (locked position) when not in use or when in transit. This will prevent twisting or kinking.</p>                                                                                                                                                                                                                                                                                                                                                              |

## Chapter 5 Operating Instructions

### 5.3 Altitude Compensation System

This unit may be equipped with an Altitude Compensation System. If so, there will be a small boxed housing mounted right below the engine start key panel on the engine mount cross member. The system is automatic during most operating conditions. However, if the machine is taken from above or below an altitude of 2,624 ft. (800 Meters) while the engine is running, the engine will need to be stopped and then restarted. There is a yellow indicator light that illuminates when the machine is above 2,624 ft. (800 Meters) indicating that the system is active.

### 5.4 About the Heated Hose, Wand, Valve, and Tip Guard

#### The Heated Hose

The heated hose supplied with the machine is Teflon-lined with steel over braid. It has a heating element, which runs the length of the hose to heat the material within the hose. The hose is covered with high temperature, durable rubber.

#### The Wand


The wand has an aluminum tube to protect both the wand and the operator. The pistol grip actuator is equipped with an electric switch which, when depressed, sends a signal to actuate the pump. The wand is equipped with a trigger lock to prevent accidental pump actuation when it is not pumping material. The trigger must be in the "LOCKED" position at all times except when intentionally pumping material.

#### The Valve

The wand has a disposable duckbill valve on the end, which shuts off the flow of material when the pump is turned off and prevents excessive dripping of material. This valve also directs the material into a stream for easy application into the crack. Other sealing tips are available. See [10.0 Tools and Accessories](#) for other sealing tips and options.

#### Tip Guard

The wand has a Tip Guard installed at the factory only when a duckbill is installed. This Tip Guard is not required when using sealing disk or dripless tip adapter. The purpose of this guard is to prolong the life of the duckbill and to protect the operator in the event of a duckbill failure. Ensure this guard is installed properly before operating equipment. See below.



## Chapter 5 Operating Instructions

### 5.5 Electric Hose Care and Cautions

**Table 5-3 Electric Hose Care**

| Step | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | <b>CAUTION</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|      | Twisting and kinking of the electric hose (used on BAX, Super Shots, and EZ Series Melters) causes the hose to fail; the electric heating wires are shorted out to the metal hose cover and the hose stops heating.<br><br>This type of failure is not covered under the CrafcO warranty.                                                                                                                                                                                                                 |
| 1    | Set the hose temperature at 380°F, or manufacturer recommended operating temperature.                                                                                                                                                                                                                                                                                                                                                                                                                     |
| 2    | Allow the hose to be turned "ON" and heating for a minimum of 30 minutes.                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 3    | Make sure the hose swivel between the hose and wand moves freely.<br><b>Note:</b> Do not twist or bend the hose over sharp edges such as the edge of the frame or tank. CrafcO, Inc. recommends you do not work directly under the boom; this may cause damage to the hose.                                                                                                                                                                                                                               |
| 4    | Follow all machine instructions in this manual.                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|      | <b>CAUTION</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|      | Hose damage occurs if:<br>The hose is bent or moved when cold.<br>The hose is twisted or bent at a sharp radius.<br>The hose is moved before being heated a minimum of 30 minutes and set at 380°F.<br>The operator crosses over or under the hose causing the wires between the hose and wand connection to twist or wrap up.<br>The swivel is cold and is not flexible which can cause the hose to twist.<br>The wiring between the hose and the wand is pulled, stressed, or used to support the wand. |

### 5.6 Storing the Electric Hose for Transport

**Table 5-4 Hose for Transport Instructions**

| Step | Action                                                                                                                                         |
|------|------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Leave the hose in the boom, swing the boom clockwise towards the front of the machine and lock the boom into position with the latch provided. |
| 2    | Place the wand in the wand holder and lock the wand into position with the latch provided.                                                     |

## Chapter 5 Operating Instructions

### 5.7 Machine Start Up for Standard Hose

**Table 5-5 Starting the Burner for Standard Hose**

| Step | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Fully open the exhaust stack.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| 2    | Start the engine. (Refer to the manufacturer's instructions for the engine).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 3    | <p>Turn the "POWER" toggle switch in the control box to the "ON" position. The red light marked "BURNER" will illuminate indicating that the material and hot oil temperatures are below set point. When the red light goes off this indicates the material or oil temperatures are up to the set point.</p> <p><b>NOTE:</b> Just because this light is illuminated does not indicate the burner is actually working.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 4    | Turn "HOSE SELECTOR" switch to "STANDARD".                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 5    | Set the heat transfer oil temperature at 450°F.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 6    | Set the material temperature to 350°F.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|      | <p style="text-align: center;"><b>CAUTION</b></p> <p>If the burner does not ignite the first time, turn the "POWER" toggle switch to the "OFF" position. Turn the toggle switch to "ON" again; the burner should ignite. If the burner still does not ignite, refer to <a href="#">8.0.1 Symptoms: Burner will Not Ignite</a> to determine the malfunction.</p> <p><b>Important:</b> The solid material in the tank melts first around the walls, bottom, and around the center tower of the tank. The material temperature sensor is located by the wall, therefore, it is possible that at the beginning of the melting process the indicated temperature reaches operating value, but the material between the center tower and the outside wall of the tank is still solid. This is normal, and when the heated hose is ready for operation, most of the material in the tank will be melted and heated to the proper application temperature.</p> |
| 7    | Allow the heat transfer oil to continue to heat.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 8    | <p>When the material reaches 275°F, the mixer light will illuminate which indicates the mixer can be engaged by turning the toggle switch at the control panel to "FORWARD" position. If the mixer does not move, allow the material to heat longer.</p> <p><b>Note:</b> Mixer speed is preset at the factory and cannot be adjusted. The mixer cannot be engaged until the material reaches 275°F.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|      | <p style="text-align: center;"><b>CAUTION</b></p> <p>Jamming the mixer can cause the hydraulic oil to overheat and damage the machine.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| 9    | <p>The pump light will come "ON" when the material temperature reaches 275°F indicating the temperature interlock will allow material pump operation.</p> <p><b>NOTE:</b> Hose temperature display will not read an accurate pumping temperature until sealant is being pumped through the hose.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|      | <p><b>Important:</b> The oven must be at 300°F for 20 minutes before attempting to pump. The oven temperature can be regulated by opening the slide gate to increase temperature or close slide gate to decrease temperature. Slide gate is located on passenger side.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

## Chapter 5 Operating Instructions

**Table 5-5.1 Starting the Burner for Standard Hose (continued)**

| Step | Action                                                                                                                                                                                                                                                 |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 10   | When sealant reaches 325°F, open “TANK, RECIRCULATION valves, and close APPLICATOR VALVE”.                                                                                                                                                             |
| 11   | Reverse pump for 3-5 minutes by turning the pump toggle switch to “PUMP REVERSE” position. When pump turns freely, return switch to “ON STANDARD” position. This circulates hot material from bottom of tank back on top of cold material in the tank. |
| 12   | Increase heat transfer oil temperature to 500°F and material temperature to manufacturers recommended application temperature (Approx. 380°-400°F).                                                                                                    |
| 13   | When application of material is desired, remove hose from oven and connect to wand assembly (Hand tight only). Insert wand tip fully into shoebox with hand wand valve in “OPEN” position.                                                             |
| 14   | Open the “APPLICATOR VALVE”, close “RECIRCULATION VALVE”.                                                                                                                                                                                              |

### 5.8 Loading Material into the Sealant Tank

This unit is equipped with a safety interlock system on the loading door. This system disables the mixer hydraulic system when the lid is open to stop the mixer from turning. This is a safety feature for the operator and should never be disabled for any reason.

#### CAUTION

Personal injury could occur if this safety system is disabled.

**Table 5-6 Loading Material into the Sealant Tank**

| Step                                                                                | Action                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>WARNING</b>                                                                                                                                                                                                                                              |
|                                                                                     | Following this procedure prevents hot material from getting on operators and causing severe burns. Never throw blocks of material directly into tank. Hot material splash hazard will result.                                                               |
| 1                                                                                   | To load material into the sealant tank first open the lid.                                                                                                                                                                                                  |
| 2                                                                                   | Place the solid material on the lid then close the lid.                                                                                                                                                                                                     |
| 3                                                                                   | Continue adding solid material at intervals to allow the mixer to rotate without jamming.<br><b>Note:</b> If blocks of solid material are added too quickly, jamming results and slows down the melting process.                                            |
|                                                                                     | <b>Note:</b> When sealant placement volume is low, or the crew has stopped working for lunch hot oil and material temperatures can equalize. To lower material temperature add a few blocks of cold sealant. This may not be an option if the tank is full. |

## Chapter 5 Operating Instructions

### 5.8.1 Material Tank Depth Chart

**Table 5-7 Material Tank Depth Chart**

| DEPTH OF MATERIAL TANK | CAPACITY IN GALLONS BOTTOM UP | CAPACITY IN LITERS BOTTOM UP | CAPACITY IN GALLONS TOP DOWN | CAPACITY IN LITERS TOP DOWN |
|------------------------|-------------------------------|------------------------------|------------------------------|-----------------------------|
| 1                      | 9.00                          | 34.07                        | 255.22                       | 966.11                      |
| 2                      | 18.25                         | 69.08                        | 245.67                       | 929.96                      |
| 3                      | 27.50                         | 104.10                       | 236.12                       | 893.81                      |
| 4                      | 36.75                         | 139.11                       | 226.57                       | 857.66                      |
| 5                      | 46.00                         | 174.13                       | 217.02                       | 821.51                      |
| 6                      | 55.38                         | 209.64                       | 207.47                       | 785.36                      |
| 7                      | 64.50                         | 244.16                       | 197.92                       | 749.21                      |
| 8                      | 74.00                         | 280.12                       | 188.37                       | 713.06                      |
| 9                      | 83.25                         | 315.14                       | 178.84                       | 676.98                      |
| 10                     | 92.50                         | 350.15                       | 169.54                       | 641.78                      |
| 11                     | 102.00                        | 386.11                       | 160.25                       | 606.61                      |
| 12                     | 111.00                        | 420.18                       | 150.95                       | 571.41                      |
| 13                     | 120.50                        | 456.14                       | 141.65                       | 536.20                      |
| 14                     | 129.75                        | 491.16                       | 132.36                       | 501.04                      |
| 15                     | 139.00                        | 526.17                       | 123.06                       | 465.83                      |
| 16                     | 148.25                        | 561.19                       | 113.76                       | 430.63                      |
| 17                     | 157.75                        | 597.15                       | 104.47                       | 395.46                      |
| 18                     | 167.00                        | 632.16                       | 95.17                        | 360.26                      |
| 19                     | 176.25                        | 667.18                       | 85.87                        | 325.05                      |
| 20                     | 185.75                        | 703.14                       | 76.57                        | 289.85                      |
| 21                     | 195.25                        | 739.10                       | 62.28                        | 235.75                      |
| 22                     | 204.75                        | 775.06                       | 57.98                        | 219.48                      |
| 23                     | 214.25                        | 811.02                       | 48.68                        | 184.27                      |
| 24                     | 224.00                        | 847.93                       | 39.39                        | 149.11                      |
| 25                     | 233.50                        | 883.89                       | 30.09                        | 113.90                      |
| 26                     | 243.00                        | 919.86                       | 20.79                        | 78.70                       |
| 27                     | 250.50                        | 948.25                       | 11.49                        | 43.49                       |
| 28                     | 262.00                        | 991.78                       | 2.26                         | 8.56                        |
| 28.25                  | 264.50                        | 1001.24                      | 0                            | 0.00                        |

## Chapter 5 Operating Instructions

### 5.9 Dispensing the Material

**Table 5-8 Dispensing the Material – Electric Hose**

| Step                                                                              | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                   | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|  | <p>Put on protective clothing, gloves, hard-soled shoes, and face shield or safety glasses when operating or filling this machine. Read the entire manual before operating the machine.</p> <p>Never point the wand at any part of the body or at any other person. Hot material can cause severe burns.</p> <p><b>Important:</b> Some difficulty may be encountered when starting up on cold days. Although the wand is designed to heat the material all the way down to the tip, on cold days you can place the tip of the wand into the shoebox to facilitate material melting in the valve. Insert the wand tip for only a short time before proceeding.</p>  |
| 1                                                                                 | When the material and hose have reached manufacturer's application temperature, you are ready to dispense material.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| 2                                                                                 | Turn the pump speed control to the lowest setting by turning the speed control knob fully clockwise.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 3                                                                                 | Insert the wand tip into the shoebox, depress trigger on the wand and slowly increase pump speed until the pump motor starts to turn.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 4                                                                                 | Adjust the pump speed for the desired flow rate for the application. The rate of flow may be varied while the pump is running.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|                                                                                   | <b>CAUTION</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|                                                                                   | Never open flow control more than 2 full turns when using an electric hose as this will cause premature material pump wear.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|                                                                                   | <p><b>Important:</b> It may be necessary to use the recirculation with the electric hose anytime the machine is not going to be used for more than 5-10 minutes when the ambient temperature is below 40°F or not being used for 20-30 minutes in warmer weather. This is critical after material is up to operating temperature and burner is running intermittently, the oven will cool and all material in the plumbing and pump will solidify. To get the oven hot enough to start pumping again, add several blocks of sealant to lower the material temperature enough to cause burner to ignite. This may not be an option if the tank is already full.</p> |

## Chapter 5 Operating Instructions

**Table 5-9 Dispensing the Material – Standard Hose**

| Step                                                                              | Action                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>WARNING</b>                                                                    |                                                                                                                                                                                                                                                                                                              |
|  | <p>Put on protective clothing, gloves, hard-soled shoes, and face shield or safety glasses when operating or filling this machine. Read the entire manual before operating the machine.</p> <p>Never point the wand at any part of the body or at any other person. Hot material can cause severe burns.</p> |
| 1                                                                                 | When the material has reached manufacturer's application temperature, you are ready to dispense material.                                                                                                                                                                                                    |
| 2                                                                                 | Turn the pump speed control to the lowest setting by turning the speed control knob fully clockwise.                                                                                                                                                                                                         |
| 3                                                                                 | Insert the wand tip into the shoebox, open the ball valve on the wand and adjust the control valve to get close to the desired material flow for the application.                                                                                                                                            |
| 4                                                                                 | Open recirculation valve to get the desired flow rate.                                                                                                                                                                                                                                                       |
| 5                                                                                 | This method of operation will give maximum pump life. If the sealant does not flow from the applicator wand, close hand wand valve and place hose and wand back into the oven to allow the sealant to become more liquid, and then repeat procedure.                                                         |
| 6                                                                                 | Once sealant is flowing freely, reverse pump and install desired sealing tip or disk and you are ready to begin sealing. See Section <a href="#">10.0 Tools and Accessories</a> for other sealing tips and disk.                                                                                             |
| <b>CAUTION</b>                                                                    |                                                                                                                                                                                                                                                                                                              |
|                                                                                   | Extreme care should be taken when changing or installing sealing tips. Always engage pump reverse if sealant is hot. Hot sealant can cause severe skin burns.                                                                                                                                                |

### 5.10 Shutting Down and Cleaning Out the Machine

When shutting down the machine for the day, Crafco recommends leaving the melter about half full with material. This will give a fairly rapid heat up rate in the morning, but allows enough material to start dispensing right away when the material becomes molten.

## Chapter 5 Operating Instructions

**Table 5-10 Shutting Down with an Electric Hose**

| Step | Action                                                                                                                                           |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Leaving the hose in the boom, swing the boom clockwise towards the front of the machine and lock the boom into position with the latch provided. |
|      | <b>CAUTION</b>                                                                                                                                   |
|      | DO NOT kink or twist the hose or permanent damage may result.                                                                                    |
| 2    | Place the wand in the wand holder and lock the wand into position with the latch provided.                                                       |
| 3    | Reverse the pump while removing tip adapter and or duckbill. Continue to reverse for approximately 30 more seconds.                              |
| 4    | Close the "APPLICATOR VALVE" and "TANK VALVE".                                                                                                   |
| 5    | Turn the mixer toggle switch to the "OFF" position.                                                                                              |
| 6    | Turn the "POWER" switch to the "OFF" position.                                                                                                   |
| 7    | Stop the engine by turning the key to the "OFF" position.                                                                                        |

**Table 5-11 Shutting Down with a Standard Hose**

| Step | Action                                                                                                                                |
|------|---------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Close recirculation valve and reverse the pump for approximately 3 minutes.                                                           |
| 2    | Close the "APPLICATOR VALVE" first, then close the "TANK VALVE".                                                                      |
| 3    | Turn the mixer toggle switch to the "OFF" position.                                                                                   |
| 4    | Turn the "POWER" switch to the "OFF" position.                                                                                        |
| 5    | Stop the engine by turning the key to the "OFF" position.                                                                             |
| 6    | Remove the wand from the hose                                                                                                         |
| 7    | Remove the hose from the boom and wrap on hose hanger located in the oven. Ensure the hose is not touching the tank wall or plumbing. |

## Chapter 5 Operating Instructions

### 5.11 Storing the Machine

Store the machine in an area where moisture cannot enter the heating system such as heat transfer oil tank, etc. Extended down time can cause moisture build up in the heating tank.

Evidence that moisture has collected in the heat transfer oil is a constant popping noise. If this popping noise is heard, warm the heat transfer oil to 300°F for two to three hours to evaporate the moisture. Failure to follow this procedure will cause the heat transfer oil to overflow the tank resulting in possible machine damage and/or personal injury.

Best practice is to check in the material tank prior to starting the burner. If water is present, try and remove as much as possible, heat the material to 300°F for two to three hours to evaporate the moisture. Failure to follow this procedure will cause the material to overflow the tank resulting in possible machine damage and/or personal injury.

Store the machine for longer periods with the material tank empty.

### 5.12 Air Compressor: PN 46200EC63, 46200SC63

Always use approved high pressure air hoses with properly installed fittings which are not frayed or worn.

A cold air lance is supplied.

Consult CrafcO, or your hot air lance manufacturer for the appropriately sized hot air lance to use on the following machine models:

For PN46200EC63 63 CFM @ 125 PSI

For PN46200SC63 63 CFM @ 125 PSI

The engine RPM is set by the factory for maximum air compressor performance on the 46200EC63.

On the 46200SC63 for best performance, the throttle will need to be set at maximum RPM.

If the compressor is not needed, turn "OFF" the toggle switch in the control box (labeled compressor)

The compressor is operated hydraulically and runs continuously. When air is not being discharged, the compressor automatically closes the intake valve and goes into an idle state which takes less energy to operate but still maintains the RPM.

There is an internal air leak at the air muffler that provides lubrication of the compressor.



## Chapter 6 Maintenance Instructions

### 6.0 Maintenance Instructions

This chapter contains all normal maintenance instructions to properly maintain your machine.

#### 6.1 Engine

Refer to the manufacturer's operating and maintenance instructions for the engine.

#### 6.2 Hydraulic System

Check hydraulic fluid daily.

Change hydraulic filter every 250 hours of machine operation. Replace if necessary.

Change hydraulic fluid every 500 hours of operation.

#### 6.3 Heat Transfer Oil

Check the oil level at the start of every day.

Change the oil every 500 hours of machine operation or 1 year, whichever comes first. Failure to follow this oil change interval will result in machine damage.

#### 6.4 Wheel Bearing

Pack the wheel bearing every 24,000 miles or every two years, whichever comes first. Use a good grade of bearing grease.

#### 6.5 Material Sensor Tube

Check for heat transfer oil in tube every 50 hours of operation. 2 ounces required.

#### 6.6 Cleaning Material Tank and Sensor Area

The material tank needs to be cleaned every year or as needed for proper operation. As the machine is used, material builds up around the tank walls and sensor guard. The built up material prevents heat from getting to the fresh material and causes longer heat up times. The built up material will also prevent the material temperature sensor from reading as accurately because it becomes insulated from the fresh material. The coked material needs to be scraped or chipped from the tank walls. The area between the sensor and sensor guard needs to be cleaned also for proper temperature sensing. An air chisel with various sized blades usually works best to break up the material and remove it from the walls. Once the walls and sensor guard areas are cleaned, remove all the loose chunks from the tank, and vacuum out any smaller pieces.

#### 6.7 Lug Nuts

Torque all nuts/bolts before first road use and after each wheel removal. Check and torque after the first 10 miles, 25 miles, and again at 50 miles. Check periodically thereafter.

Torque in stages as follows:


First stage 20-25 foot-pound (ft-lb)

Second stage 50-60 foot pound (ft-lb)

Third stage 90-120 foot pound (ft-lb)

Tighten bolts and nuts in the sequence shown in [Fig. 6.1](#).

## Chapter 6 Maintenance Instructions



**Fig. 6.1 Lug bolt Tightening Sequence**

### 6.8 Brakes


Check the brakes daily.

### 6.9 Tongue Jack

Lubricate the tongue jack, using a good grade of bearing grease.

### 6.10 Temperature Control Calibration

Check the control knob calibration weekly. Calibrate by turning the knob counterclockwise. If the marks do not align, loosen screw in knob and align the line on the control knob with the calibration mark on the scale plate. (See Fig. 6.2)



**Fig. 6.2 Temperature Control Calibration**

## Chapter 6 Maintenance Instructions

### 6.11 Maintenance Chart

**Table 6-1 Maintenance Chart**

|                          |                                                                                  | Hours                           |    |     |     |
|--------------------------|----------------------------------------------------------------------------------|---------------------------------|----|-----|-----|
| Possible Cause           | Procedure                                                                        | 8                               | 50 | 250 | 500 |
| Engine check oil level   | Refer to the manufacturer's instructions for the engine                          | X                               |    |     |     |
| Other engine maintenance | Refer to the manufacture's operating and maintenance instructions for the engine |                                 |    |     |     |
| Material Sensor Tube     | Check for HTO fluid                                                              |                                 | X  |     |     |
|                          | Add                                                                              | As needed                       |    |     |     |
| Heat Transfer Oil        | Check                                                                            | X                               |    |     |     |
|                          | Change                                                                           |                                 |    |     | X   |
| Hydraulic Oil            | Check                                                                            | X                               |    |     |     |
|                          | Change                                                                           |                                 |    |     | X   |
| Hydraulic Oil Filter     | Change                                                                           |                                 |    | X   |     |
| Burner                   | Check burner box insulation                                                      |                                 |    |     | X   |
|                          | Clean CAD cell                                                                   |                                 |    |     | X   |
|                          | Check Electrodes                                                                 |                                 |    |     | X   |
|                          | Replace burner nozzle                                                            |                                 |    |     | X   |
| Wheel Bearings           | Clean and re-pack using a good grade of bearing grease                           | Every 24,000 miles or two years |    |     |     |
| Tongue Jack              | Grease using a good grade of bearing grease                                      | Once a year                     |    |     |     |
| Compressor               | Refer to manufacturer's instructions for the compressor                          |                                 |    |     |     |
| Material Tank            | Scrape out built up material in the material tank                                | Once a year or as needed        |    |     |     |
| Material Sensor Guard    | Scrape out built up material around guard                                        |                                 |    |     | X   |

For a list of parts required for maintenance see Table 6-3 General Maintenance Parts.

## Chapter 6 Maintenance Instructions

### 6.12 Service Instructions

**Table 6-2 Service Instructions**

| Step | Action                                                                                                                                                                                             |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Do a general inspection of the machine at least once a week.                                                                                                                                       |
| 2    | Replace all worn or damaged parts.<br><b>Note:</b> Keep regular replacement items in stock for emergency repairs to prevent costly downtime. See <a href="#">Table 6-4 Recommended Spare Parts</a> |
| 3    | Make necessary adjustments and tighten all loose nuts or screws.                                                                                                                                   |
| 4    | Watch for leaks. Tighten fittings or repair as necessary.                                                                                                                                          |
| 5    | Clean the external surfaces of the machine at regular intervals.<br><b>Note:</b> Refer to the material manufacturer's instructions for recommendations.                                            |
| 6    | Follow the recommended maintenance per Table 6-1 Maintenance Chart                                                                                                                                 |

For service, find a list of authorized Distributors and service centers at [Crafco.com/Distributors](http://Crafco.com/Distributors).

### 6.13 General Maintenance Parts

**Table 6-3 General Maintenance Parts**

| Quantity                  | Description            | Machine                 | Part No.                  |
|---------------------------|------------------------|-------------------------|---------------------------|
| 1                         | Fuel Filter            | All                     | 41867                     |
| 1                         | Oil Filter             | 46200EB,<br>46200SB     | 45389                     |
| 1                         | Oil Filter             | 46200EC63,<br>46200SC63 | 45381                     |
| 1                         | Air Filter             | 46200EB,<br>46200SB     | 45391                     |
| 1                         | Air Filter             | 46200SC63               | 45382                     |
| 1                         | Air Filter             | 46400EC63               | 45348                     |
| 1                         | Nozzle, Burner         | All                     | 41881                     |
| 1                         | Packing, Material Pump | All                     | 29990S                    |
| 1                         | Hydraulic Oil Filter   | All                     | 45438                     |
| <a href="#">Table 6-5</a> | Hydraulic Oil          | All                     | <a href="#">Table 6-5</a> |
| <a href="#">Table 6-5</a> | Heat Transfer Oil      | All                     | <a href="#">Table 6-6</a> |

## Chapter 6 Maintenance Instructions

### 6.14 Recommended Spare Parts

**Table 6-4 Recommended Spare Parts**

| Quantity | Description                           | Machine               | Part No. |
|----------|---------------------------------------|-----------------------|----------|
| 1        | Temperature Controller, Material      | All                   | 51672    |
| 1        | Temperature Controller, Electric Hose | 46200EB,<br>46200EC63 | 51691    |
| 1        | Temperature Controller, Hot Oil       | All                   | 43391    |
| 1        | Temperature Controller, Material      | 46200SB,<br>46200SC63 | 43397    |
| 1        | DC Controller                         | All                   | 42335    |
| 1        | Coupling, Fuel Pump                   | All                   | 41970    |
| 1        | Electric Hose, 15'                    | 46200EB,<br>46200EC63 | 51731    |
| 1        | Solenoid                              | All                   | 39602    |

### 6.15 Recommended Fluids and Lubricants

**Table 6-5 Recommended Fluids and Lubricants**

| Application       | Recommended                        | Full Point | Machine No.                       |
|-------------------|------------------------------------|------------|-----------------------------------|
| Fuel              | #1 Cold climate<br>#2 Warm Climate | 30 Gals.   | All Models                        |
| Engine Oil        | Refer to engine manual             | 3 Qt.      | PN 46200EB, 46200SB,<br>46200SC63 |
|                   |                                    | 6.7 Qt.    | PN 46200EC63                      |
| Hydraulic Oil     | Shell AW Hydraulic 46              | 24 Gals.   | All Models                        |
| Heat Transfer Oil | Shell Turbo T 68 (Group II)        | 33.5 Gals. | All Models                        |
| Air Compressor    | Refer to Compressor Manual         |            | PN 46200EC63 and<br>46200SC63     |

**Legend:**

PN 46200EB EZ1000 Electric Base

PN 46200SB EZ1000 Standard Base

PN 46200EC63 EZ1000 Electric 63 CFM Compressor

PN 46200SC63 EZ1000 Standard 63 CFM Compressor

**Chapter 6 Maintenance Instructions**

This page left blank intentionally

## Chapter 6 Maintenance Instructions

### 6.16 Applicable Brands of Heat Transfer Oil

**Table 6-6 Applicable Brand of Heat Transfer Oil**

| Manufacturer          | Product Name                 | Crafco Heat Transfer Fluid  |
|-----------------------|------------------------------|-----------------------------|
| Chevron               | Heat Transfer Oil Grade 46   | Shell Turbo T 68 (Group II) |
| Citgo                 | Hytherm Oil 46               | Shell Turbo T 68 (Group II) |
| Conoco                | Hydroclear Heat Transfer Oil | Shell Turbo T 68 (Group II) |
| Fina                  | Vulcan Heat Transfer Oil 46  | Shell Turbo T 68 (Group II) |
| Lubrication Engineers | Heat Transfer Oil            | Shell Turbo T 68 (Group II) |
| Exxon Mobile          | Caloria HT 43                | Shell Turbo T 68 (Group II) |
| Mobil                 | Mobiltherm 43                | Shell Turbo T 68 (Group II) |
| Mobil                 | Mobiltherm 603               | Shell Turbo T 68 (Group II) |
| Phillips 66           | Heat Transfer Oil #3         | Shell Turbo T 68 (Group II) |
| Phillips 66           | Magnus Oil 68                | Shell Turbo T 68 (Group II) |

#### CAUTION

The heat transfer oil in this machine is a grade that has been tested and recommended by Crafco, Inc. Using a grade of oil not specifically recommended by Crafco, Inc., is cause for warranties to be voided.

All oils subjected to high temperatures deteriorate with time and lose many of their characteristics. Tests conducted by Crafco, Inc. have determined that for best results and safety, the heat transfer oil in this machine must be drained and replaced with Crafco, Inc. recommended oil after five hundred (500) hours of machine operation or one (1) year, whichever occurs first.

### 6.17 Typical Heat Transfer Oil Specifications

|                       |        |
|-----------------------|--------|
| ISO                   | 68     |
| Flash Point, COC      | 445°F  |
| Viscosity @ 100°F-SUS | 325    |
| Viscosity @ 210°F-SUS | 50     |
| Viscosity Index       | 95-100 |
| Pour Point            | 0°F    |
| Carbon residue        | 1%     |


## Chapter 6 Maintenance Instructions

### 6.18 Material Pump Replacement

**Table 6-7 Material Pump Replacement**

| Step                                                                              | Action                                                                                                                                                                                                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1                                                                                 | Close "TANK VALVE".                                                                                                                                                                                                                                                                                                                                                                     |
| 2                                                                                 | Remove the front of the heat compartment.                                                                                                                                                                                                                                                                                                                                               |
|  | <b>WARNING</b>                                                                                                                                                                                                                                                                                                                                                                          |
|                                                                                   | The material in the sealant tank is extremely hot. Bodily contact with hot sealant can cause severe burns.                                                                                                                                                                                                                                                                              |
| 3                                                                                 | Remove the 6 bolts from both flanges of the double elbow and remove double elbow.                                                                                                                                                                                                                                                                                                       |
| 4                                                                                 | Remove the 8 bolts from the tank valve flange.                                                                                                                                                                                                                                                                                                                                          |
| 5                                                                                 | Remove the 4 bolts from the hydraulic motor and loosen setscrew in pump/motor coupling. Remove motor from pump motor mount.                                                                                                                                                                                                                                                             |
| 6                                                                                 | Remove the 4 bolts from the pump base and remove pump from heat compartment.                                                                                                                                                                                                                                                                                                            |
| 7                                                                                 | Remove the lower suction tee and the flanged nipple assembly from the material pump. Make note of tee direction.                                                                                                                                                                                                                                                                        |
| 8                                                                                 | Install lower suction tee and flanged nipple assembly into new pump.                                                                                                                                                                                                                                                                                                                    |
| 9                                                                                 | Install material pump in heat compartment. Flange gasket P/N 29060 will also need to be installed at this time using (8) 3/8-16 x 1" bolts, (2) flat washers per bolt (1 on each side of flange), lock washer, and hex nuts. Use (4) 1/2-13 x 1 3/4" bolts, flat washer, lock washer, and hex nuts to attach pump to pump base. Leave all hardware loose until everything is installed. |
| 10                                                                                | Install double elbow using new flange gaskets P/N29050, 3/8-16 x 1" bolts, (2) flat washers per bolt (1 on each side of flange), lock washer, and hex nut. Leave all hardware loose until everything is installed.                                                                                                                                                                      |
| 11                                                                                | Install hydraulic motor on material pump using (4) 3/8-16 x 1 1/4" bolts and lock washers. Tighten setscrew on pump/motor coupling.                                                                                                                                                                                                                                                     |
| 12                                                                                | Tighten all bolts and nuts.                                                                                                                                                                                                                                                                                                                                                             |
| 13                                                                                | Replace heat compartment using (12) 1/4-20 x 3/4" bolts, flat washers, and lock washers.                                                                                                                                                                                                                                                                                                |

**Chapter 6 Maintenance Instructions**



**Fig. 6.3 Material Pump Replacement**



## Chapter 7 How to Use a Multimeter

### 7.0 How to Use a Multimeter

Melters use 12-volt direct current (DC) to power the burner, hydraulic valves, and trigger on electric wand. The DC power is from a 12-volt battery.

The electric hose and wand uses 24-volt 3-phase alternating current (AC). The AC power is from the generator which hangs under the radiator. This system has no reference to ground so there is no possibility of electrical shock unless you are between 2 of the phases. NOTE: ONLY CHECK AMPERAGE ON A HOSE WITH A CLAMP-ON AMP METER.

12-volt DC power has little danger of electrical shock. Care must still be taken when dealing with DC power systems because it is capable of producing large amounts of current.

### 7.1 Checking DC Voltage with a Multimeter

Connect the probes to the meter.

Set the range to a position that includes 12-volts or higher.

Touch the red probe to the positive side of accessory and black probe to ground. If the item you are checking has a ground wire attached then use that ground or you can use a non-painted surface on the frame.

### 7.2 Checking AC Voltage with Multimeter

Connect the probes to the meter (See [Fig. 7.1 Standard Multimeter](#)).

Set range to a position that includes 24-volts or higher.

There are three steps to test the generator voltage. All 3 values should be in the range of 24-30 volts AC.

- Touch red probe to the white wire of the generator and the black probe to the green wire of the generator.
- Next move black probe to black wire.
- Then move red probe to green wire.

### 7.3 Checking Resistance (Ohms)

Connect probes to the meter (See [Fig. 7.1 Standard Multimeter](#)).

**Note:** When checking Ohms the circuit cannot be completed. This means one end of the wire will need to be disconnected.

#### 7.3.1 How to Check Wire Continuity

Set the meter to "Audible Continuity".

Now touch the probe to each end of the wire in question. The meter will read "0" on the screen and make an audible beep if the wire has continuity from end to end.

#### 7.3.2 How to Check RTD Sensor

Set dial to Ohms  $\Omega$ . If your meter has different ranges set to 2K or 2000 ohm range.

Touch one probe to each screw or wire of the sensor. The meter will read X.XX if in the 2K range or XXX.X if in the 2000 range.

## Chapter 7 How to Use a Multimeter

### 7.4 Checking Amperage


The Multimeter can be used to check amperages under 10 amps in AC or DC current.

When checking the amperage of the electric hose **always use a clamp-on amp meter** (See [Fig. 7.2 Clamp – On Amp Meter/Multimeter](#)). The amperage in the hose can reach as high as 35 amps. Clamp the meter around one wire at a time. Remember most clamp-on meters do not work on DC current.



**Fig. 7.1 Standard Multimeter**

## Chapter 7 How to Use a Multimeter



**Fig. 7.2 Clamp – On Amp Meter/Multimeter**



## Chapter 8 Troubleshooting

### 8.0 Burner Troubleshooting

#### 8.0.1. Symptoms: Burner will Not Ignite

**Table 8-1 Basic Visual Burner Troubleshooting**

| Step | Possible Cause                                                                                                                                                                                          | If . . .                                                                                                                                                                                                                                                                        |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is the engine running?<br><b>NOTE:</b> You can troubleshoot the burner without the engine running, but you must connect a battery charger to the battery and the ignition must be in the "ON" position. | <ul style="list-style-type: none"> <li>• Yes, go to Step 2.</li> <li>• No, start the engine.</li> </ul>                                                                                                                                                                         |
| 2    | Is the "POWER" toggle switch in the "ON" position?                                                                                                                                                      | <ul style="list-style-type: none"> <li>• Yes, go to Step 3.</li> <li>• No, turn the toggle switch to the "ON" position.</li> </ul>                                                                                                                                              |
| 3    | Is the red "Burner" light "ON"?                                                                                                                                                                         | <ul style="list-style-type: none"> <li>• Yes, go to Step 6.</li> <li>• No, go to <a href="#">Table 8-3 Burner Electrical Troubleshooting</a> Step 4.</li> </ul>                                                                                                                 |
| 4    | Are both the Material and Hot Oil temperature dials set above the current temperatures?                                                                                                                 | <ul style="list-style-type: none"> <li>• Yes, go to Step 4.</li> <li>• No, set the Material temperature according to the type of material you are using and the Hot Oil 100°F above the Material set point.</li> </ul>                                                          |
| 5    | Does either readout display a -1?<br><b>NOTE:</b> This occurs only when there is a short in the sensor circuit.                                                                                         | <ul style="list-style-type: none"> <li>• Yes, this indicates a short in the circuit. Check the RTD sensor for water causing a short under the cap. Also look for worn wires possibly shorting to frame between sensor and control box.</li> <li>• No, go to step 4a.</li> </ul> |
| 5a   | Does either readout display a 1?<br><b>NOTE:</b> This occurs only when the sensor circuit is not completed.                                                                                             | <ul style="list-style-type: none"> <li>• Yes, this indicates a break in one or both of the sensor wires between the RTD sensor and the PAKSTAT. Check for broken wires between sensor and PAKSTAT.</li> <li>• No, go to Step 6.</li> </ul>                                      |
| 6    | Is the circuit breaker tripped?                                                                                                                                                                         | <ul style="list-style-type: none"> <li>• Yes, reset by pushing in the button that popped out.</li> <li>• No go to Step 7.</li> </ul>                                                                                                                                            |
| 7    | Is the fuel level low or empty?                                                                                                                                                                         | <ul style="list-style-type: none"> <li>• Yes, fill with #2 diesel fuel. Then bleed the burner, see <a href="#">Table 8-12 Bleeding the Burner</a></li> <li>• No, go to Step 8.</li> </ul>                                                                                       |

## Chapter 8 Troubleshooting

**Table 8-2 Basic Visual Burner Troubleshooting (continued)**

| Step | Possible Cause                                                                                | If . . .                                                                                                                                                                                          |
|------|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 8    | Is there smoke coming out of the exhaust stack?                                               | <ul style="list-style-type: none"> <li>• Yes, go to <a href="#">Table 8-13 Sealant is Heating Slowly</a>.</li> <li>• No, go to Step 9.</li> </ul>                                                 |
| 9    | Is your burner working properly, but it seems to take a while to reach operating temperature? | <ul style="list-style-type: none"> <li>• Yes, go to <a href="#">Table 8-13 Sealant is Heating Slowly</a>.</li> <li>• No, Call CrafcO, Inc. and speak to a customer service technician.</li> </ul> |

**Note:** Use [Fig. 8.1 Diesel Burner Schematic](#) while troubleshooting the burner electrical system.

**Table 8-3 Burner Electrical Troubleshooting**

| Step | Possible Cause                                                                                                                                                   | If . . .                                                                                                                                                                                         |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is there 12Vdc between the 2 center terminals of the frame solenoid?                                                                                             | <ul style="list-style-type: none"> <li>• Yes, go to 1a.</li> <li>• No, check for poor connection or broken wire between frame solenoid and engine oil pressure switch white/red wire.</li> </ul> |
| 1a   | Is there 12Vdc between the large terminal (red wire going to burner plug) of the frame solenoid and the black wire in the burner plug?                           | <ul style="list-style-type: none"> <li>• Yes, go to Step 4.</li> <li>• No, go to Step 1b.</li> </ul>                                                                                             |
| 1b   | Is there 12Vdc between the other large terminal (red wire going to the circuit breaker) of the frame solenoid and the ground wire attached to the mounting bolt? | <ul style="list-style-type: none"> <li>• Yes, replace frame solenoid.</li> <li>• No, go to step 2.</li> </ul>                                                                                    |
| 2    | Is there 12Vdc between the circuit breaker (red wire going to frame solenoid) located under the battery and the ground lug on the battery tray?                  | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between circuit breaker and frame solenoid.</li> <li>• No, go to Step 2a.</li> </ul>                               |
| 2a   | Is there 12Vdc between the circuit breaker (red wire going to battery positive cable) and the ground lug on the battery tray?                                    | <ul style="list-style-type: none"> <li>• Yes, wait 15 seconds then repeat step 2.</li> <li>• If still no voltage then replace circuit breaker.</li> <li>• No, go to step 2b.</li> </ul>          |
| 2b   | Check for loose or broken wires between circuit breaker and battery positive cable.                                                                              | <ul style="list-style-type: none"> <li>• Yes, replace or repair damaged wire and repeat Step 3.</li> <li>• No, go to step 3.</li> </ul>                                                          |

## Chapter 8 Troubleshooting

**Table 8-4 Burner Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                                                                          | If . . .                                                                                                                                                                                                                                                                                                   |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3    | Is there 12Vdc between the positive and negative battery post? If this check is done while the engine is running the reading should be 13.8 volts.                      | <ul style="list-style-type: none"> <li>• Yes, then there should be 12Vdc on the battery side of the circuit breaker.</li> <li>• No, replace battery.</li> <li>• <b>NOTE:</b> If the reading is less than 13.8 volts while the engine is running the alternator needs to be rebuilt or replaced.</li> </ul> |
| 4    | Find insulated quick connect between green wire and white wire that goes to burner plug. Is there 12Vdc between the green wire and a nearby ground source (black wire)? | <ul style="list-style-type: none"> <li>• Yes, go to <a href="#">Table 8-9 Testing the DC controller</a>.</li> <li>• No, go to step 4a.</li> </ul>                                                                                                                                                          |
| 4a   | Is there 12Vdc between green wire labeled "GRN-BRNR" on upper terminal blocks and nearby ground source (black wire)?                                                    | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between burner plug and terminal block.</li> <li>• No, go to Step 5.</li> </ul>                                                                                                                                              |
| 5    | Is there 12Vdc between gray wire labeled "GRY-2" and nearby ground source?                                                                                              | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to Step 5a.</li> </ul>                                                                                                                                                                                             |
| 5a   | Is there 12Vdc between terminal #7 gray wire and terminal #5 black wire of the hot oil PAKSTAT?                                                                         | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal block and terminal #7 of the hot oil PAKSTAT.</li> <li>• No, go to Step 5b.</li> </ul>                                                                                                                      |
| 5b   | Is there 12Vdc between terminal #6 gray wire and terminal #5 black wire of hot oil PAKSTAT?                                                                             | <ul style="list-style-type: none"> <li>• Yes, replace hot oil PAKSTAT.</li> <li>• No, go to Step 6.</li> </ul>                                                                                                                                                                                             |
| 6    | Is there 12Vdc between gray wire labeled "GRY-3" on upper terminal blocks and a nearby ground source (black wire)?                                                      | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal block and terminal #6 of the hot oil PAKSTAT.</li> <li>• No, go to Step 6a.</li> </ul>                                                                                                                      |
| 6a   | Is there 12Vdc between gray wire labeled "GRY-1" on upper terminal blocks and a nearby ground source (black wire)?                                                      | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to Step 7.</li> </ul>                                                                                                                                                                                              |
| 7    | Is there 12Vdc between terminal #4 gray wire and terminal #8 black wire of the material PAKSTAT?                                                                        | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal block and terminal #4 of the material PAKSTAT.</li> <li>• No, go to Step 7a.</li> </ul>                                                                                                                     |

## Chapter 8 Troubleshooting

**Table 8-5 Electrical Troubleshooting (continued)**


| Step | Possible Cause                                                                                                       | If . . .                                                                                                                                                                                                        |
|------|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7a   | Is there 12Vdc between terminal #3 orange wire and terminal #8 black wire of the material PAKSTAT?                   | <ul style="list-style-type: none"> <li>• Yes, replace PAKSTAT.</li> <li>• No, go to step 7b.</li> </ul>                                                                                                         |
| 7b   | Is there 12Vdc between terminal #1 orange wire and terminal #8 black wire of the material PAKSTAT?                   | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal #1 and #3 of material PAKSTAT.</li> <li>• No, go to Step 7c.</li> </ul>                                          |
| 7c   | Is there 12Vdc between terminal #9 orange wire and terminal #8 black wire of the material PAKSTAT?                   | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal #9 and #1 of material PAKSTAT.</li> <li>• No, go to Step 8.</li> </ul>                                           |
| 8    | Is there 12Vdc between orange wire labeled "ORN-1" on upper terminal blocks and a nearby ground source (black wire)? | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal #9 of the material PAKSTAT and terminal block.</li> <li>• No, go to Step 8a.</li> </ul>                          |
| 8a   | Is there 12Vdc between orange wire labeled "ORN-2" on upper terminal blocks and a nearby ground source (black wire)? | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to Step 9.</li> </ul>                                                                                                   |
| 9    | Is there 12Vdc between terminal #3 orange wire and terminal #5 black wire on hot oil PAKSTAT?                        | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal #3 of the hot oil PAKSTAT and terminal block.</li> <li>• No, go to Step 10.</li> </ul>                           |
| 10   | Is there 12Vdc between top terminal (orange wire) of power switch and nearby ground source (black wire)?             | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between top terminal power switch and terminal #3 of the hot oil PAKSTAT.</li> <li>• No, go to Step 11.</li> </ul>                |
| 11   | Is there 12Vdc between bottom terminal (red wire) of power switch and nearby ground source (black wire)?             | <ul style="list-style-type: none"> <li>• Yes, replace switch.</li> <li>• No, go to Step 12.</li> </ul>                                                                                                          |
| 12   | Is there 12Vdc between top terminal of circuit breaker (red wire) and nearby ground source (black wire)?             | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between top terminal of circuit breaker and bottom terminal (red wire) of power switch.</li> <li>• No, go to Step 12a.</li> </ul> |

## Chapter 8 Troubleshooting

**Table 8-6 Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                           | If . . .                                                                                                                                                                                         |
|------|--------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 12a  | Is there 12Vdc between bottom terminal of circuit breaker (red wire) and nearby ground source (black wire)?              | <ul style="list-style-type: none"> <li>• Yes, replace circuit breaker.</li> <li>• No, go to Step 13.</li> </ul>                                                                                  |
| 13   | Is there 12Vdc between “ACC” (red wire) of ignition switch and nearby ground source (black wire)?                        | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between “ACC” of ignition switch and bottom terminal of circuit breaker.</li> <li>• No, go to Step 13a.</li> </ul> |
| 13a  | Is there 12Vdc between “B” (blue wire) of ignition switch and nearby ground source (black wire)?                         | <ul style="list-style-type: none"> <li>• Yes, replace ignition switch.</li> <li>• No, go to Step 14.</li> </ul>                                                                                  |
| 14   | Is there 12Vdc between blue wire on starter solenoid and nearby ground source (black wire or bare metal on engine case)? | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between starter solenoid and ignition switch.</li> <li>• No, go to step 14a.</li> </ul>                             |
| 14a  | Check connections and condition of red battery cable?                                                                    | <ul style="list-style-type: none"> <li>• Yes, there should be 12Vdc at all previous steps.</li> <li>• No, replace battery cable.</li> </ul>                                                      |

## Chapter 8 Troubleshooting



**Fig. 8.1 Diesel Burner Schematic**

## Chapter 8 Troubleshooting

### 8.0.2. Excessive Smoke Coming Out of Exhaust Stack

**Table 8-7 Smoke Coming Out of Exhaust Stack**

| Step | Smoke Coming Out of the Exhaust Stack                                                                                                                                                                                                                                                                                                                                        |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | White smoke indicates that there is too much air being forced through the burner. Loosen the Air Shutter screw and rotate the Air Shutter counter clockwise to reduce air. Refer to <a href="#">Fig. 8.3 Diesel Burner Air Settings</a> , for the proper air settings and diagram.                                                                                           |
| 2    | Black smoke indicates that there is not enough air being forced through the burner. First check the air settings, if more air is required rotate Air Shutter clockwise. Refer to <a href="#">Fig. 8.3 Diesel Burner Air Settings</a> .                                                                                                                                       |
| 3    | Refer to <a href="#">Fig. 8.3 Diesel Burner Air Settings</a> to locate the following components. Using a 7/16" wrench, remove the copper fuel line nut attached to the nozzle line. Next remove the locking nut for the nozzle tube. Then loosen the locking tabs on the ignition coil and open the ignition coil. Remove the nozzle line assembly.                          |
| 4    | Using <a href="#">Fig. 8.2 Diesel Burner Electrode Adjustment</a> , make sure the electrodes are in the correct position. Loosen the clamp holding the electrodes in place so they can be adjusted. Inspect the porcelain ceramic insulator for any cracks. Also check the tip of each of the electrodes to make sure they still have a sharp point and are not rounded off. |
| 5    | If it has been longer than 500 hours since the last time the burner nozzle was replaced, Crafco recommends replacing the burner nozzle at this time.                                                                                                                                                                                                                         |
| 6    | Reassemble the burner, using the reverse order in Step 3.                                                                                                                                                                                                                                                                                                                    |
| 7    | Remove the burner box assembly by removing the four (4) 1/2" bolts, flat washer, lock washer, and nuts holding the burner box onto the trailer.                                                                                                                                                                                                                              |
| 7a   | Make sure the insulation inside the burner box is not soaked with diesel fuel.                                                                                                                                                                                                                                                                                               |
| 7b   | If the insulation is soaked with diesel fuel, you will need to replace the insulation.                                                                                                                                                                                                                                                                                       |
| 7c   | Reassemble the burner box.                                                                                                                                                                                                                                                                                                                                                   |

### 8.0.3. Burner Lights but Shuts Down After 15 Seconds

**Table 8-8 Burner Lights but Shuts Down After 15 Seconds**

| Step | Possible Cause                                            | If . . .                                                                                                                        |
|------|-----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| 1    | Does the CAD EYE have soot or dirt on the lens?           | <ul style="list-style-type: none"> <li>• Yes, clean cad eye lens with a soft cloth.</li> <li>• No, go to Step 2.</li> </ul>     |
| 2    | Are the two yellow wires for the CAD EYE loose or broken? | <ul style="list-style-type: none"> <li>• Yes, repair or replace as needed.</li> <li>• No, go to Step 3.</li> </ul>              |
| 3    | Is the CAD EYE faulty?                                    | <ul style="list-style-type: none"> <li>• Yes, replace CAD EYE.</li> <li>• No, call a Crafco Inc. service technician.</li> </ul> |

## Chapter 8 Troubleshooting

### 8.0.4. Testing the DC Controller

**Table 8-9 Testing the DC controller**

| Step | Bench Test DC Controller                                                                                                                                                                                                                                                                                                        |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Remove all wire nuts attaching the DC Controller to the burner.                                                                                                                                                                                                                                                                 |
| 2    | Attach the black ground wire to the negative battery post.                                                                                                                                                                                                                                                                      |
| 3    | Attach the red wire to the positive battery post.                                                                                                                                                                                                                                                                               |
| 4    | Attach the white (Enable) wire to the positive battery post to start the test. (Genesis II Controllers will have a 15-second delay.) <ul style="list-style-type: none"> <li>• Orange (Blower Motor) wire should have 12Vdc (all the time).</li> <li>• Blue (Igniter) wire should have 12Vdc.</li> </ul>                         |
| 5    | Twist the yellow wires together (once voltage registers) on the orange, blue and purple wires. <ul style="list-style-type: none"> <li>• Orange (Blower Motor) wire should maintain 12Vdc.</li> <li>• Blue (Igniter) wire should lose voltage after 15 seconds.</li> <li>• Purple (Valve) wire should maintain 12Vdc.</li> </ul> |
| 6    | If any of the above tests fail, replace the DC Controller.                                                                                                                                                                                                                                                                      |

### 8.0.5. Burner Fuel solenoid Testing

**Table 8-10 Burner Fuel Solenoid Testing**

| Step | Fuel Solenoid Test                                                                                           |
|------|--------------------------------------------------------------------------------------------------------------|
| 1    | Remove cord set from fuel solenoid.                                                                          |
| 2    | Check the ohms between the terminals of fuel solenoid.                                                       |
| 3    | If the reading is between 15-25 ohms the coil is good.                                                       |
| 4    | If the reading is outside the above range or the meter indicates an open circuit, replace the fuel solenoid. |

## Chapter 8 Troubleshooting

### 8.0.6. Burner Ignition Coil Testing

**Table 8-11 Burner Ignition Coil Test**


| Step | Ignition Coil Test                                                                                                                                                                                                                                                                     |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Make sure the burner is off. Open the ignition transformer (located above the blower) to expose the springs.                                                                                                                                                                           |
| 2    | Check resistance between each of the springs and the ground (exposed metal on the burner).                                                                                                                                                                                             |
| 3    | The meter should read less than 2000 ohms. (Take note of the readings, you will use them in Step 5.)                                                                                                                                                                                   |
| 4    | Check resistance between both springs. (Take note of the reading, you will use it in Step 5.)                                                                                                                                                                                          |
| 5    | The igniter should be replaced if: <ul style="list-style-type: none"> <li>• The difference between the two springs to ground resistance readings is greater than 20%.</li> <li>• Or the spring-to-spring resistance does not read approximately twice the spring to ground.</li> </ul> |

### 8.0.7. Bleeding the Burner

**Table 8-12 Bleeding the Burner**


| Step | Bleeding the Diesel Burner                                                                                                                                                                                                                                                         |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Place an oil pan under the machine in front of the burner.                                                                                                                                                                                                                         |
| 2    | Using a 3/8" wrench, loosen the bleeder valve on the fuel pump refer to <a href="#">Fig. 8.3 Diesel Burner Air Settings</a> for bleeder location.                                                                                                                                  |
| 3    | Turn the ignition key to the "ON" position, then turn the power toggle switch to the "ON" position. Fuel should flow out of the bleeder valve. You want the fuel to be clear from any air bubbles, this may require you to turn the ignition key "OFF" and "ON" a couple of times. |
| 4    | Allow burner to cycle itself off 30 seconds.                                                                                                                                                                                                                                       |
| 5    | Tighten the bleeder valve.                                                                                                                                                                                                                                                         |

**Chapter 8 Troubleshooting**



**Fig. 8.2 Diesel Burner Electrode Adjustment**

Air Shutter = 8  
Air Band = 0  
Fuel Pressure = 140 PSI  
Adjustment Plate = 3



**Fig. 8.3 Diesel Burner Air Settings**

## Chapter 8 Troubleshooting

### 8.1 Sealant Heating Slowly

**Table 8-13 Sealant is Heating Slowly**

| Step | Sealant is Heating Slowly                                                                                                                                                                                                                                                                                                                                                                              |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | With the material level half or less, open the loading lid and inspect the inside edge of the material tank. Check if there is a buildup of old, dried out and hardened material along the top half of the material tank.                                                                                                                                                                              |
| 2    | If this is the case you will need to drain out (use up) the rest of the material inside the tank. When the tank is empty, use an air chisel to remove this built up material. Remove as much as possible all around the tank including the roof of the material tank. Remove all the old sealant chunks from the bottom of the material tank. This should be done every year or as conditions require. |
| 3    | Check your level of the heat transfer oil, the mark on the dipstick is for 70°F.                                                                                                                                                                                                                                                                                                                       |
| 4    | Check your records of the last service replacement of the heat transfer oil. If it has been longer than 500 hours, or one year, you need to change your oil.                                                                                                                                                                                                                                           |
| 5    | Many of Crafco, Inc. service centers can perform these service steps for you if you cannot. Call your local service center to find out if they can.                                                                                                                                                                                                                                                    |

## Chapter 8 Troubleshooting

### 8.2 Agitator Troubleshooting

#### 8.2.1 Symptom: Mixer Does Not Rotate

**Table 8-14 Basic Visual Mixer Troubleshooting**

| Step | Possible Cause                                                                                                                                                    | If . . .                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is the Material Temperature Display at or above 275°F?                                                                                                            | <ul style="list-style-type: none"> <li>• Yes, go to Step 2.</li> <li>• No, continue to allow the machine to heat. (Make sure the Material dial and the Hot Oil dial are set at operating temperatures.)</li> </ul>                                                                                                                                                                                                                         |
| 2    | Is the red "Mixer" light "ON"?                                                                                                                                    | <ul style="list-style-type: none"> <li>• Yes, go to Step 4.</li> <li>No, go to <a href="#">Table 8-15 Mixer Electrical Troubleshooting</a></li> </ul>                                                                                                                                                                                                                                                                                      |
| 3    | Is the loading door closed?                                                                                                                                       | <ul style="list-style-type: none"> <li>• Yes, go to Step 4.</li> <li>• No, shut the loading door.</li> </ul>                                                                                                                                                                                                                                                                                                                               |
| 4    | Is the "Mixer" toggle switch in the "Forward" position?                                                                                                           | <ul style="list-style-type: none"> <li>• Yes, go to Step 5.</li> <li>• No, move the toggle switch to the forward position.</li> </ul>                                                                                                                                                                                                                                                                                                      |
| 5    | Move the "Mixer" toggle switch to the "Reverse" position.<br>Is the agitator moving?                                                                              | <ul style="list-style-type: none"> <li>• Yes, allow mixer to reverse for 15 seconds and then move the "Mixer" toggle switch to the "Forward" position. Go to Step 6.</li> <li>No, go to <a href="#">Table 8-15 Mixer Electrical Troubleshooting</a></li> </ul>                                                                                                                                                                             |
| 6    | Open the Material loading door. Are there several unmelted blocks in the tank?                                                                                    | <ul style="list-style-type: none"> <li>• Yes, this may cause the agitator to jam. Use the mixer toggle switch to move the agitator forward and backward until the material melts enough to allow forward movement without jamming. Crafco, Inc. recommends you add one to two blocks every three to four minutes during dispensing of product.</li> <li>• No, go to <a href="#">Table 8-15 Mixer Electrical Troubleshooting</a></li> </ul> |
| 7    | Is the hydraulic fluid level near the center of the sight gauge? Check at ambient temperature. See <a href="#">Fig. 5.1 Hydraulic Fluid Level and Temp. Gauge</a> | <ul style="list-style-type: none"> <li>Yes, go to <a href="#">Table 8-15 Mixer Electrical Troubleshooting</a></li> <li>• No, fill oil to the center of the sight gauge.</li> </ul>                                                                                                                                                                                                                                                         |

## Chapter 8 Troubleshooting

**Note:** Use [Fig. 8.5 Mixer Circuit](#) while troubleshooting the mixer electrical system.

**Table 8-15 Mixer Electrical Troubleshooting**

| Step | Possible Cause                                                                                                                                                                                                      | If . . .                                                                                                                                                                                                                                                                                                                                                                                                          |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is the amber light "ON" on the Din Plug when the "Mixer" toggle switch is in the "Forward" position? (For forward din plug location. Refer to <a href="#">Fig. 8.7 Din Plug Layout</a> ).                           | <ul style="list-style-type: none"> <li>• Yes, then the mixer should be working. If it is not working see <a href="#">Table 8-18 Mixer Hydraulic Troubleshooting</a></li> <li>• No, go to step 1a.</li> </ul>                                                                                                                                                                                                      |
| 1a   | Unscrew the din plug center screw so you can pull the din plug up about 1/4" in order to check for voltage.<br>Is there 12Vdc from side post to side post?                                                          | <ul style="list-style-type: none"> <li>• Yes, the electrical system for the agitator is working properly, go to <a href="#">Table 8-18 Mixer Hydraulic Troubleshooting</a>. Also replace din plug at earliest convenience to retain visual troubleshooting ability.</li> <li>• No, go to step 2.</li> </ul>                                                                                                       |
| 2    | Is there 12Vdc between the "Mixer" toggle switch bottom post brown wire and nearby ground wire (black wire)? (With the "Mixer" toggle switch in the "Forward" position.) See <a href="#">Fig. 8.5 Mixer Circuit</a> | <ul style="list-style-type: none"> <li>• Yes, replace din plug.</li> <li>• No, go to Step 2a.</li> </ul>                                                                                                                                                                                                                                                                                                          |
| 2a   | Is there 12Vdc between the "Mixer" toggle switch center post red wire and nearby ground source (black wire)?                                                                                                        | <ul style="list-style-type: none"> <li>• Yes, replace mixer toggle switch</li> <li>• No, go to step 2b.</li> </ul>                                                                                                                                                                                                                                                                                                |
| 2b   | Is there 12Vdc at the lower terminal block red wire labeled Red-8 and Red Lid P.S.?                                                                                                                                 | <p>Yes to both then check for loose connections or broken wires between terminal block and mixer switch.</p> <p>Yes to Red Lid P.S. and No to Red-8 replace terminal block.</p> <p>No, go to step 3.</p>                                                                                                                                                                                                          |
| 3    | Is there 12Vdc between the P.S. lid switch red wires and a nearby ground source?<br>(Check both red wires on the bottom of the lid switch with the lid closed.)                                                     | <ul style="list-style-type: none"> <li>• Yes, on both red wires check for loose connections or broken wires between lid switch and terminal block.</li> <li>• Yes, on only one red wire when the lid is closed. Readjust the lid switch so that the lid completely depresses the switch, and then recheck for 12Vdc. If the same result happens, replace the lid switch.</li> <li>• No, go to step 3a.</li> </ul> |

## Chapter 8 Troubleshooting

**Table 8-16 Mixer Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                                                                  | If . . .                                                                                                                                                                                                                                                                                                                                                                                                               |
|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3a   | Is there 12Vdc between the D.S. lid switch red wires and a nearby ground source?<br>(Check both red wires on the bottom of the lid switch with the lid closed.) | <ul style="list-style-type: none"> <li>• Yes, on both red wires check for loose connections or broken wires between D.S. lid switch and P.S. lid switch.</li> <li>• Yes, on only one red wire when the lid is closed. Readjust the lid switch so that the lid completely depresses the switch, and then recheck for 12Vdc. If the same result happens, replace the lid switch.</li> <li>• No, go to step 4.</li> </ul> |
| 4    | Check for 12Vdc at red wire labeled Red Lid D.S. and pink wire labeled Pink-2 on terminal block and a nearby ground source (black wire).                        | <ul style="list-style-type: none"> <li>• Yes on both, check for loose connections or broken wires between D.S. lid switch and terminal block.</li> <li>• No on Red Lid D.S. and Yes on Pink-2, ensure yellow jumper bar is securely installed between the two terminal blocks.</li> <li>• No, go to step 4a.</li> </ul>                                                                                                |
| 4a   | Is there 12Vdc between the Material PAKSTAT terminal #2 pink wire and terminal #8 black ground wire?<br>(Refer to <a href="#">Fig. 8.5 Mixer Circuit.</a> )     | <ul style="list-style-type: none"> <li>• Yes, check for loose connections or broken wires between PAKSTAT terminal #2 and terminal block.</li> <li>• No, go to Step 4b</li> </ul>                                                                                                                                                                                                                                      |
| 4b   | Is there 12Vdc between the Material PAKSTAT terminal #1 orange wire and terminal #8 black ground wire?                                                          | <ul style="list-style-type: none"> <li>• Yes, replace the Material PAKSTAT.</li> <li>• No, go to Step 4c.</li> </ul>                                                                                                                                                                                                                                                                                                   |
| 4c   | Is there 12Vdc between orange wire labeled ORN-1, terminal #9 and terminal #8 ground source (black wire)?                                                       | <ul style="list-style-type: none"> <li>• Yes, check for loose connections or broken wires between terminals #8 and #1.</li> <li>• No, go to step 5.</li> </ul>                                                                                                                                                                                                                                                         |
| 5    | Is there 12Vdc at orange wire labeled ORN-1 and ORN-2 on the upper terminal block?                                                                              | <ul style="list-style-type: none"> <li>• Yes on both, check for loose connections or broken wires between terminal block and material PAKSTAT.</li> <li>• Yes on ORN-2 and No on ORN-1 replace terminal block.</li> <li>• No on both, go to step 6.</li> </ul>                                                                                                                                                         |
| 6    | Is there 12Vdc between orange wire labeled ORN-2 terminal #3 and terminal #5 black ground of hot oil PAKSTAT?                                                   | <ul style="list-style-type: none"> <li>• Yes, check for loose connections or broken wires between terminal #3 and terminal block.</li> <li>• No, go to step 7.</li> </ul>                                                                                                                                                                                                                                              |

## Chapter 8 Troubleshooting

**Table 8-17 Mixer Electrical Troubleshooting (continued)**


| Step | Possible Cause                                                                                                              | If . . .                                                                                                                                                                                  |
|------|-----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7    | Is there 12Vdc between top terminal of the power switch and a nearby ground (black wire)?                                   | <ul style="list-style-type: none"> <li>• Yes, check for loose connections or broken wires between toggle switch and hot oil PAKSTAT terminal #3.</li> <li>• No, go to step 7a.</li> </ul> |
| 7a   | Is there 12Vdc between bottom terminal wire labeled RED-3 and a nearby ground source (black wire)?                          | <ul style="list-style-type: none"> <li>• Yes, replace toggle switch.</li> <li>• No, go to step 8.</li> </ul>                                                                              |
| 8    | Is there 12Vdc between the top terminal of circuit breaker red wire labeled RED-3 and nearby ground source (black wire)?    | <ul style="list-style-type: none"> <li>• Yes, check for loose connections or broken wires between circuit breaker and toggle switch.</li> <li>• No, go to step 8a.</li> </ul>             |
| 8a   | Is there 12Vdc between the bottom terminal of circuit breaker red wire labeled RED-2 and nearby ground source (black wire)? | <ul style="list-style-type: none"> <li>• Yes, replace circuit breaker.</li> <li>• No, go to step 9.</li> </ul>                                                                            |
| 9    | Is there 12Vdc between ignition switch “ACC” terminal and nearby ground source (black wire)?                                | <ul style="list-style-type: none"> <li>• Yes, check for loose connections or broken wires between “ACC” terminal and circuit breaker.</li> <li>• No, go to Step 9a.</li> </ul>            |
| 9a   | Is there 12Vdc between “B” (blue wire) of ignition switch and nearby ground source (black wire)?                            | <ul style="list-style-type: none"> <li>• Yes, replace ignition switch.</li> <li>• No, go to Step 10.</li> </ul>                                                                           |
| 10   | Is there 12Vdc between blue wire on starter solenoid and nearby ground source (black wire or bare metal on engine case)?    | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between starter solenoid and ignition switch.</li> <li>• No, go to step 10a.</li> </ul>                      |
| 10a  | Check connections and condition of red battery cable?                                                                       | <ul style="list-style-type: none"> <li>• Yes, there should be 12Vdc at all previous steps.</li> <li>• No, replace battery cable.</li> </ul>                                               |

## Chapter 8 Troubleshooting



**Fig. 8.4 Checking Din Plug Voltage**

## Chapter 8 Troubleshooting



**Fig. 8.5 Mixer Circuit**


## Chapter 8 Troubleshooting

### 8.2.2 Mixer Hydraulic Troubleshooting

**Table 8-18 Mixer Hydraulic Troubleshooting**


| Step | Possible Cause                                                                                                                                                                                                                                                                                                                   | If . . .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Remove the din plug, then remove the coil by unscrewing the nut on top of the coil. With the coil removed, re-attach the din plug and energize the coil by moving the mixer switch to Forward or Reverse, then insert a screw driver into the center of the coil. Does the coil magnetize when the din plug amber light is "ON"? | <ul style="list-style-type: none"> <li>• Yes, go to Step 2.</li> <li>• No, replace the coil.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 2    | Is the relief pressure set correctly?<br><br>(Refer to <a href="#">Fig. 8.6 Hydraulic Valve Pressure Setting</a> , for pressure settings.)                                                                                                                                                                                       | <ul style="list-style-type: none"> <li>• Yes, go to Step 3.</li> <li>• No, first turn "OFF" the Isuzu engine, then remove one of the two hydraulic hoses going to the agitator hydraulic motor, cap off the fitting on the motor and use a 3,000 PSI gauge with the proper JIC fitting, attach it to the hose. Start the Isuzu engine, turn "ON" the main power in the control box, move the "Mixer" toggle switch to the "Forward" position and read the pressure gauge. If the pressure needs to be adjusted use the pressure relief valve labeled "RVA", loosen the jam nut and adjust the pressure with the allen screw at the end of the relief. Turn clockwise to increase pressure and counter clockwise to decrease pressure, then tighten the jam nut to lock the pressure. Next turn "OFF" the Isuzu engine, remove the cap and pressure gauge, then re-attach the hose.</li> </ul> |
| 3    | Is the hydraulic flow 1.5 GPM from the hydraulic valve? If you do not have a flow meter, call a local hydraulic shop to run the test for you.                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Yes, call Crafco, Inc. and speak to a customer service technician, you should have been able to find the problem.</li> <li>• No, replace the flow divider in the hydraulic valve.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 4    | Is the hydraulic flow correct from the hydraulic pump? If you do not have a flow meter, call a local hydraulic shop to run the test for you. (Refer <a href="#">Fig. 8.6 Hydraulic Valve Pressure Setting</a> for flow rate).                                                                                                    | <ul style="list-style-type: none"> <li>• Yes, call Crafco, Inc. and speak to a customer service technician, you should have been able to find the problem.</li> <li>• No, replace the hydraulic pump.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

**Chapter 8 Troubleshooting**



**Fig. 8.6 Hydraulic Valve Pressure Setting**

**Chapter 8 Troubleshooting**



**Fig. 8.7 Din Plug Layout**

## Chapter 8 Troubleshooting

### 8.3 Hose Troubleshooting

#### 8.3.1 Symptom: Hose Does Not Heat

**Table 8-19 Basic Visual Troubleshooting**

| Step | Possible Cause                                         | If . . .                                                                                                                                                                                                           |
|------|--------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is the Material Temperature Display at or above 275°F? | <ul style="list-style-type: none"> <li>• Yes, go to Step 2.</li> <li>• No, continue to allow the machine to heat. (Make sure the Material dial and the Hot Oil dial are set at operating temperatures.)</li> </ul> |
| 2    | Is the red "HEATED HOSE" light "ON"?                   | <ul style="list-style-type: none"> <li>• Yes, go to <a href="#">Table 8-20 Electrical Troubleshooting</a></li> <li>• No, allow the machine to heat material to 275°F.</li> </ul>                                   |
| 2a   | Is the circuit breaker tripped?                        | <ul style="list-style-type: none"> <li>• Yes, reset the circuit breaker by pushing in the button which has popped out.</li> <li>• No, go to <a href="#">Table 8-20 Electrical Troubleshooting</a></li> </ul>       |

**NOTE:** Use [Fig. 8.9 Hose Circuit Schematic](#) while troubleshooting the hose electrical system.

**Table 8-20 Electrical Troubleshooting**

| Step | Possible Cause                                                                                                                                                                                                                     | If . . .                                                                                                                                                                                                       |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is there 12Vdc between "BATT" terminal of the generator and a nearby ground source (lug on battery tray)?                                                                                                                          | <ul style="list-style-type: none"> <li>• Yes, go to Step 2.</li> <li>• No, go to Step 6.</li> </ul>                                                                                                            |
| 2    | Is there 24Vac between the white, green, and black wires?<br><b>NOTE:</b> Do this test inside the junction box. Check between black and white, black and green, and green and white.                                               | <ul style="list-style-type: none"> <li>• Yes, go to Step 3</li> <li>• No, stop the engine, tighten the belt, restart engine and recheck output voltage.</li> <li>• Still no, replace the generator.</li> </ul> |
| 2a   | Check the three heating element wires (blue) in the junction box for 30 Amps cold or 20-22 Amps hot.<br><b>NOTE:</b> Always use a clamp-on amp meter to perform this test. Each wire should have the same amp reading (+/- 1 amp). | <ul style="list-style-type: none"> <li>• Yes, the hose should be working properly.</li> <li>• No, go to Step 3.</li> </ul>                                                                                     |

## Chapter 8 Troubleshooting


**Table 8-21 Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                                                                                                                                                                                                                                                                                                                                                          | If . . .                                                                                                                                                                                                                                                                                                                           |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3    | Check for continuity in the hose from end to end. Disconnect the three blue heating element wires (blue) from the terminal block inside the junction box and disconnect the five pin plug between the hose and wand. Refer to <a href="#">Fig. 8.9 Hose Circuit Schematic</a> .<br><b>NOTE:</b> Check each letter “D”, “E”, and “A” with the three blue wires on the other end of the hose. There should only be continuity on one wire to each letter. | <ul style="list-style-type: none"> <li>• Yes, go to Step 3a.</li> <li>• No, either there was no continuity from one letter to the other end of the hose or there was more than one wire with continuity to a letter. This hose needs to be repaired or replaced. Contact CrafcO, Inc. to send back the hose for repair.</li> </ul> |
| 3a   | Check the RTD sensor in the hose against the readout in the control box. Disconnect the black and white wires from the terminal block in the junction box and test for ohms. Refer to <a href="#">Table 8-24 RTD Sensor Ohms vs. Temperature</a> .                                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>• Yes, the readout matches the table, go to Step 4.</li> <li>• No, this hose needs to be repaired or replaced. Contact CrafcO, Inc. to send back the hose for repair.</li> </ul>                                                                                                            |
| 4    | Check for continuity in the wand between “D”, “E”, and “A”.<br><b>NOTE:</b> Check between “D” and “E”, “D” and “A”, and “A” and “E”.                                                                                                                                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Yes, go to Step 5.</li> <li>• No, this wand needs to be repaired or replaced. Contact CrafcO, Inc. to send back the wand for repair.</li> </ul>                                                                                                                                           |
| 5    | Is there 12Vdc between wire labeled “BLU-GEN” on the upper terminal block and nearby ground source (black wire)?                                                                                                                                                                                                                                                                                                                                        | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken connections between terminal block “BATT” terminal of generator.</li> <li>• No, go to Step 6.</li> </ul>                                                                                                                                                   |
| 6    | Is there 12Vdc between Hose PAKSTAT blue wire terminal #4 and black wire terminal #8?                                                                                                                                                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal #4 and the terminal block.</li> <li>• No, go to Step 6a.</li> </ul>                                                                                                                                                                  |
| 6a   | Is there 12Vdc between Hose PAKSTAT terminal #3 Pink wire and terminal #8 black wire?                                                                                                                                                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>• Yes, replace hose PAKSTAT.</li> <li>• No, go to Step 6b.</li> </ul>                                                                                                                                                                                                                       |
| 6b   | Is there 12Vdc between Hose PAKSTAT pink wire terminal #1 and black wire terminal #8?                                                                                                                                                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between terminal #1 and terminal #3.</li> <li>• No, go to Step 7.</li> </ul>                                                                                                                                                                         |
| 7    | Is there 12Vdc between pink wire labeled “PNK-1 on the upper terminal block and a nearby ground source (black wire)?                                                                                                                                                                                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal block and terminal #1.</li> <li>• No go to Step 7.</li> </ul>                                                                                                                                                                        |
| 7a   | Is there 12Vdc between pink wire labeled “PNK-4 and nearby ground source (black wire)?                                                                                                                                                                                                                                                                                                                                                                  | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to Step 8.</li> </ul>                                                                                                                                                                                                                      |

## Chapter 8 Troubleshooting


**Table 8-22 Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                                        | If . . .                                                                                                                                                                                            |
|------|---------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 8    | Is there 12Vdc between the Hose Selector switch pink wire labeled "PNK-4 (bottom left terminal) and a near" ground source black wire? | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wires between switch and upper terminal block.</li> <li>• No, go to Step 8a.</li> </ul>                                     |
| 8a   | Is there 12Vdc between the Hose Selector switch pink wire Labeled "PNK-3" center left terminal and a nearby ground source.            | <ul style="list-style-type: none"> <li>• Yes, replace Hose Selector switch.</li> <li>• No, go to Step 9.</li> </ul>                                                                                 |
| 9    | Is there 12Vdc between pink wire labeled "PNK-3" on the upper terminal block and a nearby ground source black wire?                   | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal block and hose selector switch.</li> <li>• No go to Step 9a.</li> </ul>                               |
| 9a   | Is there 12Vdc between pink wire labeled "PNK-2" on upper terminal block and nearby ground source black wire?                         | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to <a href="#">Table 8-16 Mixer Electrical Troubleshooting (continued)</a> Steps 4a through 10a.</li> </ul> |




**Fig. 8.8 Junction Box Voltage Testing**

## Chapter 8 Troubleshooting




**Fig. 8.9 Hose Circuit Schematic**

## Chapter 8 Troubleshooting



KETTLE END



WAND END

**Fig. 8.10 Junction Box Wiring**

## Chapter 8 Troubleshooting

### 8.3.2 Symptom: Trigger is not Working

**Table 8-23 Trigger is not Working**

| Step | Possible Cause                                                                                                                                                                                                   | If . . .                                                                                                                                                                                                                                                                      |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | <p>Check continuity between two red wires coming from the hose in junction box.</p> <p><b>NOTE:</b> These wires must be disconnected from the terminal block and the trigger depressed to perform this test.</p> | <ul style="list-style-type: none"> <li>• Yes, go to <a href="#">Table 8-26 Basic Visual Pump Troubleshooting</a></li> <li>• No, go to Step 2.</li> </ul>                                                                                                                      |
| 2    | <p>Disconnect the electrical connector between the hose and wand, check for continuity between C and B wand side.</p>                                                                                            | <ul style="list-style-type: none"> <li>• Yes, this hose needs to be repaired or replaced. Contact Crafco, Inc. to send back the hose for repair.</li> <li>• No, this wand needs to be repaired or replaced. Contact Crafco, Inc. to send back the hose for repair.</li> </ul> |

## Chapter 8 Troubleshooting

### 8.3.3 RTD Sensor Ohms vs. Temperature

Table 8-23 below shows what the ohm reading would be for a given temperature. The following are the instructions for using the table.

Measure the resistance (ohms) of the sensor in question with an ohm meter (See [7.3 Checking Resistance \(Ohms\)](#)) in Section [7.0 How to Use a Multimeter](#).

Find the reading in the chart (columns 0 through 9).

Follow the row to the left and get the temperature in 10°F increments, then follow the column up to get the 1°F increment. (For example, 1391 Ohms = 215°F)

**Table 8-24 RTD Sensor Ohms vs. Temperature**

| °F  | 0      | 1      | 2      | 3      | 4      | 5      | 6      | 7      | 8      | 9      |
|-----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| 0   | 930.3  | 932.5  | 934.7  | 936.9  | 939.1  | 941.3  | 943.4  | 945.6  | 947.8  | 950.0  |
| 10  | 952.2  | 954.3  | 956.5  | 958.7  | 960.9  | 963.0  | 965.2  | 967.4  | 969.6  | 971.8  |
| 20  | 973.9  | 976.1  | 978.3  | 980.5  | 982.6  | 984.8  | 987.0  | 989.1  | 991.3  | 993.5  |
| 30  | 995.7  | 997.8  | 1000.0 | 1002.2 | 1004.3 | 1006.5 | 1008.7 | 1010.9 | 1013.0 | 1015.2 |
| 40  | 1017.4 | 1019.5 | 1021.7 | 1023.9 | 1026.0 | 1028.2 | 1030.4 | 1032.5 | 1034.7 | 1036.9 |
| 50  | 1039.0 | 1041.2 | 1043.4 | 1045.5 | 1047.7 | 1049.8 | 1052.0 | 1054.2 | 1056.3 | 1058.5 |
| 60  | 1060.7 | 1062.8 | 1065.0 | 1067.1 | 1069.3 | 1071.5 | 1073.6 | 1075.8 | 1077.9 | 1080.1 |
| 70  | 1082.2 | 1084.4 | 1086.6 | 1088.7 | 1090.9 | 1093.0 | 1095.2 | 1097.3 | 1099.5 | 1101.6 |
| 80  | 1103.8 | 1106.0 | 1108.1 | 1110.3 | 1112.4 | 1114.6 | 1116.7 | 1118.9 | 1121.0 | 1123.2 |
| 90  | 1125.3 | 1127.5 | 1129.6 | 1131.8 | 1133.9 | 1136.1 | 1138.2 | 1140.4 | 1142.5 | 1144.7 |
| 100 | 1146.8 | 1149.0 | 1151.1 | 1153.2 | 1155.4 | 1157.5 | 1159.7 | 1161.8 | 1164.0 | 1166.1 |
| 110 | 1168.3 | 1170.4 | 1172.5 | 1174.7 | 1176.9 | 1179.0 | 1181.1 | 1183.3 | 1185.4 | 1187.5 |
| 120 | 1189.7 | 1191.8 | 1194.0 | 1196.1 | 1198.2 | 1200.4 | 1202.5 | 1204.6 | 1206.8 | 1208.9 |
| 130 | 1211.0 | 1213.2 | 1215.3 | 1217.5 | 1219.6 | 1221.7 | 1223.9 | 1226.0 | 1228.1 | 1230.3 |
| 140 | 1232.4 | 1234.5 | 1236.7 | 1238.9 | 1240.9 | 1243.0 | 1245.2 | 1247.3 | 1249.4 | 1251.6 |
| 150 | 1253.7 | 1255.8 | 1258.0 | 1260.1 | 1262.2 | 1264.3 | 1266.5 | 1268.6 | 1270.7 | 1272.8 |
| 160 | 1275.0 | 1277.1 | 1279.2 | 1281.3 | 1283.5 | 1285.6 | 1287.7 | 1289.8 | 1292.0 | 1294.1 |
| 170 | 1296.2 | 1298.3 | 1300.4 | 1302.6 | 1304.7 | 1306.8 | 1308.9 | 1311.0 | 1313.2 | 1315.3 |
| 180 | 1317.4 | 1319.5 | 1321.6 | 1323.8 | 1325.9 | 1328.0 | 1330.1 | 1332.2 | 1334.3 | 1336.5 |
| 190 | 1338.6 | 1340.7 | 1342.8 | 1344.9 | 1347.0 | 1349.1 | 1351.2 | 1353.4 | 1355.5 | 1357.6 |
| 200 | 1359.7 | 1361.8 | 1363.9 | 1366.0 | 1368.1 | 1370.2 | 1372.4 | 1374.5 | 1376.6 | 1378.7 |
| 210 | 1380.8 | 1382.9 | 1385.0 | 1387.1 | 1389.2 | 1391.3 | 1393.4 | 1395.5 | 1397.6 | 1399.7 |
| 220 | 1401.8 | 1403.9 | 1406.0 | 1408.1 | 1410.3 | 1412.4 | 1414.5 | 1416.6 | 1418.7 | 1420.8 |
| 230 | 1422.9 | 1425.0 | 1427.1 | 1429.2 | 1431.3 | 1433.4 | 1435.5 | 1437.6 | 1439.6 | 1441.7 |
| 240 | 1443.8 | 1445.9 | 1448.0 | 1450.1 | 1452.2 | 1454.3 | 1456.4 | 1458.5 | 1460.6 | 1462.7 |
| 250 | 1464.8 | 1466.9 | 1469.0 | 1471.1 | 1473.2 | 1475.3 | 1477.3 | 1479.4 | 1481.5 | 1483.6 |
| 260 | 1485.7 | 1487.8 | 1489.9 | 1492.0 | 1494.1 | 1496.1 | 1498.2 | 1500.3 | 1502.4 | 1504.5 |

## Chapter 8 Troubleshooting

**Table 8-25 RTD Sensor Ohms vs. Temperature (continued)**

| °F  | 0      | 1      | 2      | 3      | 4      | 5      | 6      | 7      | 8      | 9      |
|-----|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
| 270 | 1506.6 | 1508.7 | 1510.8 | 1512.8 | 1514.9 | 1517.0 | 1519.1 | 1521.2 | 1523.3 | 1525.3 |
| 280 | 1527.4 | 1529.5 | 1531.6 | 1533.7 | 1535.7 | 1537.8 | 1539.9 | 1542.0 | 1544.1 | 1546.1 |
| 290 | 1548.2 | 1550.3 | 1552.4 | 1554.5 | 1556.5 | 1558.6 | 1560.7 | 1562.8 | 1564.8 | 1566.9 |
| 300 | 1569.0 | 1571.1 | 1573.1 | 1575.2 | 1577.3 | 1579.4 | 1581.4 | 1583.5 | 1585.6 | 1587.7 |
| 310 | 1589.7 | 1591.8 | 1593.9 | 1595.9 | 1598.0 | 1600.1 | 1602.2 | 1604.2 | 1606.3 | 1608.4 |
| 320 | 1610.4 | 1612.5 | 1614.6 | 1616.6 | 1618.7 | 1620.8 | 1622.8 | 1624.9 | 1627.0 | 1629.0 |
| 330 | 1631.1 | 1633.2 | 1635.2 | 1637.3 | 1639.3 | 1641.4 | 1643.5 | 1645.5 | 1647.6 | 1649.7 |
| 340 | 1651.7 | 1653.8 | 1655.8 | 1657.9 | 1660.0 | 1662.0 | 1664.1 | 1666.1 | 1668.2 | 1670.2 |
| 350 | 1672.3 | 1674.4 | 1676.4 | 1678.5 | 1680.5 | 1682.6 | 1684.6 | 1686.7 | 1688.7 | 1690.8 |
| 360 | 1692.9 | 1694.9 | 1697.0 | 1699.0 | 1701.1 | 1703.1 | 1705.2 | 1707.2 | 1709.3 | 1711.3 |
| 370 | 1713.4 | 1715.4 | 1717.5 | 1719.5 | 1721.6 | 1723.6 | 1725.7 | 1727.7 | 1729.8 | 1731.8 |
| 380 | 1733.9 | 1735.9 | 1737.9 | 1740.0 | 1742.0 | 1744.1 | 1746.1 | 1748.2 | 1750.2 | 1752.3 |
| 390 | 1754.3 | 1756.3 | 1758.4 | 1760.4 | 1762.5 | 1764.5 | 1766.6 | 1768.6 | 1770.6 | 1772.7 |
| 400 | 1774.7 | 1776.8 | 1778.8 | 1780.8 | 1782.9 | 1784.9 | 1786.9 | 1789.0 | 1791.0 | 1793.1 |
| 410 | 1795.1 | 1797.1 | 1799.2 | 1801.2 | 1803.2 | 1805.3 | 1807.3 | 1809.3 | 1811.4 | 1813.4 |
| 420 | 1815.4 | 1817.5 | 1819.5 | 1821.5 | 1823.6 | 1825.6 | 1827.6 | 1829.6 | 1831.7 | 1833.7 |
| 430 | 1835.7 | 1837.8 | 1839.8 | 1841.8 | 1843.8 | 1845.9 | 1847.9 | 1849.9 | 1851.9 | 1854.0 |
| 440 | 1856.0 | 1858.0 | 1860.0 | 1862.1 | 1864.1 | 1866.1 | 1868.1 | 1870.2 | 1872.2 | 1874.2 |
| 450 | 1876.2 | 1878.2 | 1880.3 | 1882.3 | 1884.3 | 1886.3 | 1888.3 | 1890.4 | 1892.4 | 1894.4 |
| 460 | 1896.4 | 1898.4 | 1900.5 | 1902.5 | 1904.5 | 1906.5 | 1908.5 | 1910.5 | 1912.6 | 1914.6 |
| 470 | 1916.6 | 1918.6 | 1920.6 | 1922.6 | 1924.6 | 1926.6 | 1928.7 | 1930.7 | 1932.7 | 1934.7 |
| 480 | 1936.7 | 1938.7 | 1940.7 | 1942.7 | 1944.7 | 1946.8 | 1948.8 | 1950.8 | 1952.8 | 1954.8 |
| 490 | 1956.8 | 1958.8 | 1960.8 | 1962.8 | 1964.8 | 1966.8 | 1968.8 | 1970.8 | 1972.8 | 1974.8 |
| 500 | 1976.8 | 1978.8 | 1980.8 | 1982.9 | 1984.9 | 1986.9 | 1988.9 | 1990.9 | 1992.9 | 1994.9 |
| 510 | 1996.9 | 1998.9 | 2000.9 | 2002.9 | 2004.9 | 2006.9 | 2008.8 | 2010.8 | 2012.8 | 2014.8 |
| 520 | 2016.8 | 2018.8 | 2020.8 | 2022.8 | 2024.8 | 2026.8 | 2028.8 | 2030.8 | 2032.8 | 2034.8 |
| 530 | 2036.8 | 2038.8 | 2040.8 | 2042.8 | 2044.7 | 2046.7 | 2048.7 | 2050.7 | 2052.7 | 2054.7 |
| 540 | 2056.7 | 2058.7 | 2060.7 | 2062.7 | 2064.6 | 2066.6 | 2068.6 | 2070.6 | 2072.6 | 2074.6 |
| 550 | 2076.6 | 2078.5 | 2080.5 | 2082.5 | 2084.5 | 2086.5 | 2088.5 | 2090.4 | 2092.4 | 2094.4 |

## Chapter 8 Troubleshooting

### 8.4 Pump Troubleshooting

#### 8.4.1 Symptom: Material Does Not Dispense When the Pump is Activated

**Table 8-26 Basic Visual Pump Troubleshooting**

| Step | Possible Cause                                                                                                                                                                                                                                                                            | If . . .                                                                                                                                                                                                                                                                                                                              |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is the Hose Temperature Display at or above 325°F?                                                                                                                                                                                                                                        | <ul style="list-style-type: none"> <li>• Yes, go to Step 2.</li> <li>• No, continue to allow the hose to heat. (Make sure the Hose dial is set at proper operating temperature.)</li> </ul>                                                                                                                                           |
| 2    | Is the red "Pump" light "ON"?                                                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>• Yes, go to Step 3.</li> <li>• No, go to <a href="#">Table 8-27 Pump Electrical Troubleshooting</a>.</li> </ul>                                                                                                                                                                               |
| 3    | Is the hose selector switch in the "ELECTRIC" position as well as the pump switch should be in "ON ELECTRIC" position?                                                                                                                                                                    | <ul style="list-style-type: none"> <li>• Yes, go to Step 4.</li> <li>• No, move the toggle switches to the proper positions.</li> </ul>                                                                                                                                                                                               |
| 4    | With the wand in the shoebox, pull the wand trigger and look at the material pump shaft coupler.<br>Is it spinning clockwise?                                                                                                                                                             | <ul style="list-style-type: none"> <li>• Yes, shut down machine and look for a plug in the plumbing.</li> <li>• No, adjust the material flow control to increase the flow.</li> <li>• Still no, go to Step 5.</li> </ul>                                                                                                              |
| 5    | Inside the control box and under the front panel, find the relay cube for the pump. It is found near the middle, left-hand side of the box. It is a clear yellow cube with a green button facing the top of the control box. When the trigger is engaged does the green light illuminate? | <ul style="list-style-type: none"> <li>• Yes, this indicates that 12Vdc is reaching the relay coil. Go to <a href="#">Table 8-28 Pump Electrical Troubleshooting (continued)</a> Step 5 to find the problem.</li> <li>• No, go to <a href="#">Table 8-27 Pump Electrical Troubleshooting</a>, Steps 2 to find the problem.</li> </ul> |
| 6    | Is the hydraulic fluid level near the center of the sight gauge when the machine is cold?<br>See <a href="#">Fig. 5.1 Hydraulic Fluid Level and Temp. Gauge</a>                                                                                                                           | <ul style="list-style-type: none"> <li>• Yes, go to <a href="#">Table 8-27 Pump Electrical Troubleshooting</a>.</li> <li>• No, fill oil to the center of the sight gauge.</li> </ul>                                                                                                                                                  |

## Chapter 8 Troubleshooting

**NOTE:** Use [Figure 8.12 Pump Circuit Schematic](#) while troubleshooting the pump electrical system.

**Table 8-27 Pump Electrical Troubleshooting**

| Step | Possible Cause                                                                                                                                                                                                                                                                  | If . . .                                                                                                                                                                                                                                                                         |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Is the amber light “ON” on the Din Plug when the trigger is actuated? For pump forward din plug location Refer to <a href="#">Fig. 8.7 Din Plug Layout</a>                                                                                                                      | <ul style="list-style-type: none"> <li>• Yes, then the pump should be working. If it is not working see <a href="#">Table 8-31 Pump Hydraulic Troubleshooting</a></li> <li>• No, go to Step 1a.</li> </ul>                                                                       |
| 1a   | Unscrew the center screw of the din plug so you can pull the din plug up 1/4” in order to check voltage.<br>Is there 12Vdc from side post to side post?                                                                                                                         | <ul style="list-style-type: none"> <li>• Yes, the electrical system for the pump is working properly. Refer to <a href="#">Table 8-31 Hydraulic Troubleshooting</a></li> <li>• No, go to Step 4.</li> </ul>                                                                      |
| 2    | Is there 12Vdc between red wire labeled “TRIGGER RED” in junction box and nearby ground source?                                                                                                                                                                                 | <ul style="list-style-type: none"> <li>• Yes, go to Step 2a.</li> <li>• No, go to <a href="#">Table 8-29 Pump Electrical Troubleshooting (continued)</a> Step 10 for an Electric Hose.</li> <li>• No, for a Standard Hose is normal because this circuit is not used.</li> </ul> |
| 2a   | Is there 12Vdc between green wire labeled “TRIGGER GRN” in junction box and nearby ground source?<br><b>NOTE:</b> Wand trigger must be actuated during this test.                                                                                                               | <ul style="list-style-type: none"> <li>• Yes, go to Step 3.</li> <li>• No, see <a href="#">Table 8-23 Trigger is not Working</a></li> </ul>                                                                                                                                      |
| 3    | Is there 12Vdc between green wire on terminal #14 of pump relay and black wire terminal #13 pump relay?<br><b>NOTE:</b> Wand trigger must be actuated during this test.                                                                                                         | <ul style="list-style-type: none"> <li>• Yes, go to Step 5.</li> <li>• No, check for loose or broken wire between relay and junction box.</li> </ul>                                                                                                                             |
| 4    | Is there 12Vdc between the brown wire located on the lower set of terminal blocks, top right terminal and 5 <sup>th</sup> terminal down on the right blue ground wire?<br><b>NOTE:</b> Wand Trigger must be actuated or pump switch in “ON STANDARD” position during this test. | <ul style="list-style-type: none"> <li>• Yes, replace Din Plug.</li> <li>• No, go to Step 4a.</li> </ul>                                                                                                                                                                         |
| 4a   | Is there 12Vdc between the blue wire located on the lower set of terminal blocks, top left terminal and 5 <sup>th</sup> terminal down on the left black ground wire?<br><b>NOTE:</b> Trigger must be actuated or pump switch in “ON STANDARD” position during this test.        | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to Step 5.</li> </ul>                                                                                                                                                                    |

## Chapter 8 Troubleshooting

**Table 8-28 Pump Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                                                                                                                           | If . . .                                                                                                                                                                                                                             |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5    | Is there 12Vdc between the blue wire on terminal #12 of pump relay and the black wire on terminal #13 of pump relay?<br><b>NOTE:</b> Trigger must be actuated or pump switch in “ON STANDARD” position during this test. | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal #12 and the terminal block.</li> <li>• No, go to Step 5a for Electric Hose.</li> <li>• No, go to Step 5b for Standard Hose.</li> </ul> |
| 5a   | Is there 12Vdc on red wire terminal #8 of pump relay and black wire terminal #13?                                                                                                                                        | <ul style="list-style-type: none"> <li>• Yes, replace relay.</li> <li>• Go to Step 6</li> </ul>                                                                                                                                      |
| 5b   | Is there 12Vdc on red wire terminal #4 of pump relay and black wire terminal #13?<br><b>NOTE:</b> This only applies to “ON STANDARD” position of pump switch.                                                            | <ul style="list-style-type: none"> <li>• Yes, replace relay.</li> <li>• No, go to Step 7.</li> </ul>                                                                                                                                 |
| 6    | Is there 12Vdc between red wire labeled RED-1 upper terminal block and a nearby ground source (black wire)?                                                                                                              | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal block and terminal #8.</li> <li>• No, go to Step 6a.</li> </ul>                                                                        |
| 6a   | Is there 12Vdc between red wire labeled RED-4 upper terminal block and nearby ground source (black wire)?                                                                                                                | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to <a href="#">Table 8-17 Mixer Electrical Troubleshooting (continued)</a> steps 9-10a.</li> </ul>                                           |
| 7    | Is there 12Vdc between red wire labeled RED-9 on top right hand terminal of pump switch and a nearby ground source?                                                                                                      | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between pump switch and pump relay.</li> <li>• No, go to Step 7a.</li> </ul>                                                                            |
| 7a   | Is there 12Vdc between purple wire labeled PRP-3 on center right hand terminal of pump switch and a nearby ground source (black wire)?                                                                                   | <ul style="list-style-type: none"> <li>• Yes, replace pump switch.</li> <li>• No, go to Step 8.</li> </ul>                                                                                                                           |
| 8    | Is there 12Vdc between purple wire labeled PRP-3 top left terminal of hose selector switch and nearby ground (black wire)?                                                                                               | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between hose selector switch and pump switch.</li> <li>• No go to Step 8a.</li> </ul>                                                                   |
| 8a   | Is there 12Vdc between pink wire labeled PNK-3 center left terminal of hose selector switch and nearby ground (black wire)?                                                                                              | <ul style="list-style-type: none"> <li>• Yes, replace hose selector switch.</li> <li>• No, go to Step 9.</li> </ul>                                                                                                                  |
| 9    | Is there 12Vdc between pink wire labeled PNK-3 upper terminal block and nearby ground (black wire)?                                                                                                                      | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal block and hose selector switch.</li> <li>• No, go to Step 9a.</li> </ul>                                                               |

## Chapter 8 Troubleshooting


**Table 8-29 Pump Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                                       | If . . .                                                                                                                                                                                                                                      |
|------|--------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 9a   | Is there 12Vdc between pink wire labeled PNK-2 upper terminal block and nearby ground (black wire)?                                  | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to <a href="#">Table 8-16 Mixer Electrical Troubleshooting (continued)</a> Steps 4a through 10a.</li> </ul>                                           |
| 10   | Is there 12Vdc between red wire labeled "RED-TRIG" upper terminal block and nearby ground source (black wire)?                       | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal block and junction box.</li> <li>• No, go to Step 11.</li> </ul>                                                                                |
| 11   | Is there 12Vdc between purple wire labeled "PRP-1" upper terminal block and nearby ground source (black wire)?                       | <ul style="list-style-type: none"> <li>• Yes, ensure the yellow jumper in the middle of the terminal blocks is connected to the "PRP-1" and "RED-TRIG" wires is pushed in all the way.</li> <li>• No, Go to Step 12</li> </ul>                |
| 12   | Is there 12Vdc between purple wire on terminal #2 of hose PAKSTAT and terminal #8 black ground wire?                                 | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between PAKSTAT and terminal block.<br/><b>NOTE</b> This wire has a diode that could be bad and cause an open circuit.</li> <li>• No, go to Step 12a.</li> </ul> |
| 12a  | Is there 12Vdc between pink wire on terminal #1 of hose PAKSTAT and terminal #8 black ground wire?                                   | <ul style="list-style-type: none"> <li>• Yes, replace the hose PAKSTAT.</li> <li>• No, go to Step 13.</li> </ul>                                                                                                                              |
| 13   | Is there 12Vdc between pink wire labeled "PNK-1" upper terminal blocks and nearby ground source (black wire)?                        | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal blocks and hose PAKSTAT.</li> <li>• No, go to Step 13a</li> </ul>                                                                               |
| 13a  | Is there 12Vdc between pink wire labeled "PNK-4" upper terminal blocks and nearby ground source (black wire)?                        | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to Step 14.</li> </ul>                                                                                                                                |
| 14   | Is there 12Vdc between pink wire labeled "PNK-4" lower left terminal of hose selector switch and nearby ground source (black wire)?  | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between hose selector switch and terminal block.</li> <li>• No, go to Step 14a.</li> </ul>                                                                       |
| 14a  | Is there 12Vdc between pink wire labeled "PNK-3" center left terminal of hose selector switch and nearby ground source (black wire)? | <ul style="list-style-type: none"> <li>• Yes, replace hose selector switch.</li> <li>• No, go to Step 15.</li> </ul>                                                                                                                          |

## Chapter 8 Troubleshooting

**Table 8-30 Pump Electrical Troubleshooting (continued)**

| Step | Possible Cause                                                                                                      | If . . .                                                                                                                                                                                            |
|------|---------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 15   | Is there 12Vdc between pink wire labeled "PNK-3" on the upper terminal block and a nearby ground source black wire? | <ul style="list-style-type: none"> <li>• Yes, check for loose or broken wire between terminal block and hose selector switch.</li> <li>• No go to Step 9a.</li> </ul>                               |
| 15a  | Is there 12Vdc between pink wire labeled "PNK-2" on upper terminal block and nearby ground source black wire?       | <ul style="list-style-type: none"> <li>• Yes, replace terminal block.</li> <li>• No, go to <a href="#">Table 8-16 Mixer Electrical Troubleshooting (continued)</a> Steps 4a through 10a.</li> </ul> |



**Fig. 8.11 Pump Circuit Schematic**

## Chapter 8 Troubleshooting

### 8.4.2 Pump Hydraulic Troubleshooting

**Table 8-31 Pump Hydraulic Troubleshooting**

| Step | Possible Cause                                                                                                                   | If...                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------|----------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Does the coil magnetize when the din plug amber light is "ON"?                                                                   | <ul style="list-style-type: none"> <li>• Yes, go to Step 2.</li> <li>• No, remove the din plug, then remove the coil by unscrewing the nut on the end of the coil. With the coil removed reattach the din plug and place a metal screw driver in the center of the coil to see if the coil is magnetic. If it is not, recheck the din plug is plugged into the coil and the amber light is "ON". If still not magnetic replace the coil.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                        |
| 2    | Is the relief pressure set correctly?<br>(Refer to <a href="#">Fig. 8.6 Hydraulic Valve Pressure Setting</a> ).                  | <ul style="list-style-type: none"> <li>• Yes, go to Step 3.</li> <li>• No, first turn "OFF" the Isuzu engine, then remove one of the two hydraulic hoses going to the pump hydraulic motor, cap off the fitting on the motor and use a 3000 PSI gauge with the proper JIC fitting, attach it to the hose. Start the Isuzu engine, turn "ON" the main power in the control box, pull the wand trigger and read the pressure gauge. If the pressure needs to be adjusted use the pressure relief valve marked "RVP", loosen the jam nut and adjust the pressure with the allen screw at the end of the relief. Turn clockwise to increase pressure and counter clockwise to decrease pressure, then tighten the jam nut to lock pressure. Next turn "OFF" the Isuzu engine, remove the cap, pressure gauge and reattach the hose.</li> </ul> |
| 3    | Is the hydraulic flow correct from the hydraulic pump?<br>(Refer to <a href="#">Fig. 8.6 Hydraulic Valve Pressure Setting</a> ). | <ul style="list-style-type: none"> <li>• Yes, call Crafcro, Inc. and speak to a service technician. You should have been able to find the problem.</li> <li>• No, call a local hydraulic shop to see if they can run a hydraulic pump flow test, using the information in <a href="#">Fig. 8.6 Hydraulic Valve Pressure Setting</a></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

## **Chapter 9 Illustrated Parts List**

### **9.0 About the Illustrated Parts List**

The Illustrated Parts List (IPL) is designed to help technical service or maintenance personnel correctly identify orderable replacement parts.

The figure and table titles reference the part number (PN) to which they apply. The PN's for each of the EZ 1000 Series II Diesel Melter machine models are as follows:

EZ1000 Series II Electric Base Diesel Melter PN46200EB

EZ1000 Series II Standard Base Diesel Melter PN46200SB

EZ1000 Series II Electric Base Diesel Melter with 63CFM Air Compressor PN46200EC63

EZ1000 Series II Standard Base Diesel Melter with 63CFM Air Compressor PN46200SC63

Illustrations are designed to show general shape and size of a part and the relationship that part has to other parts. Actual size and shape of parts or components may differ or vary from the actual part or component.

### **9.1 Ordering Crafco Parts**

Crafco distributors and Crafco Pavement Preservation Supply Centers are strategically located throughout the United States. Parts can be ordered from your local Crafco distributor or directly from Crafco, Inc. if a distributor is not available in your area.

When ordering parts, give the following information:

- Part Number
- Machine Model
- Serial Number

Write, call, or Fax Crafco, Inc. at the following:

Crafco, Inc. Headquarters

420 N. Roosevelt Ave.

Chandler, AZ 85226-2601

Phone: (602) 276-0406


Toll Free: (800) 528-8242

Fax: (480) 961-0513

Visit our website at [www.crafco.com](http://www.crafco.com)

## Chapter 9 Illustrated Parts List

### 9.2 EZ1000 Series II Melter



**Fig. 9.1 EZ1000 Series II Melter**


## Chapter 9 Illustrated Parts List

| FIG.     | ITEM | PART NO. | DESCRIPTION                       | QTY. |
|----------|------|----------|-----------------------------------|------|
| Fig. 9.1 | 1    | 44342    | TIRE AND WHEEL ASSEMBLY           | 2/4* |
|          | 2    | 45007    | TORSIONAL AXLE ASSEMBLY           | 1/2* |
|          | 3    | 23117    | BREAKAWAY SWITCH                  | 1    |
|          | 4    | 47103    | ENGINE ASSEMBLY – 46200EB         | 1    |
|          | 4    | 47100    | ENGINE ASSEMBLY – 46200SB         | 1    |
|          | 4    | 46727    | ENGINE ASSEMBLY – 46200SC63       | 1    |
|          | 4    | 46712    | ENGINE ASSEMBLY – 46200EC63       | 1    |
|          | 5    | 29399    | ISOMOUNT                          | 4    |
|          | 6    | 46255    | HYDRAULIC TANK ASSEMBLY           | 1    |
|          | 7    | 45498    | HYDRAULIC FILTER ASSEMBLY         | 1    |
|          | 7a   | 45438    | HYDRAULIC FILTER ELEMENT          | 1    |
|          | 7b   | 45440    | O-RING, HYDRAULIC FILTER          | 1    |
|          | 7c   | 45497    | GASKET, HYDRAULIC FILTER          | 1    |
|          | 8    | 46620    | CONTROL BOX ASSEMBLY – ELECTRIC   | 1    |
|          | 8    | 46715    | CONTROL BOX ASSEMBLY – STANDARD   | 1    |
|          | 9    | 43355    | OVERFLOW TANK                     | 1    |
|          | 10   | 46265    | DIPSTICK                          | 1    |
|          | 11   | 26025    | AIR BREATHER                      | 1    |
|          | 12   | 22310    | MOTOR, HYDRAULIC – AGITATOR       | 1    |
|          | 13   | 46010    | BOOM – HOSE                       | 1    |
|          | 14   | 45579    | BASE, BOOM                        | 1    |
|          | 15   | 43167    | MATERIAL PUMP ASSEMBLY            | 1    |
|          | 16   | 45553    | BEARING, BOOM                     | 2    |
|          | 17   | 45420    | HYDRAULIC CONTROL VALVE ASSEMBLY  | 1    |
|          | 18   | 44027    | JUNCTION BOX ASSEMBLY             | 1    |
|          | 19   | 25057    | GAUGE, HOSE COMPARTMENT           | 1    |
|          | 20   | 43465    | SENSOR, RTD                       | 2    |
|          | 21   | 56940    | SENSOR, RTD – PUMPING TEMPERATURE | 1    |
|          | 22   | 46060    | REGULATOR, FLOW                   | 1    |

\*EB/SB = SINGLE AXLE

\*EC63/SC63 = DUAL AXLE

## Chapter 9 Illustrated Parts List




**Fig. 9.2 EZ1000 Series II Melter**

## Chapter 9 Illustrated Parts List

| FIG.     | ITEM | PART NO. | DESCRIPTION                            | QTY. |
|----------|------|----------|----------------------------------------|------|
| Fig. 9.2 | 23   | 32363    | TAIL LIGHT, STOP, TURN, AND TAIL       | 2    |
|          | 24   | 24040    | SIDE MARKER, RED                       | 2    |
|          | 25   | 24041    | CLEARANCE MARKER, YELLOW               | 2    |
|          | 26   | 46707    | SUPPORT ASSEMBLY, WAND                 | 1    |
|          | 27   | 24000    | BATTERY                                | 1    |
|          | 28   | 24002    | BATTERY BOX                            | 1    |
|          | 29   | 27048    | SWIVEL, HOSE                           | OPT. |
|          | 30   | 46340    | SUPPORT, HOSE                          | 1    |
|          | 31   | 45439    | HYDRAULIC PUMP ASSEMBLY – EB/SB        | 1    |
|          | 31   | 45442    | HYDRAULIC PUMP ASSEMBLY – EC63/SC63    | 1    |
|          | 32   | 20130    | SAFETY CHAIN                           | 2    |
|          | 33   | 46182    | FENDER ASSEMBLY, D.S.                  | 2    |
|          | 34   | 52200    | WAND ASSEMBLY – ELECTRIC               | OPT. |
|          | 34   | 46129    | WAND – STANDARD HOSE (Not Shown)       | OPT. |
|          | 35   | 41208    | HANDLE W/ VALVE (Not Shown)            | OPT. |
|          | 36   | 45372    | EXHAUST PIPE – EB/SB/SC63              | 1    |
|          | 36   | 46380    | EXHAUST PIPE – EC63                    | 1    |
|          | 37   | 41881    | NOZZLE, BURNER (Not Shown)             | 1    |
|          | 38   | 46053    | HOSE HANGER                            | 1    |
|          | 39   | 51065    | CORD GRIP                              | 3    |
|          | 40   | 39608    | SWITCH, LID                            | 1    |
|          | 41   | 23095    | BUSHING, JACK ASSEMBLY                 | 1    |
|          | 42   | 23082    | JACK ASSEMBLY, 7000#                   | 1    |
|          | 43   | 52400    | ELECTRIC HEATED HOSE, 15'(Not Shown)   | OPT. |
|          | 44   | 27009    | HOSE, 20' SEALANT (Not Shown)          | OPT. |
|          | 45   | 46263    | BOOM LOCK ASSEMBLY                     | 1    |
|          | 46   | 45762    | HYDRAULIC OIL COOLER                   | 1    |
|          | 47   | 45542    | TEMPERATURE SWITCH, COOLER (Not shown) | 1    |
|          | 48   | 46172    | FENDER ASSEMBLY, P.S.                  | 1    |

## Chapter 9 Illustrated Parts List

### 9.3 EZ1000 Series II melter Options



**Fig. 9.3 EZ1000 Series II Melter Options**

## Chapter 9 Illustrated Parts List


| FIG.     | ITEM | PART NO. | DESCRIPTION                   | QTY. |
|----------|------|----------|-------------------------------|------|
| Fig. 9.3 | 1    | 51230    | CONVEYOR ASSEMBLY             | 1    |
|          | 2    | 46280K   | ARROW BOARD                   | 1    |
|          | 3    | 46279    | KIT, GRAVITY FEED             | 1    |
|          | 4    | 46271    | RACK, AIR HOSE                | 1    |
|          | 5    | 46260    | TOOL BOX                      | 1    |
|          | 6    | 46170K   | STROBE LIGHT KIT (NOT SHOWN)  | 1    |
|          | 7    | 46160K   | LIGHT BAR KIT (NOT SHOWN)     | 1    |
|          | 8    | 46148    | MOUNTING PLATE, HOSE REEL     | 1    |
|          | 9    | 41629    | HAND WAND ASSEMBLY            | 1    |
|          | 9a   | 41208    | HANDLE ASSEMBLY W/ VALVE      | 1    |
|          | 10   | 45535    | ENGINE COVER ASSEMBLY         | 1    |
|          | 11   | 44151    | PLATE, SUPPORT – ENGINE COVER | 2    |
|          | 12   | 45345    | COMPRESSOR ASSEMBLY           | 1    |
|          | 13   | 43549    | KIT, SPARE TIRE               | 1    |
|          | 14   | 41259K   | KIT, 100# PROPANE TANK        | 1    |
|          | 15   | 27059    | HOSE REEL, STAINLESS STEEL    | 1    |
|          | 16   | 27009    | 20' SEALANT HOSE              | 1    |
|          | 17   | 26119    | 3/8" SAFETY HOOK (NOT SHOWN)  | 2    |
|          | 18   | 26059    | BRACKET, FIRE EXTINGUISHER    | 1    |
|          | 19   | 26058    | FIRE EXTINGUISHER W/ COVER    | 1    |
|          | 20   | 24190    | HEATER, FIREROD               | 1    |
|          | 21   | 45650    | HOT AIR LANCE (NOT SHOWN)     | 1    |

**Chapter 9 Illustrated Parts List**

This page left blank intentionally

**Chapter 9 Illustrated Parts List**

**9.4 Tank Detail**




**Fig. 9.4 Tank Detail**

| FIG.     | ITEM | PART NO. | DESCRIPTION                 | QTY. |
|----------|------|----------|-----------------------------|------|
| Fig. 9.4 | 1    | 46246    | PADDLE, AGITATOR            | 2    |
|          | 2    | 42574    | MOTOR, HYDRAULIC – AGITATOR | 1    |
|          | 3    | 46050    | SHAFT ASSEMBLY – AGITATOR   | 1    |
|          | 4    | 46380    | BURNER, 14 VOLT DIESEL      | 1    |
|          | 5    | 46058    | BURNER BOX ASSEMBLY         | 1    |
|          | 5a   | 43179    | BURNER BOX INSULATION KIT   | 1    |
|          | 6    | 42573    | MOUNTING PLATE – MOTOR      | 1    |
|          | 7    | 40030    | SPACER. MOTOR               | 4    |

## Chapter 9 Illustrated Parts List

### 9.5 Plumbing




**Fig. 9.5 Plumbing**

## Chapter 9 Illustrated Parts List

| FIG.     | ITEM | PART NO. | DESCRIPTION                            | QTY. |
|----------|------|----------|----------------------------------------|------|
| Fig. 9.5 | 1    | 46020    | PUMP ASSEMBLY                          | 1    |
|          | 2    | 22027    | HYDRAULIC MOTOR                        | 1    |
|          | 3    | 22030    | NIPPLE ASSEMBLY, FLANGED               | 2    |
|          | 4    | 29050    | GASKET, 2" CIRCULAR FLANGED            | 5    |
|          | 5    | 46668    | ELBOW, DOUBLE                          | 1    |
|          | 6    | 46678    | FLANGED TEE                            | 1    |
|          | 7    | 41246    | VALVE, 2" BALL                         | 1    |
|          | 8    | 46675    | PIPING ASSEMBLY, UPPER                 | 1    |
|          | 9    | 29270    | VALVE, 2" GATE                         | 1    |
|          | 10   | 28060    | NIPPLE, 2" NPT X 5" LG.                | 1    |
|          | 11   | 28213    | ELBOW, 2" NPT                          | 1    |
|          | 12   | 46371    | TEE, LOWER SUCTION                     | 1    |
|          | 13   | 29060    | GASKET, 3" CIRCULAR FLANGED            | 2    |
|          | 14   | 28258    | TEE, 2" PIPE                           | 1    |
|          | 15   | 28242    | ELBOW, 2" 45° PIPE                     | 1    |
|          | 16   | 28358    | BUSHING, 2" X 1" HEX HEAD REDUCER      | 2    |
|          | 17   | 28285    | PLUG, 1" SQ. HEAD PIPE                 | 1    |
|          | 18   | 28190    | NIPPLE, 2" NPT X 14.5" LG.             | 1    |
|          | 19   | 28183    | COUPLING, 2" PIPE                      | 1    |
|          | 20   | 27048    | SWIVEL, 1" PIPE                        | 1    |
|          | 21   | 28225    | ELBOW, 1" STREET                       | 1    |
|          | 22   | 28351    | BUSHING, 1" X 3/4" HEX HEAD REDUCER    | 1    |
|          | 23   | 28043    | NIPPLE, 1/4" NPT X 2" LG.              | 1    |
|          | 24   | 28176    | COUPLING, 1/4" PIPE                    | 1    |
|          | 25   | 46509    | EXTENSION, VALVE HANDLE                | 1    |
|          | 26   | 46065    | FLEXHOSE ASSEMBLY, 2 1/2" X 8 1/4" LG. | 1    |
|          | 27   | 29292    | VALVE, 3" FLANGED GATE                 | 1    |
|          | 28   | 28048    | NIPPLE, 2" NPT X 4" LG.                | 1    |
|          | 29   | 28273    | CAP, 2" PIPE                           | 1    |

## Chapter 9 Illustrated Parts List

## 9.6 Control Box Assembly – Electric Hose




## Chapter 9 Illustrated Parts List

**Fig. 9.6 Control Box Assembly: 46200EB, 46200EC63**

| FIG.     | ITEM | PART NO. | DESCRIPTION                       | QTY. |
|----------|------|----------|-----------------------------------|------|
| Fig. 9.6 | 1    | 45595    | ENCLOSURE (NOT SHOWN)             | 1    |
|          | 2    | 24024    | CORD CONNECTOR                    | 3    |
|          | 3    | 50280    | 1/2" CONDUIT NUT                  | 5    |
|          | 4    | 51662    | SOCKET, RELAY                     | 1    |
|          | 5    | 51661    | RELAY                             | 1    |
|          | 6    | 51663    | HOLD DOWN SPRING                  | 1    |
|          | 7    | 51691    | TEMPERATURE CONTROLLER, 400°/325° | 1    |
|          | 8    | 51672    | TEMPERATURE CONTROLLER, 400°/275° | 1    |
|          | 9    | 51803    | MOUNTING RAIL                     | 2    |
|          | 10   | 51802    | END BRACKET                       | 2    |
|          | 11   | 51800    | FEED THROUGH TERMINAL             | 40   |
|          | 12   | 51801    | JUMPER, 2-POLE                    | 3    |
|          | 13   | 51804    | JUMPER, 3-POLE                    | 1    |
|          | 14   | 50251    | READOUT, DIGITAL                  | 3    |
|          | 15   | 43391    | TEMPERATURE CONTROLLER 150°-550°  | 1    |
|          | 16   | 51651    | LIGHT, 12VDC                      | 4    |
|          | 17   | 50719    | SWITCH, TOGGLE                    | 2    |
|          | 18   | 51665    | CIRCUIT BREAKER, 15 AMP           | 1    |
|          | 19   | 50593    | KNOB                              | 3    |
|          | 20   | 51834    | CABLE ASSEMBLY, SENSOR            | 1    |
|          | 21   | 51835    | CABLE ASSEMBLY, POWER             | 1    |
|          | 22   | 51836    | CABLE ASSEMBLY, TRIGGER/SENSOR    | 1    |
|          | 23   | 51684    | RIBBON CABLE, 36" (NOT SHOWN)     | 2    |
|          | 24   | 51670    | SPACER, TEMPERATURE CONTRLLER     | 8    |
|          | 25   | 43984    | CABLE ASSEMBLY, VALVE             | 1    |
|          | 26   | 51805    | END BRACKET                       | 4    |
|          | 27   | 44979    | RELAY, STARTER                    | 2    |
|          | 28   | 44980    | TIMER                             | 1    |
|          | 29   | -        | RELAY                             | 1    |

## Chapter 9 Illustrated Parts List




**Fig. 9.7 Control Box Assembly: 46200EB, 46200EC63**

## Chapter 9 Illustrated Parts List

| FIG.     | ITEM | PART NO. | DESCRIPTION                          | QTY. |
|----------|------|----------|--------------------------------------|------|
| Fig. 9.7 | 30   | 24076    | HOUR METER                           | 1    |
|          | 31   | 41994    | IGNITION SWITCH                      | 1    |
|          | 32   | 45950    | SOCKET, CONNECTOR                    | 1    |
|          | 33.  | 45970    | WIRING HARNESS, EXTENSION            | 1    |
|          | 34   | 51698    | RIBBON CABLE, 5"                     | 1    |
|          | 35   | 51811    | SWITCH, HOSE SELECTOR                | 1    |
|          | 36   | 32522    | SWITCH, PUMP                         | 1    |
|          | 37   | 44975    | GAUGE, WATER TEMPERATURE (Not Shown) | OPT. |
|          | 38   | 44976    | GAUGE, OIL PRESSURE (Not Shown)      | OPT. |
|          | 39   | 44977    | GAUGE, VOLT METER (Not Shown)        | OPT. |
|          | 40   | 44987    | RESISTANCE CONTROL                   | 1    |
|          | 41   | 44989    | LIGHT, AMBER                         | 2    |
|          | 42   | 44988    | LIGHT, RED                           | 1    |

## Chapter 9 Illustrated Parts List

### 9.7 Control Box Assembly – Standard Hose




**Fig. 9.8 Control Box Assembly: 46200SB, 46200SC63**

## Chapter 9 Illustrated Parts List

| FIG.     | ITEM | PART NO. | DESCRIPTION                       | QTY. |
|----------|------|----------|-----------------------------------|------|
| Fig. 9.8 | 1    | 45595    | ENCLOSURE (NOT SHOWN)             | 1    |
|          | 2    | 24021    | CORD CONNECTOR                    | 3    |
|          | 3    | 50280    | 1/2" CONDUIT NUT                  | 5    |
|          | 4    | 51662    | SOCKET, RELAY                     | 1    |
|          | 5    | 51661    | RELAY                             | 1    |
|          | 6    | 51663    | HOLD DOWN SPRING                  | 1    |
|          | 7    | 51672    | TEMPERATURE CONTROLLER, 400°/275° | 1    |
|          | 8    | 43397    | TEMPERATURE CONTROLLER, 400°      | 1    |
|          | 9    | 51803    | MOUNTING RAIL                     | 2    |
|          | 10   | 51802    | END PLATE                         | 2    |
|          | 11   | 51800    | FEED THROUGH TERMINAL             | 33   |
|          | 12   | 51801    | JUMPER, 2-POLE                    | 1    |
|          | 13   | 51804    | JUMPER, 3-POLE                    | 2    |
|          | 14   | 50251    | READOUT, DIGITAL                  | 3    |
|          | 15   | 43391    | TEMPERATURE CONTROLLER 150°-550°  | 1    |
|          | 16   | 51651    | LIGHT, 12VDC                      | 3    |
|          | 17   | 50719    | SWITCH, TOGGLE                    | 2    |
|          | 18   | 51665    | CIRCUIT BREAKER, 15 AMP           | 1    |
|          | 19   | 50593    | KNOB                              | 3    |
|          | 20   | 51834    | CABLE ASSEMBLY, SENSOR            | 1    |
|          | 21   | 51835    | CABLE ASSEMBLY, POWER             | 1    |
|          | 22   | 51836    | CABLE ASSEMBLY, TRIGGER/SENSOR    | 1    |
|          | 23   | 51684    | RIBBON CABLE, 36" (NOT SHOWN)     | 1    |
|          | 24   | 51670    | SPACER, TEMPERATURE CONTROLLER    | 4    |
|          | 25   | 44994    | TERMINAL BLOCK 5-POLE             | 1    |
|          | 26   | 51805    | END BRACKET                       | 4    |
|          | 27   | 44979    | RELAY, STARTER                    | 2    |
|          | 28   | 44980    | TIMER                             | 1    |
|          | 29   | 51673    | RELAY (NOT SHOWN)                 | 1    |
|          | 30   | 24076    | HOUR METER                        | 1    |

## Chapter 9 Illustrated Parts List




**Fig. 9.9 Control Box Assembly: 46200SB, 46200SC63**

## Chapter 9 Illustrated Parts List

| FIG.     | ITEM | PART NO. | DESCRIPTION                 | QTY. |
|----------|------|----------|-----------------------------|------|
| Fig. 9.9 | 31   | 44990    | KEY AND TUMBLER             | 1    |
|          | 31a  | 41994    | IGNITION SWITCH W/O TUMBLER | 1    |
|          | 32   | 45950    | SOCKET, CONNECTOR           | 1    |
|          | 33   | 45970    | WIRING HARNESS, EXTENSION   | 1    |
|          | 34   | 51698    | RIBBON CABLE, 5"            | 2    |
|          | 35   | 44976    | GAUGE, OIL PRESSURE         | OPT. |
|          | 36   | 44977    | GAUGE, VOLT METER           | OPT. |
|          | 37   | 43984    | CABLE ASSEMBLY, VALVE       | 1    |
|          | 38   | 44987    | RESISTANCE CONTROL          | 1    |
|          | 39   | 44989    | LIGHT, AMBER                | 1    |
|          | 40   | 44988    | LIGHT, RED                  | 2    |
|          | 41   | 51678    | SWITCH, DPDT                | 2    |
|          | 42   | 32522    | SWITCH, PUMP                | 1    |

## Chapter 9 Illustrated Parts List

### 9.8 Engine Assembly – Non Compressor




**Fig. 9.10 Engine Assembly - 46200EB, 46200SB**

| FIG.      | ITEM | PART NO. | DESCRIPTION                           | QTY. |
|-----------|------|----------|---------------------------------------|------|
| Fig. 9.10 | 1    | 47103    | 27.5 HP ENGINE W/ GENERATOR – 46200EB | 1    |
|           | 1    | 47100    | 27.5 HP ENGINE NO GENERATOR – 46200SB | 1    |
|           | 2    | 43612    | GENERATOR, 24VAC (46200EB ONLY)       | 1    |
|           | 3    | 45748    | BELT, DRIVE – GEN. (46200EB ONLY)     | 1    |
|           | 4    | 41867    | FUEL FILTER                           | 1    |
|           | 5    | 45389    | OIL FILTER                            | 1    |
|           | 6    | 45439    | HYDRAULIC PUMP                        | 1    |
|           | 7    | 45391    | AIR FILTER ELEMENT                    | 1    |

## Chapter 9 Illustrated Parts List

### 9.9 Engine Assembly, Compressor - Standard Hose




**Fig. 9.11 Engine Assembly - 46200SC63**

| FIG.      | ITEM | PART NO. | DESCRIPTION        | QTY. |
|-----------|------|----------|--------------------|------|
| Fig. 9.11 | 1    | 46727    | 35.5 HP ENGINE     | 1    |
|           | 2    | 41867    | FUEL FILTER        | 1    |
|           | 3    | 45381    | OIL FILTER         | 1    |
|           | 4    | 45449    | HYDRAULIC PUMP     | 1    |
|           | 5    | 45382    | AIR FILTER ELEMENT | 1    |

**Chapter 9 Illustrated Parts List**

**9.10 Engine Assembly, Compressor – Electric Hose**




**Fig. 9.12 Engine Assembly - 46200EC63**

| FIG.      | ITEM | PART NO. | DESCRIPTION                 | QTY. |
|-----------|------|----------|-----------------------------|------|
| Fig. 9.12 | 1    | 46712    | 41.6 HP ENGINE W/ GENERATOR | 1    |
|           | 2    | 43612    | GENERATOR, 24VAC            | 1    |
|           | 3    | 45748    | BELT, DRIVE – GENERATOR     | 1    |
|           | 4    | 41867    | FUEL FILTER                 | 1    |
|           | 5    | 45381    | OIL FILTER                  | 1    |
|           | 6    | 45442    | HYDRAULIC PUMP              | 1    |
|           | 7    | 45348    | AIR FILTER ELEMENT          | 1    |

**Chapter 9 Illustrated Parts List**

**9.11 Hydraulic Control Valve Assembly**



**Fig. 9.13 Hydraulic Control Valve**


| FIG.      | ITEM | PART NO. | DESCRIPTION                            | QTY. |
|-----------|------|----------|----------------------------------------|------|
| Fig. 9.13 | 1    | 45418    | VALVE ASSEMBLY                         | 2    |
|           | 2    | 45419    | COIL, VALVE ASSEMBLY                   | 4    |
|           | 3    | 45417    | VALVE, RELIEF                          | 2    |
|           | 4    | -        | TEE, MALE #8 ORB X #8 JIC RUN          | 1    |
|           | 5    | 45413    | CAP, DUST                              | 2    |
|           | 6    | 45414    | FITTING, TEST POINT                    | 2    |
|           | 7    | 45416    | FLOW CONTROL, PRIORITY                 | 1    |
|           | 8    | -        | FITTING, #6 ORB X #6 JIC LONG STRAIGHT | 2    |
|           | 9    | -        | FITTING, #6 ORB X #8 JIC STRAIGHT      | 2    |

**Chapter 9 Illustrated Parts List**

This page left blank intentionally

**Chapter 9 Illustrated Parts List**

**9.12 Hydraulic Compressor Valve Assembly**




**Fig. 9.14 Compressor Valve Assembly**

| FIG.      | ITEM | PART NO. | DESCRIPTION                         | QTY. |
|-----------|------|----------|-------------------------------------|------|
| Fig. 9.14 | 1    | 45417    | VALVE, RELIEF                       | 1    |
|           | 2    | 45429    | VALVE, LOGIC RELIEF                 | 1    |
|           | 3    | 45426    | COIL, SOLENOID VALVE                | 1    |
|           | 4    | 45424    | VALVE, SOLENOID                     | 1    |
|           | 5    | -        | FITTING, #12 ORB X #10 JIC STRAIGHT | 2    |
|           | 6    | 45436    | FLOW CONTROL, PRESSURE COMP.        | 1    |
|           | 7    | 45414    | FITTING, TEST POINT                 | 1    |
|           | 8    | 45413    | CAP, DUST                           | 1    |
|           | 9    | -        | TEE, #12 ORB X #12 JIC RUN          | 1    |

**Chapter 9 Illustrated Parts List**

**9.13 Diesel Burner Assembly**



**Fig. 9.15 Diesel Burner**

## Chapter 9 Illustrated Parts List


| FIG.      | ITEM | PART NO. | DESCRIPTION                                        | QTY. |
|-----------|------|----------|----------------------------------------------------|------|
| Fig. 9.15 | 1    | 41949    | IGNITION TRANSFORMER                               | 1    |
|           | 2    | 41870    | CAD EYE (NOT SHOWN)                                | 1    |
|           | 3    | 42335    | DC CONTROLLER (NOT SHOWN)                          | 1    |
|           | 4    | 41890    | BLOWER MOTOR                                       | 1    |
|           | 5    | 41970    | COUPLING, FUEL PUMP                                | 1    |
|           | 6    | 41892    | PUMP, FUEL                                         | 1    |
|           | 7    | 41888    | SOLENOID, FUEL                                     | 1    |
|           | 8    | 41883    | NOZZLE                                             | 1    |
|           | 9    | 41993    | ELECTRODE                                          | 1    |
|           | 10   | 24258    | DIESEL GAUGE KIT (SEE <a href="#">Figure 8.3</a> ) | OPT. |

**Chapter 9 Illustrated Parts List**

This page left blank intentionally

## Chapter 9 Illustrated Parts List

### 9.14 Material Pump Assembly




**Fig. 9.16 Material Pump Assembly**

| FIG.      | ITEM | PART NO. | DESCRIPTION                        | QTY. |
|-----------|------|----------|------------------------------------|------|
| Fig. 9.16 | 1    | 22027    | MOTOR, HYDRAULIC                   | 1    |
|           | 2    | 42071    | PUMP ASSEMBLY, NON-JACKETED        | 1    |
|           | 2a   | 29990S   | PACKING RING (SET OF 7)            | 1    |
|           | 3    | 43129    | MOUNTING PLATE ASSEMBLY            | 1    |
|           | 4    | 22029    | FITTING, #10 ORB X #6 JIC STRAIGHT | 2    |

**Chapter 9 Illustrated Parts List**

**9.15 Air Compressor Assembly**




**Fig. 9.17 Compressor Assembly**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM | PART NO. | DESCRIPTION                          | QTY. |
|-----------|------|----------|--------------------------------------|------|
| Fig. 9.17 | 1    | 45320    | COMPRESSOR, ROTARY VANE              | 1    |
|           | 2    | 45347    | SHAFT, COMPRESSOR DRIVE              | 1    |
|           | 3    | 45346    | PLATE, MOTOR ADAPTER                 | 1    |
|           | 4    | 45327    | MOUNTING PLATE, VALVE                | 1    |
|           | 5    | 45425    | VALVE, HYDRAULIC                     | 1    |
|           | 6    | 43874    | MOTOR, HYDRAULIC                     | 1    |
|           | 7    | 29819    | FITTING, #12 ORB X #12 JIC STRAIGHT  | 2    |
|           | 8    | 45326    | FITTING, #12 BSPP X #12 JIC STRAIGHT | 1    |
|           | 9    | 29773    | ADAPTER, #12 JIC X 3/4 FPT 90°       | 1    |
|           | 10   | 28348    | BUSHING, 3/4" NPT X 1/2" NPT         | 1    |
|           | 11   | 51405    | NIPPLE, 1/2" NPT HEX                 | 1    |
|           | 12   | 42643    | FITTING, 1/2" NPT AIR HOSE           | 1    |
|           | 13   | 42702    | SWIVEL, 1/2" NPT                     | 1    |
|           | 14   | 28253    | TEE, 1/2" NPT PIPE                   | 1    |
|           | 15   | 45564    | NIPPLE, RESTRICTOR                   | 1    |
|           | 16   | 50267    | MUFFLER, AIR                         | 1    |
|           | 17   | 45476    | RETURN LINE, COMPRESSOR              | 1    |
|           | 18   | 45475    | SUPPLY LINE, COMPRESSOR              | 1    |

**Chapter 9 Illustrated Parts List**

**9.16 Wand Assembly**




**Fig. 9.18 Wand Assembly**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM | PART NO. | DESCRIPTION                      | QTY. |
|-----------|------|----------|----------------------------------|------|
| Fig. 9.18 | 1    | 52204    | COVER, WAND                      | 1    |
|           | 2    | 50278    | TIP GUARD, LONG CLAMP ON         | 1    |
|           | 3    | 52206    | CORD ASSEMBLY                    | 1    |
|           | 4    | 52201R   | HANDLE, WAND – RIGHT (W/INSERTS) | 1    |
|           | 5    | 52201L   | HANDLE, WAND – LEFT (NOT SHOWN)  | 1    |
|           | 6    | 52208    | SWITCH, WAND                     | 1    |
|           | 7    | 52202    | ACUATOR                          | 1    |
|           | 8    | 52207    | SPRING, ACUATOR                  | 1    |
|           | 9    | 52209    | PIN, ACTUATOR                    | 1    |
|           | 10   | 52203    | LOCK, TRIGGER                    | 1    |
|           | 11   | 51656    | TERMINAL STRIP                   | 1    |

**Chapter 9 Illustrated Parts List**

**9.17 Hydraulic Diagram**




**Fig. 9.19 Hydraulic Diagram W/O Compressor 46200EB, 46200SB**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM     | PART NO.                                                        | DESCRIPTION                     | QTY |
|-----------|----------|-----------------------------------------------------------------|---------------------------------|-----|
| Fig. 9.18 | <b>1</b> | <b>HYDRAULIC RESERVOIR TO HYDRAULIC PUMP SUCTION PORT</b>       |                                 |     |
|           |          | 29898                                                           | FITTING, #20 ORB X 16 JIC 45°   | 1   |
|           |          | 16G4H 16G-16FJX45 16+G-16FJX 20                                 | HYDRAULIC HOSE                  | 1   |
|           |          | 29820                                                           | FITTING, #16 ORB X #16 JIC STR. | 1   |
|           | <b>2</b> | <b>HYDRAULIC PUMP TO HYDRAULIC VALVE “P” PORT</b>               |                                 |     |
|           |          | 29842                                                           | FITTING, #12 ORB x 10 JIC 90°   | 1   |
|           |          | 8M3K 8G-10FJX 8G-10FJX 29                                       | HYDRAULIC HOSE                  | 1   |
|           |          | 29805                                                           | FITTING, #10 JIC BULKHEAD       | 1   |
|           |          | 29807                                                           | NUT, BULKHEAD FITTING           | 1   |
|           |          | 46277                                                           | TUBE, HYDRAULIC PRESSURE        | 1   |
|           |          | 8M3K 8G-8FJX90S 8G-10FJX 27                                     | HYDRAULIC HOSE                  | 1   |
|           |          | 29897                                                           | FITTING, #8 ORB X #8 JIC STR.   | 1   |
|           | <b>3</b> | <b>HYDRAULIC VALVE “AA” PORT TO AGITATOR MOTOR REAR PORT</b>    |                                 |     |
|           |          | 29919                                                           | FITTING, #6 ORB X #8 JIC STR.   | 1   |
|           |          | 6M3K 6G-6FJX 6G-8FJX90L 36                                      | HYDRAULIC HOSE                  | 1   |
|           |          | 29808                                                           | FITTING, #6 JIC X #6 JIC UNION  | 1   |
|           |          | 46721                                                           | TUBE, HYDRAULIC PRESSURE        | 1   |
|           |          | 22029                                                           | FITTING, #10 ORB X #6 JIC STR.  | 1   |
|           | <b>4</b> | <b>AGITATOR MOTOR (FRONT PORT) TO HYDRAULIC VALVE “AB” PORT</b> |                                 |     |
|           |          | 22029                                                           | FITTING, #10 ORB X #6 JIC STR.  | 1   |
|           |          | 46778                                                           | TUBE, HYDRAULIC RETURN          | 1   |
|           |          | 29808                                                           | FITTING, #6 JIC X #6 JIC UNION  | 1   |
|           |          | 6M3K 6G-6FJX 6G-6FJX90S 35                                      | HYDRAULIC HOSE                  | 1   |
|           |          | 40308                                                           | FITTING, #6 ORB X #6 JIC LONG   | 1   |
|           | <b>5</b> | <b>HYDRAULIC VALVE “PA” TO FLOW CONTROL #1 PORT</b>             |                                 |     |
|           |          | 40308                                                           | FITTING, #6 ORB X #6 JIC LONG   | 1   |
|           |          | 6M3K 6G-6FJX90S 6G-8FJX 18                                      | HYDRAULIC HOSE                  | 1   |
|           |          | 29896                                                           | FITTING, #8 ORB X #8 JIC 90°    | 1   |

**Chapter 9 Illustrated Parts List**




**Fig. 9.20 Hydraulic Diagram W/O Compressor 46200EB, 46200SB**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM      | PART NO.                                                     | DESCRIPTION                     | QTY. |
|-----------|-----------|--------------------------------------------------------------|---------------------------------|------|
| Fig. 9.19 | <b>6</b>  | <b>FLOW CONTROL #3 PORT TO PUMP MOTOR (TOP PORT)</b>         |                                 |      |
|           |           | 29896                                                        | FITTING, #8 ORB X #8 JIC 90°    | 1    |
|           |           | 8M3K 8G-8FJX 8G-8FJX 47                                      | HYDRAULIC HOSE                  | 1    |
|           |           | 29913                                                        | FITTING, #10 ORB X #8 JIC STR.  | 1    |
|           | <b>7</b>  | <b>PUMP MOTOR (BOTTOM PORT) TO HYDRAULIC VALVE "PB" PORT</b> |                                 |      |
|           |           | 29913                                                        | FITTING, #10 ORB X #8 JIC STR.  | 1    |
|           |           | 8M3K 8G-8FJX 8G-8FJX90S 28                                   | HYDRAULIC HOSE                  | 1    |
|           |           | 29919                                                        | FITTING, #6 ORB X #8 JIC STR.   | 1    |
|           | <b>8</b>  | <b>FLOW CONTROL #2 PORT TO HYDRAULIC VALVE TANK PORT</b>     |                                 |      |
|           |           | 29896                                                        | FITTING, #8 ORB X #8 JIC STR.   | 1    |
|           |           | 8M3K 8G-8FJX 8G-8FJX90S 22                                   | HYDRAULIC HOSE                  | 1    |
|           |           | 29932                                                        | FITTING, #8 ORB RUN TEE         | 1    |
|           | <b>9</b>  | <b>HYDRAULIC VALVE TANK PORT TO HYDRAULIC OIL COOLER</b>     |                                 |      |
|           |           | 29932                                                        | FITTING, #8 ORB RUN TEE         | 1    |
|           |           | 8M3K 8G-8FJX 8G-10FJX 20                                     | HYDRAULIC HOSE                  | 1    |
|           |           | 29805                                                        | FITTING, #10 JIC BULKHEAD       | 1    |
|           |           | 29807                                                        | NUT, BULKHEAD FITTING           | 1    |
|           |           | 46276                                                        | TUBE, HYDRAULIC RETURN          | 1    |
|           |           | 29805                                                        | FITTING, #10 JIC BULKHEAD       | 1    |
|           |           | 29807                                                        | NUT, BULKHEAD FITTING           | 1    |
|           |           | 8M3K 8G-10FJX 8G-12FJX 33                                    | HYDRAULIC HOSE                  | 1    |
|           |           | 27692                                                        | FITTING, #16 FJIC X #12 JIC     | 1    |
|           |           | 29820                                                        | FITTING, #16 ORB X #16 JIC STR. | 1    |
|           | <b>10</b> | <b>HYDRAULIC OIL COOLER TO HYDRAULIC TANK</b>                |                                 |      |
|           |           | 29824                                                        | FITTING, #16 ORB X #16 JIC 90°  | 1    |
|           |           | 16G4H 16G-16FJX90S 16G-16FJX 18                              | HYDRAULIC HOSE                  | 1    |
|           |           | 29818                                                        | FITTING, #20 ORB X #16 JIC STR. | 1    |

**Chapter 9 Illustrated Parts List**

**9.18 Hydraulic Diagram - Compressor**




**Fig. 9.21 Hydraulic Diagram W/ Compressor 46200EC63, 46200SC63**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM     | PART NO.                                                        | DESCRIPTION                      | QTY |
|-----------|----------|-----------------------------------------------------------------|----------------------------------|-----|
| Fig. 9.20 | <b>1</b> | <b>HYDRAULIC RESERVOIR TO HYDRAULIC PUMP SUCTION PORT</b>       |                                  |     |
|           |          | 29888                                                           | FITTING, #20 ORB X #20 JIC 45°   | 1   |
|           |          | 20G4H 20G-20FJX45 20G-20FJX 25                                  | HYDRAULIC HOSE                   | 1   |
|           |          | 29885                                                           | FITTING, #16 ORB X #20 JIC STR.. | 1   |
|           | <b>2</b> | <b>HYDRAULIC PUMP (REAR PORT) TO HYDRAULIC VALVE “P” PORT</b>   |                                  |     |
|           |          | 29842                                                           | FITTING, #12 ORB X #10 JIC 90°.  | 1   |
|           |          | 8M3K 8G-10FJX 8G-10FJX 29                                       | HYDRAULIC HOSE                   | 1   |
|           |          | 29805                                                           | FITTING, #10 JIC BULKHEAD        | 1   |
|           |          | 29807                                                           | NUT, BULKHEAD FITTING            | 1   |
|           |          | 46277                                                           | TUBE, HYDRAULIC PRESSURE         | 1   |
|           |          | 8M3K 8G-8FJX90S 8G-10FJX 27                                     | HYDRAULIC HOSE                   | 1   |
|           |          | 29896                                                           | FITTING, #8 ORB X #8 JIC 90°.    | 1   |
|           | <b>3</b> | <b>HYDRAULIC VALVE “AA” PORT TO AGITATOR MOTOR REAR PORT</b>    |                                  |     |
|           |          | 29919                                                           | FITTING, #6 ORB X #8 JIC STR.    | 1   |
|           |          | 6M3K 6G-6FJX 6G-8FJX90L 36                                      | HYDRAULIC HOSE                   | 1   |
|           |          | 29808                                                           | FITTING, #6 JIC X #6 JIC UNION   | 1   |
|           |          | 46721                                                           | TUBE, HYDRAULIC PRESSURE         | 1   |
|           |          | 22029                                                           | FITTING, #10 ORB X #6 JIC STR.   | 1   |
|           | <b>4</b> | <b>AGITATOR MOTOR (FRONT PORT) TO HYDRAULIC VALVE “AB” PORT</b> |                                  |     |
|           |          | 22029                                                           | FITTING, #10 ORB X #6 JIC STR.   | 1   |
|           |          | 46722                                                           | TUBE, HYDRAULIC RETURN           | 1   |
|           |          | 29808                                                           | FITTING, #6 JIC X #6 JIC UNION   | 1   |
|           |          | 6M3K 6G-6FJX 6G-6FJX90S 35                                      | HYDRAULIC HOSE                   | 1   |
|           |          | 40308                                                           | FITTING, #6 ORB X #6 JIC LONG    | 1   |
|           | <b>5</b> | <b>HYDRAULIC VALVE “PA” TO FLOW CONTROL #1 PORT</b>             |                                  |     |
|           |          | 40308                                                           | FITTING, #6 ORB X #6 JIC LONG    | 1   |
|           |          | 6M3K 6G-6FJX90S 6G-8FJX 18                                      | HYDRAULIC HOSE                   | 1   |
|           |          | 29896                                                           | FITTING, #8 ORB X #8 JIC 90°     | 1   |

**Chapter 9 Illustrated Parts List**




DIN PLUG LOCATION

**Fig. 9.22 Hydraulic Diagram W/ Compressor 46200EC63, 46200SC63**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM      | PART NO.                                                         | DESCRIPTION                     | QTY |
|-----------|-----------|------------------------------------------------------------------|---------------------------------|-----|
| Fig. 9.21 | <b>6</b>  | <b>FLOW CONTROL #3 PORT TO PUMP MOTOR (TOP PORT)</b>             |                                 |     |
|           |           | 29896                                                            | FITTING, #8 ORB X #8 JIC 90°    | 1   |
|           |           | 8M3K 8G-8FJX 8G-8FJX 47                                          | HYDRAULIC HOSE                  | 1   |
|           |           | 29913                                                            | FITTING, #10 ORB X #8 JIC STR.  | 1   |
|           | <b>7</b>  | <b>PUMP MOTOR (BOTTOM PORT) TO HYDRAULIC VALVE "PB" PORT</b>     |                                 |     |
|           |           | 29913                                                            | FITTING, #10 ORB X #8 JIC STR.  | 1   |
|           |           | 8M3K 8G-8FJX 8G-8FJX90S 28                                       | HYDRAULIC HOSE                  | 1   |
|           |           | 29919                                                            | FITTING, #6 ORB X #8 JIC STR.   | 1   |
|           | <b>8</b>  | <b>FLOW CONTROL #2 PORT TO HYDRAULIC VALVE TANK PORT</b>         |                                 |     |
|           |           | 29896                                                            | FITTING, #8 ORB X #8 JIC STR.   | 1   |
|           |           | 8M3K 8G-8FJX 8G-8FJX90S 22                                       | HYDRAULIC HOSE                  | 1   |
|           |           | 29932                                                            | FITTING, #8 ORB RUN TEE         | 1   |
|           | <b>9</b>  | <b>HYDRAULIC VALVE TANK PORT TO HYDRAULIC OIL COOLER</b>         |                                 |     |
|           |           | 29932                                                            | FITTING, #8 ORB RUN TEE         | 1   |
|           |           | 8M3K 8G-8FJX 8G-10FJX 20                                         | HYDRAULIC HOSE                  | 1   |
|           |           | 29805                                                            | FITTING, #10 JIC BULKHEAD       | 1   |
|           |           | 29807                                                            | NUT, BULKHEAD FITTING           | 1   |
|           |           | 46276                                                            | TUBE, HYDRAULIC RETURN          | 1   |
|           |           | 29805                                                            | FITTING, #10 JIC BULKHEAD       | 1   |
|           |           | 29807                                                            | NUT, BULKHEAD FITTING           | 1   |
|           |           | 8M3K 8G-10FJX 8G-12FJX 36                                        | HYDRAULIC HOSE                  | 1   |
|           |           | 27692                                                            | FITTING, #16 FJIC X #12 JIC     | 1   |
|           |           | 29951                                                            | FITTING, #16 ORB RUN TEE.       | 1   |
|           | <b>10</b> | <b>HYDRAULIC PUMP (FRONT PORT) TO COMPRESSOR VALVE "P1" PORT</b> |                                 |     |
|           |           | 29842                                                            | FITTING, #12 ORB X #10 JIC 90°  | 1   |
|           |           | 10M3K 10G-12FJX 10G-10FJX90S 48                                  | HYDRAULIC HOSE                  | 1   |
|           |           | 29821                                                            | FITTING, #12 ORB X #10 JIC STR. | 1   |

**Chapter 9 Illustrated Parts List**




**Fig. 9.23 Hydraulic Diagram W/ Compressor 46200EC63, 46200SC63**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM      | PART NO.                                                 | DESCRIPTION                      | QTY |
|-----------|-----------|----------------------------------------------------------|----------------------------------|-----|
| Fig. 9.22 | <b>11</b> | <b>HYDRAULIC VALVE “P2” PORT TO COMPRESSOR MOTOR</b>     |                                  |     |
|           |           | 29821                                                    | FITTING, #12 ORB X #10 JIC STR.  | 1   |
|           |           | 45475                                                    | COMPRESSOR SUPPLY LINE           | 1   |
|           |           | 29819                                                    | FITTING, #12 ORB X #12 JIC STR.  | 1   |
|           | <b>12</b> | <b>COMPRESSOR MOTOR TO COMPRESSOR VALVE “T” PORT</b>     |                                  |     |
|           |           | 29819                                                    | FITTING, #12 ORB X #12 JIC STR.. | 1   |
|           |           | 45476                                                    | COMPRESSOR RETURN LINE           | 1   |
|           |           | 29900                                                    | FITTING, #12 ORB RUN TEE         | 1   |
|           | <b>13</b> | <b>COMPRESSOR VALVE “T” PORT TO HYDRAULIC OIL COOLER</b> |                                  |     |
|           |           | 29900                                                    | FITTING, #12 ORB RUN TEE         | 1   |
|           |           | 16M3K 16G-12FJX 16G-16FJX90S 68                          | HYDRAULIC HOSE                   | 1   |
|           |           | 29951                                                    | FITTING, #16 ORB RUN TEE         | 1   |
|           | <b>14</b> | <b>HYDRAULIC OIL COOLER TO HYDRAULIC TANK</b>            |                                  |     |
|           |           | 29824                                                    | FITTING, #16 ORB X #16 JIC 90°   | 1   |
|           |           | 16M3K 16G-16FJX 16G-16FJX 23                             | HYDRAULIC HOSE                   | 1   |
|           |           | 29818                                                    | FITTING, #20 ORB X #16 JIC STR.  | 1   |

**Chapter 9 Illustrated Parts List**

**9.19 Diesel Line Schematic**




**Fig. 9.24 Diesel Fuel Line Schematic**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM                                                       | PART NO. | DESCRIPTION                       | QTY. |
|-----------|------------------------------------------------------------|----------|-----------------------------------|------|
| Fig. 9.23 | <b>1. DIESEL FUEL TANK TO ENGINE FUEL FILTER "IN" PORT</b> |          |                                   |      |
|           | 1                                                          | 26782    | FITTING, 1/4 MPT X 5/16 JIC ELBOW | 1    |
|           | 1                                                          | 26767    | FITTING, #5 HOSE PUSH-ON          | 1    |
|           | 1                                                          | 29591    | HOSE, 5/16 FUEL LINE              | 1    |
|           | 2                                                          | 26080    | CLAMP, #4 GEAR                    | 2    |
|           | 1                                                          | -        | BANJO FITTING                     | REF. |
|           | <b>2. ENGINE FUEL FILTER UPPER FITTING TO BURNER</b>       |          |                                   |      |
|           | 1                                                          | -        | BANJO FITTING                     | REF. |
|           | 1                                                          | 29591    | HOSE, 5/16 FUEL LINE              | 1    |
|           | 1                                                          | 26767    | FITTING, #5 HOSE PUSH-ON          | 1    |
|           | 1                                                          | 26782    | FITTING, 1/4 MPT X 5/16 JIC ELBOW | 1    |
|           | 2                                                          | 26080    | CLAMP, #4 GEAR                    | 2    |
|           | <b>3. ENGINE RETURN LINE TO DIESEL FUEL TANK</b>           |          |                                   |      |
|           | 1                                                          | 29591    | HOSE, 5/16 FUEL LINE              | 1    |
|           | 1                                                          | 26767    | FITTING, #5 HOSE PUSH-ON          | 1    |
|           | 1                                                          | 26782    | FITTING, 1/4 MPT X 5/16 JIC ELBOW | 1    |
|           | 2                                                          | 26080    | CLAMP, #4 GEAR                    | 2    |

## Chapter 9 Illustrated Parts List

### 9.21 Electrical Schematic – Electric Hose




**Fig. 9.25 Electrical Schematic 46200EB, 46200EC63**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM | PART NO. | DESCRIPTION                       | QTY. |
|-----------|------|----------|-----------------------------------|------|
| Fig. 9.24 | 1    | 47202    | CONTROL BOX ASSEMBLY              | 1    |
|           | 2    | 45970    | WIRING HARNESS, EXTENSION         | 1    |
|           | 3    | 51836    | CABLE ASSEMBLY, TRIGGER           | 1    |
|           | 4    | 51835    | CABLE ASSEMBLY, ENGINE            | 1    |
|           | 5    | 51834    | CABLE ASSEMBLY, SENSOR            | 1    |
|           | 6    | 39608    | LID SWITCH                        | 2    |
|           | 7    | 43465    | SENSOR, RTD                       | 2    |
|           | 8    | 46791    | JUNCTION BOX, HOSE                | 1    |
|           | 9    | 31512    | CIRCUIT BREAKER                   | 1    |
|           | 10   | 43612    | GENERATOR                         | 1    |
|           | 11   | 43984    | CABLE ASSEMBLY, VALVE             | 1    |
|           | 12   | 56940    | SENSOR, RTD – PUMPING TEMPERATURE | 2    |
|           | 13   | 43947    | CABLE ASSEMBLY, HOSE              | 1    |
|           | 14   | 45569    | WIRING HARNESS, COOLER            | 1    |
|           | 15   | 45542    | SWITCH, TEMPERATURE – OIL COOLER  | 1    |
|           | 16   | 45349    | SWITCH, TEMPERATURE – COMPRESSOR  | 1    |
|           | 17   | 43886    | CABLE ASSEMBLY, COMPRESSOR VALVE  | 1    |
|           | 18   | 39602    | SOLENOID, FRAME                   | 1    |

## Chapter 9 Illustrated Parts List

### 9.22 Electrical Schematic – Standard Hose




**Fig. 9.26 Electrical Schematic – 46200SB, 46200SC63**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM | PART NO. | DESCRIPTION                       | QTY. |
|-----------|------|----------|-----------------------------------|------|
| Fig. 9.25 | 1    | 47201    | CONTROL BOX ASSEMBLY              | 1    |
|           | 2    | 45970    | WIRING HARNESS, EXTENSION         | 1    |
|           | 3    | 51836    | CABLE ASSEMBLY, TRIGGER           | 1    |
|           | 4    | 51835    | CABLE ASSEMBLY, ENGINE            | 1    |
|           | 5    | 51834    | CABLE ASSEMBLY, SENSOR            | 1    |
|           | 6    | 39608    | LID SWITCH                        | 2    |
|           | 7    | 43465    | SENSOR, RTD                       | 2    |
|           | 8    | 31512    | CIRCUIT BREAKER                   | 1    |
|           | 9    | 43984    | CABLE ASSEMBLY, VALVE             | 1    |
|           | 10   | 56940    | SENSOR, RTD – PUMPING TEMPERATURE | 2    |
|           | 11   | 45569    | WIRING HARNESS, COOLER            | 1    |
|           | 12   | 45542    | SWITCH, TEMPERATURE – OIL COOLER  | 1    |
|           | 13   | 45349    | SWITCH, TEMPERATURE – COMPRESSOR  | 1    |
|           | 14   | 43886    | CABLE ASSEMBLY, COMPRESSOR VALVE  | 1    |
|           | 15   | 39602    | SOLENOID, FRAME                   | 1    |

## Chapter 9 Illustrated Parts List

### 9.23 Hot Air Lance



**Fig. 9.27 Hot Air Lance (Option)**

## Chapter 9 Illustrated Parts List

| FIG.      | ITEM | PART NO. | DESCRIPTION                              | QTY. |
|-----------|------|----------|------------------------------------------|------|
| Fig. 9.25 | 1    | 45651    | MIXING BLOCK                             | 1    |
|           | 2    | 51401    | NIPPLE, 1/4 NPT HEX                      | 2    |
|           | 3    | 29195    | VALVE, 1/4" BALL                         | 2    |
|           | 4    | 45656    | AIR MIXER TUBE                           | 1    |
|           | 5    | 45658    | PROPANE TUBE W/ ORFICE                   | 1    |
|           | 6    | 45652    | BURNER BASE                              | 1    |
|           | 7    | 28340    | BUSHING, 1/4" NPT X 1/8" NPT             | 1    |
|           | 8    | 45654    | PRIMARY BURNER TUBE                      | 1    |
|           | 9    | 45657    | AIR LANCE TUBE                           | 1    |
|           | 10   | 45668    | AIR ORFICE "A" - .125"                   | 1    |
|           | 11   | 45653    | MAIN BURNER TUBE                         | 1    |
|           | 12   | 45670    | SCREW, #10-32 X 1/2" ALLEN SCREW         | 4    |
|           | 13   | 45672    | SCREW, #10-32 X 1/2" ALLEN SET           | 1    |
|           | 14   | 45671    | SCREW, 1/4-20 X 3/8" ALLEN SET           | 1    |
|           | 15   | 45669    | NUT, 1/8-27 JAM                          | 1    |
|           | 16   | 27990    | PLUG, 1/4" COUNTERSUNK                   | 1    |
|           | 17   | 45655    | HANDLE ASSEMBLY                          | 1    |
|           | 18   | 45663    | BUSHING, 3/8" NPT X 1/4" NPT REDUCER     | 1    |
|           | 19   | 45659    | VALVE, NEEDLE                            | 1    |
|           | 20   | 45675    | HOSE ASSEMBLY, PROPANE                   | 1    |
|           | 21   | 45679    | COUPLING, 1/4" FPT X M                   | 1    |
|           | 22   | 45681    | COUPLING, 1/4" NPT X FM                  | 1    |
|           | 23   | 45664    | FITTING, 1/4" NPT X 3/8 JIC FERRULE LOCK | 1    |



## **Chapter 10 Tools and Accessories**

### **10.0 Tools and Accessories**



**Crafcro Applicator Disk**

27162 – 3" Disk Assembly  
27163 – 4" Disk Assembly  
27164 – 6" Disk Assembly



**Crafcro Swivel Disk Applicator**

27120 – 3" Swivel Applicator  
27130 – 4" Swivel Applicator



**Crafcro Sealing Foot/Flush**

27154 – 1/4" Flush  
27155 – 3/8" Flush



**Crafcro Sealing Foot/Protruded**

27159 – 1/4" Protruding  
27160 – 3/8" Protruding



**Crafcro Joint Sealing Tip**

27146 – 1/4" Sealing Tip  
27147 – 3/8" Sealing Tip



**Crafcro Round Sealing Tip**

27170 – 3/8" Sealing Tip  
27171 – 1/2" Sealing Tip



**Crafcro Cold Air Lance - 42648**

**Chapter 10 Tools and Accessories**



**Crafc Heavy Duty Squeegee with  
Aluminum Handle - 27199**  
27195 – Replacement Blade



**Crafc Pour Pot with Wheels - 40200**



**Super Shot Drip Stopper**  
Use with 50270 Duckbill  
27114 – Tip Adapter  
27115 – Shroud, Tip Adapter



**Crafc Hand Held Pour Pot - 40201**



**Crafc Duckbill - 50270**



**Crafc Heat Lance - 31370**

## **Chapter 10 Tools and Accessories**



**Crafcro Heat Lance with Regulator  
and Attachments - 32259**



**Crafcro Hand Torch w/ 20ft. Hose - 25012**







©2016 Crafco, Inc.